

**adic**

The ADIC  
Distributed AML Server

**DAS V3.10E  
Interfacing  
Guide**

 Advanced Digital Information Corp

---

---

## Copyright Notice

© *Copyright* ADIC 2001

The information contained in this document is subject to change without notice.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without prior written consent of ADIC.

ADIC shall not be liable for errors contained herein or for incidental or consequential damages (including lost profits) in connection with the furnishing, performance or use of this material whether based on warranty, contract, or other legal theory.

All trademarks within this document are the property of their respective owners.

## Copyright Notice (Europe)

© *Copyright* ADIC Europe 2001

All rights reserved. No part of this document may be copied or reproduced in any form or by any means, without prior written permission of ADIC Europe, ZAC des Basses Auges, 1 rue Alfred de Vigny, 78112 Fourqueux, FRANCE.

ADIC Europe assumes no responsibility for any errors that may appear in this document, and retains the right to make changes to these specifications and descriptions at any time, without notice.

This publication may describe designs for which patents are pending, or have been granted. By publishing this information, ADIC Europe conveys no license under any patent or any other right.

ADIC Europe makes no representation or warranty with respect to the contents of this document and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, ADIC Europe reserves the right to revise or change this publication without obligation on the part of ADIC Europe to notify any person or organization of such revision of change.

Every effort has been made to acknowledge trademarks and their owners. Trademarked names are used solely for identification or exemplary purposes, any omission is unintentional.

ADIC and ADIC Europe are trademarks of Advanced Digital Information Corporation.

ADIC	ADIC Europe	ADIC Germany Beteiligungs GmbH, KG
Tel.: +1 303-705-3900	ZAC des Basses Auges	Eschenstraße 3
Fax: +1-303-792-2465	1, rue Alfred de Vigny	D-89558 Böhmenkirch, Germany
ATAC: 1-800-827-3822	78112 Fourqueux, France	Tel:+00.800.9999.3822
www.adic.com	Tel.: +33.1.3087.5300	
	Fax: +33.1.3087.5301	

Document number: 601626-B

Published: 21 Dec 2001

Printed in the USA

**ADIC CORPORATE • 11431 WILLOWS ROAD, NE • REDMOND, WASHINGTON, USA • 1-800-336-1233**  
**ADIC • 8560 UPLAND DRIVE • PARKER, COLORADO, USA • 1-800-827-3822**  
**ADIC • 10 BROWN ROAD • ITHACA, NEW YORK, USA • 1-607-266-4000**





# Contents

1

---

## Introduction

Overview .....	1-3
Intended Audience .....	1-3
Organization .....	1-3
Associated Documents .....	1-4
Explanation of Symbols and Notes .....	1-4
Assistance .....	1-5

2

---

## DAS ACI

Overview .....	2-3
DAS/2 .....	2-3
ACI Services .....	2-4
Client Services .....	2-4
ACI Routines - Basic Services .....	2-5
ACI Routines - Complete Services .....	2-5



Media Types .....	2-7
DAS Error Codes .....	2-8

# 3

## Safety

Overview .....	3-3
Hazard Alert Messages .....	3-3
Validity .....	3-5

# 4

## DAS ACI Functions

Overview .....	4-5
aci_barcode .....	4-5
Return Values .....	4-6
aci_cancel .....	4-7
Return Values .....	4-8
aci_cleandrive .....	4-9
Return Values .....	4-9
aci_clientaccess .....	4-11
Return Values .....	4-12
aci_clientstatus .....	4-14
Return Values .....	4-15
aci_dismount .....	4-16
Return Values .....	4-17
aci_driveaccess .....	4-18
Return Values .....	4-20
aci_drivestatus .....	4-21
Return Values .....	4-22
aci_drivestatus2 .....	4-22

---



---

Return Values .....	4-25
aci_drivestatus3 .....	4-26
Return Values .....	4-29
aci_drivestatus4 .....	4-29
Return Values .....	4-31
aci_drivestatus_one .....	4-32
Return Values .....	4-33
aci_drivestatus2_one .....	4-34
Return Values .....	4-35
aci_drivestatus3_one .....	4-36
Return Values .....	4-37
aci_eif_conf .....	4-38
Return Values .....	4-39
aci_eject .....	4-39
Return Values .....	4-40
aci_eject2 .....	4-42
Return Values .....	4-43
aci_eject3 .....	4-46
Return Values .....	4-47
aci_eject_complete .....	4-49
Return Values .....	4-50
aci_eject2_complete .....	4-51
Return Values .....	4-53
aci_eject3_complete .....	4-54
Return Values .....	4-56
aci_ejectclean .....	4-57
Return Values .....	4-58
aci_email .....	4-60
Return Values .....	4-61
aci_flip .....	4-61
Return Values .....	4-62
aci_force .....	4-64
Return Values .....	4-64
aci_foreign .....	4-66
Return Values .....	4-67
aci_getvolsertodrive .....	4-68
Return Values .....	4-69

---



---

aci_getVolserToSide .....	4-70
Return Values .....	4-71
aci_init .....	4-72
Return Values .....	4-73
aci_initialize .....	4-74
Return Values .....	4-74
aci_insert .....	4-75
Return Values .....	4-76
aci_insert2 .....	4-77
Return Values .....	4-79
aci_inventory .....	4-81
Return Values .....	4-81
aci_killamu .....	4-82
Return Values .....	4-83
aci_list .....	4-84
Return Values .....	4-86
aci_list2 .....	4-87
Return Values .....	4-89
aci_list_foreign .....	4-89
Return Values .....	4-90
aci_mount .....	4-91
Return Values .....	4-91
aci_partial_inventory .....	4-93
Return Values .....	4-95
aci_perror .....	4-96
aci_qversion .....	4-97
Return Values .....	4-97
aci_qvolsrange .....	4-98
Return Values .....	4-101
aci_register .....	4-103
Return Values .....	4-104
aci_robhome .....	4-106
Return Values .....	4-106
aci_robstat .....	4-107
Return Values .....	4-108
aci_scratch_get .....	4-109
Return Values .....	4-110

---



---

aci_scratch_info .....	4-111
Return Values .....	4-112
aci_scratch_set .....	4-114
Return Values .....	4-115
aci_scratch_unset .....	4-116
Return Values .....	4-117
aci_shutdown .....	4-118
Return Values .....	4-118
aci_snmp .....	4-119
Return Values .....	4-119
aci_switch .....	4-120
Return Values .....	4-121
aci_unload .....	4-122
Return Values .....	4-122
aci_view .....	4-123
Return Values .....	4-125
aci_volser_inventory .....	4-126
Return Values .....	4-127
aci_volseraccess .....	4-128
Return Values .....	4-128
aci_volserstatus .....	4-129
Return Values .....	4-130

# 5

---

## DAS ACI 3.0 Asynchronous Support Layer

Overview .....	5-3
How It Works .....	5-3
Sadmin Sample Application .....	5-3
Sadmin Syntax .....	5-4
Contents of the Async Support Layer Library .....	5-4
aci_async_add() .....	5-5
Parameters .....	5-5
das_mount .....	5-6
das_dismount .....	5-7

---



---

das_force .....	5-7
das_insert .....	5-8
das_eject .....	5-9
das_eject_complete .....	5-10
Return Values .....	5-11
aci_async_create() .....	5-13
Return Values .....	5-13
aci_async_find() .....	5-14
Return Values .....	5-15
aci_async_free() .....	5-16
Return Values .....	5-16
Macros .....	5-16
aci_mount .....	5-16
Return Values .....	5-17
aci_dismount .....	5-17
Return Value .....	5-17
aci_force .....	5-17
Return Values .....	5-18
aci_insert .....	5-18
Returned values .....	5-18
aci_eject .....	5-19
Return Values .....	5-19
aci_eject_complete .....	5-19
Return Values .....	5-20
Response Technique .....	5-21
Setup .....	5-21
Signal Handler Routine .....	5-22
Data structures .....	5-23
aci_async_entry .....	5-23
Parameter Data (Parms Structure) .....	5-25
Response Data (Structure) .....	5-26
st_response .....	5-26
st_mount_parms .....	5-26
st_insert_response .....	5-27

# A

---

## Application Notes

Overview .....	A-3
----------------	-----

---

---

Error Recovery Procedures .....	A-3
Terms .....	A-9

---

## **Index**



# Figures

<b>Figure 2-1</b>	Logical Relationship Between AML Components .....	2-3
<b>Figure 4-1</b>	aci_barcode Function Call .....	4-5
<b>Figure 4-2</b>	Example of the aci_barcode Function.....	4-7
<b>Figure 4-3</b>	aci_cancel Function Call .....	4-7
<b>Figure 4-4</b>	Example of the aci_cancel Function .....	4-8
<b>Figure 4-5</b>	aci_cleandrive Function Call .....	4-9
<b>Figure 4-6</b>	aci_clientaccess Function Call .....	4-11
<b>Figure 4-7</b>	Example of the aci_clientaccess Function .....	4-13
<b>Figure 4-8</b>	aci_clientstatus Function Call .....	4-14
<b>Figure 4-9</b>	Returned Configuration Information.....	4-14
<b>Figure 4-10</b>	Example of the aci_clientstatus Function.....	4-16
<b>Figure 4-11</b>	aci_dismount Function Call .....	4-16
<b>Figure 4-12</b>	Example of the aci_dismount Function .....	4-18
<b>Figure 4-13</b>	aci_driveaccess Function Call .....	4-18
<b>Figure 4-14</b>	Example of the aci_driveaccess Function.....	4-20
<b>Figure 4-15</b>	aci_drivestatus Function Call .....	4-21
<b>Figure 4-16</b>	Returned Status .....	4-21
<b>Figure 4-17</b>	aci_drivestatus2 Function Call .....	4-22
<b>Figure 4-18</b>	Returned Status .....	4-23
<b>Figure 4-19</b>	Example of the aci_drivestatus2 Function.....	4-26
<b>Figure 4-20</b>	aci_drivestatus3 Function Call .....	4-27
<b>Figure 4-21</b>	Returned Status .....	4-27



---



---

<b>Figure 4-22</b>	aci_drivestatus4 Function Call . . . . .	4-29
<b>Figure 4-23</b>	Returned Status . . . . .	4-30
<b>Figure 4-24</b>	aci_drivestatus_one Function Call . . . . .	4-32
<b>Figure 4-25</b>	Returned Status . . . . .	4-32
<b>Figure 4-26</b>	aci_drivestatus_2_one Function Call . . . . .	4-34
<b>Figure 4-27</b>	Returned Status . . . . .	4-34
<b>Figure 4-28</b>	aci_drivestatus_3_one Function Call . . . . .	4-36
<b>Figure 4-29</b>	Returned Status . . . . .	4-36
<b>Figure 4-30</b>	aci_eif_conf Function Call . . . . .	4-38
<b>Figure 4-31</b>	Returned Status . . . . .	4-38
<b>Figure 4-32</b>	aci_eject Function Call . . . . .	4-39
<b>Figure 4-33</b>	Example of the aci_eject Function. . . . .	4-41
<b>Figure 4-34</b>	aci_eject2 Function Call . . . . .	4-42
<b>Figure 4-35</b>	Structure of the aci_ei_info function from aci.h . . . . .	4-42
<b>Figure 4-36</b>	Example of the aci_eject2 Function. . . . .	4-45
<b>Figure 4-37</b>	aci_eject3 Function Call . . . . .	4-46
<b>Figure 4-38</b>	Structure of the aci_ei_info function. . . . .	4-46
<b>Figure 4-39</b>	aci_eject_complete function call . . . . .	4-49
<b>Figure 4-40</b>	Example of the aci_eject_complete Function. . . . .	4-51
<b>Figure 4-41</b>	aci_eject2_complete Function Call . . . . .	4-51
<b>Figure 4-42</b>	Structure of the aci_ei_info function. . . . .	4-51
<b>Figure 4-43</b>	Example of the aci_eject2_complete Function. . . . .	4-54
<b>Figure 4-44</b>	aci_eject3_complete Function Call . . . . .	4-54
<b>Figure 4-45</b>	Structure of the aci_ei_info function. . . . .	4-55
<b>Figure 4-46</b>	aci_ejectclean Function Call . . . . .	4-57
<b>Figure 4-47</b>	Structure of the aci_ei_info function from aci.h . . . . .	4-57
<b>Figure 4-48</b>	Example of the aci_ejectclean Function . . . . .	4-60
<b>Figure 4-49</b>	aci_email Function Call . . . . .	4-60
<b>Figure 4-50</b>	aci_flip Function Call . . . . .	4-61
<b>Figure 4-51</b>	Example of the aci_flip Function. . . . .	4-63
<b>Figure 4-52</b>	aci_force Function Call . . . . .	4-64
<b>Figure 4-53</b>	Example of the aci_force Function . . . . .	4-65
<b>Figure 4-54</b>	aci_foreign Function Call . . . . .	4-66

---



---

<b>Figure 4-55</b>	Example of the aci_foreign Function.....	4-68
<b>Figure 4-56</b>	aci_getvolsertodrive Function Call.....	4-68
<b>Figure 4-57</b>	aci_voltodrive_entry Structure .....	4-69
<b>Figure 4-58</b>	Example of the aci_getvolsertodrive Function.....	4-70
<b>Figure 4-59</b>	aci_getVolserToSide Function Call.....	4-70
<b>Figure 4-60</b>	Structure of Type aci_sideinfo.....	4-71
<b>Figure 4-61</b>	Example of the aci_getvolsertoside Function .....	4-72
<b>Figure 4-62</b>	aci_init Function Call .....	4-72
<b>Figure 4-63</b>	Example of the aci_init Function.....	4-73
<b>Figure 4-64</b>	aci_initialize Function Call.....	4-74
<b>Figure 4-65</b>	Example of the aci_initialize Function.....	4-74
<b>Figure 4-66</b>	aci_insert Function Call .....	4-75
<b>Figure 4-67</b>	Example of the aci_insert Function.....	4-77
<b>Figure 4-68</b>	aci_insert2 Function Call .....	4-77
<b>Figure 4-69</b>	aci_ei_info Structure from aci.h.....	4-78
<b>Figure 4-70</b>	Example of the aci_insert2 Function.....	4-80
<b>Figure 4-71</b>	aci_inventory Function Call.....	4-81
<b>Figure 4-72</b>	Example of the aci_inventory Function .....	4-82
<b>Figure 4-73</b>	aci_killamu Function Call.....	4-82
<b>Figure 4-74</b>	Example of the aci_killamu Function.....	4-83
<b>Figure 4-75</b>	aci_list Function Call.....	4-84
<b>Figure 4-76</b>	Example of the Returned Structure.....	4-84
<b>Figure 4-77</b>	Example of the aci_list Function .....	4-86
<b>Figure 4-78</b>	aci_list2 Function Call.....	4-87
<b>Figure 4-79</b>	Example of the Returned Structure.....	4-87
<b>Figure 4-80</b>	aci_list_foreign Function Call .....	4-89
<b>Figure 4-81</b>	Example of the Returned Structure.....	4-90
<b>Figure 4-82</b>	aci_mount Function Call .....	4-91
<b>Figure 4-83</b>	Example of the aci_mount Function.....	4-93
<b>Figure 4-84</b>	aci_partial_inventory Function Call.....	4-93
<b>Figure 4-85</b>	Example of the aci_partial_inventory Function .....	4-95
<b>Figure 4-86</b>	aci_perror Function Call.....	4-96
<b>Figure 4-87</b>	Example of the aci_perror Function .....	4-96

---



---

<b>Figure 4-88</b>	aci_qversion Function Call . . . . .	4-97
<b>Figure 4-89</b>	Example of the aci_qversion Function . . . . .	4-98
<b>Figure 4-90</b>	aci_qvolstrange Function Call . . . . .	4-98
<b>Figure 4-91</b>	Amount of Listed Volsers. . . . .	4-99
<b>Figure 4-92</b>	Structure for the aci_volserinfo . . . . .	4-99
<b>Figure 4-93</b>	Example of the aci_qvolstrange Function . . . . .	4-102
<b>Figure 4-94</b>	aci_register Function Call . . . . .	4-103
<b>Figure 4-95</b>	Example of the aci_register Function . . . . .	4-105
<b>Figure 4-96</b>	aci_robhome Function Call . . . . .	4-106
<b>Figure 4-97</b>	Example of the aci_robhome Function. . . . .	4-107
<b>Figure 4-98</b>	aci_robstat Function Call . . . . .	4-107
<b>Figure 4-99</b>	Example of the aci_robstat Function. . . . .	4-109
<b>Figure 4-100</b>	aci_scratch_get Function Call . . . . .	4-109
<b>Figure 4-101</b>	Example of the aci_scratch_get Function. . . . .	4-111
<b>Figure 4-102</b>	aci_scratch_info Function Call . . . . .	4-111
<b>Figure 4-103</b>	Example of the aci_scratch_info Function . . . . .	4-113
<b>Figure 4-104</b>	aci_scratch_set Function Call . . . . .	4-114
<b>Figure 4-105</b>	Example of the aci_scratch_set Function . . . . .	4-115
<b>Figure 4-106</b>	aci_scratch_unset Function Call . . . . .	4-116
<b>Figure 4-107</b>	Example of the aci_scratch_unset Function. . . . .	4-117
<b>Figure 4-108</b>	aci_shutdown Function Call . . . . .	4-118
<b>Figure 4-109</b>	Example of the aci_shutdown Function. . . . .	4-119
<b>Figure 4-110</b>	aci_snmp Function Call . . . . .	4-119
<b>Figure 4-111</b>	aci_switch Function Call . . . . .	4-120
<b>Figure 4-112</b>	Example of the aci_switch Function . . . . .	4-121
<b>Figure 4-113</b>	aci_unload Function Call . . . . .	4-122
<b>Figure 4-114</b>	aci_view Function Call . . . . .	4-123
<b>Figure 4-115</b>	Volser Information Contained in the aci_volume_desc Structure	4-123
<b>Figure 4-116</b>	Example of the aci_view Function . . . . .	4-126
<b>Figure 4-117</b>	aci_volser_inventory Function Call . . . . .	4-126
<b>Figure 4-118</b>	aci_volseraccess Function Call . . . . .	4-128
<b>Figure 4-119</b>	aci_volserstatus Function Call . . . . .	4-129
<b>Figure 4-120</b>	aci_volser_entry Structure . . . . .	4-130

---



---

<b>Figure 5-1</b>	Example of a Generic aci_async_add() Function . . . . .	5-5
<b>Figure 5-2</b>	aci_async_add Function with the das_mount Parameter . . . . .	5-6
<b>Figure 5-3</b>	Example of the aci_async_add Function with the das_mount Parameter . . . . .	5-6
<b>Figure 5-4</b>	aci_async_add Function with the das_dismount Parameter . . . . .	5-7
<b>Figure 5-5</b>	aci_async_add Function with the das_force Parameter. . . . .	5-7
<b>Figure 5-6</b>	aci_async_add Function with the das_insert Parameter . . . . .	5-8
<b>Figure 5-7</b>	aci_async_add Function with the das_eject Parameter . . . . .	5-9
<b>Figure 5-8</b>	aci_async_add Function with the das_eject_complete Parameter . . . . .	5-10
<b>Figure 5-9</b>	Example of an aci_async_add Function. . . . .	5-12
<b>Figure 5-10</b>	aci_async_create Function Call . . . . .	5-13
<b>Figure 5-11</b>	Example if the aci_async_create Function . . . . .	5-14
<b>Figure 5-12</b>	aci_async_find Function Call. . . . .	5-14
<b>Figure 5-13</b>	Example of the aci_async_find Function . . . . .	5-15
<b>Figure 5-14</b>	aci_async_free Function Call . . . . .	5-16
<b>Figure 5-15</b>	Example of aci_mount Asynchronous ACI Call. . . . .	5-16
<b>Figure 5-16</b>	aci_dismount Asynchronous ACI Call. . . . .	5-17
<b>Figure 5-17</b>	aci_force Asynchronous ACI Call. . . . .	5-18
<b>Figure 5-18</b>	aci_insert Asynchronous Function Call . . . . .	5-18
<b>Figure 5-19</b>	aci_eject Asynchronous Function Call . . . . .	5-19
<b>Figure 5-20</b>	aci_eject_complete Asynchronous Function Call . . . . .	5-19
<b>Figure 5-21</b>	Setup Signal Handler . . . . .	5-21
<b>Figure 5-22</b>	dasadmin Sample Application . . . . .	5-22
<b>Figure 5-23</b>	Common Structure for aci_async_entry. . . . .	5-24
<b>Figure 5-24</b>	async_drive_parms Structure . . . . .	5-25
<b>Figure 5-25</b>	async_ei_parms Structure . . . . .	5-25
<b>Figure 5-26</b>	async_response Structure. . . . .	5-26
<b>Figure 5-27</b>	async_mount_parms Structure . . . . .	5-26
<b>Figure 5-28</b>	async_insert_responce Structure. . . . .	5-27



# Tables

<b>Table 2-1</b>	Routines Available with Basic Service Access . . . . .	2-5
<b>Table 2-2</b>	Routines Available with Complete Service Access . . . . .	2-5
<b>Table 2-3</b>	Supported Media Types . . . . .	2-7
<b>Table 3-1</b>	Hazard Alert Message . . . . .	3-3
<b>Table 4-1</b>	Parameters for the aci_barcode Function Call . . . . .	4-5
<b>Table 4-2</b>	Parameter for the aci_cancel Function Call . . . . .	4-7
<b>Table 4-3</b>	Parameter for the aci_cleandrive Function Call . . . . .	4-9
<b>Table 4-4</b>	Parameters for the aci_clientaccess Function Call . . . . .	4-11
<b>Table 4-5</b>	Parameters for the aci_clientstatus Function Call . . . . .	4-15
<b>Table 4-6</b>	Parameters for the aci_dismount Function Call . . . . .	4-16
<b>Table 4-7</b>	Parameters for the aci_driveaccess Function Call . . . . .	4-19
<b>Table 4-8</b>	Parameters for the aci_drivestatus2 Function Call . . . . .	4-23
<b>Table 4-9</b>	Parameters for the aci_drivestatus3 Function Call . . . . .	4-27
<b>Table 4-10</b>	Parameters for the aci_drivestatus4 Function Call . . . . .	4-30
<b>Table 4-11</b>	Parameters for the aci_drivestatus_one Function Call . . . . .	4-33
<b>Table 4-12</b>	Parameters for the aci_drivestatus2_one Function Call . . . . .	4-35
<b>Table 4-13</b>	Parameters for the aci_drivestatus3_one Function Call . . . . .	4-37
<b>Table 4-14</b>	Parameters for the aci_eif_conf Function Call . . . . .	4-39
<b>Table 4-15</b>	Parameters for the aci_eject Function Call . . . . .	4-40
<b>Table 4-16</b>	Parameters for the aci_eject2 Function Call . . . . .	4-42
<b>Table 4-17</b>	Parameters for the aci_eject3 Function Call . . . . .	4-46
<b>Table 4-18</b>	Parameters for the aci_eject_complete Function Call . . . . .	4-49



---



---

<b>Table 4-19</b>	Parameters for the aci_eject2_complete Function Call. . . . .	4-52
<b>Table 4-20</b>	Parameters for the aci_eject3_complete Function Call. . . . .	4-55
<b>Table 4-21</b>	Parameters for the aci_ejectclean Function Call . . . . .	4-57
<b>Table 4-22</b>	Parameter for the aci_email Function Call. . . . .	4-61
<b>Table 4-23</b>	Parameter for the aci_flip Function Call . . . . .	4-62
<b>Table 4-24</b>	Parameter for the aci_force Function Call . . . . .	4-64
<b>Table 4-25</b>	Parameters for the aci_foreign Function Call . . . . .	4-66
<b>Table 4-26</b>	Parameters for the aci_getvolsertodrive Function Call . . . . .	4-69
<b>Table 4-27</b>	Parameters for the aci_getvolsertoside Function Call . . . . .	4-71
<b>Table 4-28</b>	Parameters for the aci_insert Function Call. . . . .	4-75
<b>Table 4-29</b>	Parameters for the aci_insert2 Function Call. . . . .	4-78
<b>Table 4-30</b>	Parameters for the aci_list Function Call . . . . .	4-85
<b>Table 4-31</b>	Explanation of the Req_types . . . . .	4-85
<b>Table 4-32</b>	Parameters for the aci_list2 Function Call . . . . .	4-88
<b>Table 4-33</b>	Explanation of the Req_types . . . . .	4-88
<b>Table 4-34</b>	Parameters for the aci_list_foreign Function Call. . . . .	4-90
<b>Table 4-35</b>	Parameters for the aci_mount Function Call. . . . .	4-91
<b>Table 4-36</b>	Parameters for the aci_partial_inventory Function Call . . . . .	4-94
<b>Table 4-37</b>	Parameter for the aci_perror Function Call . . . . .	4-96
<b>Table 4-38</b>	Parameters for the aci_qversion Function Call . . . . .	4-97
<b>Table 4-39</b>	Parameters for the aci_qvolsrange Function Call. . . . .	4-99
<b>Table 4-40</b>	Explanation of the Attrib Values. . . . .	4-100
<b>Table 4-41</b>	Parameters for the aci_register Function Call . . . . .	4-103
<b>Table 4-42</b>	Parameter for the aci_robhome Function Call . . . . .	4-106
<b>Table 4-43</b>	Parameters for the aci_robstat Function Call . . . . .	4-108
<b>Table 4-44</b>	Parameters for the aci_scratch_get Function Call. . . . .	4-110
<b>Table 4-45</b>	Parameters for the aci_scratch_info Function Call. . . . .	4-112
<b>Table 4-46</b>	Parameters for the aci_scratch_set Function Call. . . . .	4-114
<b>Table 4-47</b>	Parameters for the aci_scratch_unset Function Call. . . . .	4-116
<b>Table 4-48</b>	Parameter for the aci_shutdown Function Call . . . . .	4-118
<b>Table 4-49</b>	Parameter for the aci_snmp Function Call . . . . .	4-119
<b>Table 4-50</b>	Parameter for the aci_switch Function Call. . . . .	4-120
<b>Table 4-51</b>	Parameter for the aci_unload Function Call . . . . .	4-122

---



---

<b>Table 4-52</b>	Parameters for the aci_view Function Call . . . . .	4-124
<b>Table 4-53</b>	Table Types. . . . .	4-124
<b>Table 4-54</b>	Table Attributes . . . . .	4-125
<b>Table 4-55</b>	Parameters for the aci_volser_inventory Function Call. . . . .	4-127
<b>Table 4-56</b>	Parameters for the aci_volseraccess Function Call. . . . .	4-128
<b>Table 4-57</b>	Parameters for the aci_volserstatus Function Call . . . . .	4-130
<b>Table 5-1</b>	Parameters for the das_mount Parameter . . . . .	5-6
<b>Table 5-2</b>	Parameters for the das_dismount Parameter . . . . .	5-7
<b>Table 5-3</b>	Parameter for the das_force Parameter . . . . .	5-8
<b>Table 5-4</b>	Parameters for the das_insert Parameter . . . . .	5-9
<b>Table 5-5</b>	Parameters for the das_eject Parameter . . . . .	5-10
<b>Table 5-6</b>	Parameters for the das_eject_complete Parameter. . . . .	5-11
<b>Table 5-7</b>	Parameter for the aci_async_create Function . . . . .	5-13
<b>Table 5-8</b>	Parameter for the aci_async_find Function. . . . .	5-14
<b>Table 5-9</b>	Parameters for the aci_async_free Function . . . . .	5-16
<b>Table A-1</b>	Error Code Reactions . . . . .	A-3



# 1

## Introduction

Overview .....	1-3
Intended Audience .....	1-3
Organization .....	1-3
Associated Documents .....	1-4
Explanation of Symbols and Notes .....	1-4
Assistance .....	1-5





---

---

## Overview

This guide contains information and instructions necessary to program an application for using the ADIC AML via the Distributed AML Server (DAS). The topics discussed in this chapter are:

- Overview
- Intended Audience
- Organization
- Associated Documents
- Explanation of Symbols and Notes
- Assistance

## Intended Audience

This guide is intended for use by system programmers and administrators working with the DAS software. Knowledge of the UNIX and OS/2 operating systems is required.

## Organization

This manual is divided into the following chapters:

Chapter 1	Introduction - Notes on the use of the manual
Chapter 2	DAS ACI - Overview of the DAS/2 software and information on AML Client Interface (ACI) services
Chapter 3	Safety - Describes the hazard symbols, messages, safety features, and operational considerations
Chapter 4	DAS ACI Functions - Information and descriptions of ACI functions and function calls
Chapter 5	ACI 3.0 Asynchronous Support Layer - Provides a description of the Asynchronous ACI calls
Appendix A	Important Information - Error recovery procedures and explanations of terms used throughout this document

Index

---

---

## Associated Documents

You may wish to reference the following documents:

- 601324-A DAS V3.1 Release Guide
- 601625-A DAS V3.1 Administration Guide

## Explanation of Symbols and Notes

The following symbols and highlighted passages draw attention to important information.



Detailed explanations for the above symbols are provided in *Hazard Alert Messages* on page 3-3.

<1>+<2> Press these keys simultaneously.

*Italic*                   Headline, e.g., Chapter 3, *Safety*  
File name, e.g., *dasdata.ini*

**Bold**                   Terms appearing on the operating panel  
Special Term, e.g., Utilities  
Commands with or without parameters,  
e.g., **INITIALIZE**

Courier                   Command appearing on a console, e.g., `cd`  
Switch position, e.g., ON, OFF

---

---



## Assistance

If problems cannot be solved with the aid of this document or if recommended training is desired, contact the ADIC Technical Assistance Center (ATAC).

ADIC  
10949 East Peakview Avenue  
Englewood, CO 80112  
U.S.A.

- United States 1-800-827-3822
- Europe and Africa 00-800-9999-3822



# 2

## DAS ACI

Overview .....	2-3
DAS/2 .....	2-3
ACI Services .....	2-4
Client Services .....	2-4
ACI Routines - Basic Services .....	2-5
ACI Routines - Complete Services .....	2-5
Media Types .....	2-7
DAS Error Codes .....	2-8





---

---

## Overview

This section contains an overview of the DAS/2 software and information on AML Client Interface (ACI) services.

## DAS/2

DAS is a client/server software product designed to provide shared access to the family of ADIC AML systems (AMLs). The DAS software may be installed as a stand-alone AML connection or be configured to share an AML with MVS or other ADIC supported, host attachments. DAS may be requesting services via a client command line interface, or may be integrated with backup, tape management and/or HSM applications on the client to direct automated removable media activity through the DAS server to the automated media library. See Figure 2-1.




Figure 2-1 Logical Relationship Between AML Components

---

---

The DAS server component is an OS/2 program that runs within the AMU controller personal computer (PC). It converts DAS client requests into AMU AMS requests and sends them to the AMS for action. Fifty heterogeneous networked clients can be configured within the DAS server environment.

Clients requiring access to ADIC AML systems may use the DAS ACI software component to communicate library requests to the DAS server component. DAS clients make the necessary calls to the DAS server with remote procedure calls (RPC). The DAS ACI library component hides this interface from the client application and provides function calls to the library to request library operations. Clients may be granted complete or restricted access to the AML resources. DAS administrators control client access and privileges through client registration.

The DAS client ACI component provides a set of C function calls, available as static and/or dynamic libraries (depending on the operating system platform) for a range of operating system platforms. The libraries may be linked to application software, or be used with the command line administration command interface.

## ACI Services

Since the DAS server is a network server, all communication with the server component use a network application level protocol. The ACI hides the network support, and enables the user to treat the functions as 'stand-alone', without the need for a supporting structure. The ACI operates synchronously. Once a request is made to the AML, the request process does not regain control until the operation has completed or has otherwise terminated. (An exception is the inventory call, which starts a physical inventory, and returns.)

The ACI uses RPCs to request DAS services and to receive replies over the network. The RPC port mapper assures that port numbers are routed correctly.

## Client Services

The ACI provides two types of user services:

- Basic Services
- Complete Services

---

---

## ACI Routines - Basic Services

Table 2-1 lists the routines that are available to an ACI client with basic service access rights.

**Table 2-1** Routines Available with Basic Service Access

<b>Routine</b>	<b>Explanation</b>
aci_dismount	Dismount media from the drive.
aci_init	Initialize the AML for client use.
aci_initialize	Initialize ACI library for client use.
aci_mount	Mount specified media in drive.

## ACI Routines - Complete Services

Table 2-2 lists the routines that are available to an ACI client with complete service access rights.

**Table 2-2** Routines Available with Complete Service Access

<b>Routine</b>	<b>Explanation</b>
aci_barcode	Switching ON and Off Barcode Reading
aci_cancel	Cancel outstanding request.
aci_dismount	Dismount media from drive.
aci_cleandrive	Clean a drive (immediately)
aci_clientaccess	Change client access list.
aci_clientstatus	Query client access list.
aci_driveaccess	Change client drive status.
aci_drivestatus	Query client drive status (for compatibility only).
aci_drivestatus2	Query client drive status with additional information.
aci_drivestatus3	Query physical drive status.
aci_eject	Eject media from AML (for compatibility only).

**Table 2-2** Routines Available with Complete Service Access

<b>Routine</b>	<b>Explanation</b>
aci_eject2	Eject media from AML, and keep database entry for future insert requests.
aci_ejectclean	Eject clean media from AML, and remove database entry.
aci_eject2_complete	Eject media from AML, and remove database entry.
aci_flip	Turn Optical Disk on in the drive.
aci_force	Force a dismount request from a specified drive.
aci_foreign	Add or delete foreign media.
aci_getvolsertodrive	Get the volsers, which are allowed to be mounted to a specified drive. (Volsers are configured in the DAS config file)
aci_getvolsertoside	Get the second volser of the Optical Disk (OD has two volser).
aci_init	Initialize AML for client use.
aci_initialize	Initialize ACI library for client use.
aci_insert	Insert media into AML.
aci_insert2	Insert media into AML (also for clean-and scratch media).
aci_inventory	Start physical inventory with AMU database update.
aci_list	List outstanding and currently operating DAS requests.
aci_mount	Mount selected media in drive.
aci_partial_inventory	Start a physical inventory of subsystem in the AML
aci_qversion	Query version of DAS and ACI.
aci_qvolstrange	List client accessible and physically present volsers within requested range.
aci_register	Temporarily allow client access to DAS.

**Table 2-2** Routines Available with Complete Service Access

<b>Routine</b>	<b>Explanation</b>
aci_robhome	Set the AML-System to offline and move the robot to home position.
aci_robstat	Get Information about the AML-status and set the AML to on-line.
aci_scratch_get	Mount a scratch volume.
aci_scratch_info	Query scratch volume information.
aci_scratch_set	Add volume to scratch pool.
aci_scratch_unset	Remove volume from scratch pool.
aci_killamu	Shutdown AMU complete with OS/2.
aci_shutdown	Shut down DAS.
aci_switch	Switch between active and inactive AMU (DAS and AMS).
aci_unload	On an AML drive pressed one or more drive buttons (e.g. unload button).
aci_view	Query volume database entry.
aci_volseraccess	Set ownership of volser.
aci_volserstatus	Query ownership for volser.

## Media Types

The DAS ACI supports a variety of media types. The media type is passed as a parameter to all ACI functions that require media operations. Each media type name is a member of an enumerated type *aci\_media*, defined in the *aci.h* header file.

Table 2-3 lists the media types supported by DAS.

**Table 2-3** Supported Media Types

<b>ACI Media Name</b>	<b>Media Type</b>
ACI_3480	3480/3490 cartridges
ACI_3590	3590/8590 cartridges (NTP)
ACI_4MM	DDS or DAT (4mm tape)

**Table 2-3** Supported Media Types

ACI Media Name	Media Type
ACI_8MM	DDS 8mm tape (e.g. EXABYTE)
ACI_AUDIO_TAPE	standard audio tape cartridges
ACI_BETACAM	SONY BetaCAM cartridge
ACI_BETACAML	large BetaCAM cartridge
ACI_CD	CD-ROM (with CADDY)
ACI_D2	D2 (small and medium) tape cartridge
ACI_DECDLT	DLT (CompacTape) cartridge
ACI_DTF	SONY DTF cartridge
ACI_OD_THIN	Reflection optical disks
ACI_OD_THICK	512 MO/WORM optical disks
ACI_TRAVAN	TRAVAN cartridge
ACI_VHS	VHS cartridge
ACI_SONY_AIT	Sony AIT
ACI_LTO	LTO <sup>a</sup>

a. only IBM LTO media type is supported.

## DAS Error Codes

The DAS ACI functions return either a successful or failed return code. In case of failure, a DAS error code *d\_errno* is set describing the failure. The DAS error numbers are defined in the *derrno.h* header file, which is included by the *aci.h* header file. Refer to *Error Recovery Procedures* on page A-3.

# 3

## Safety

Overview .....	3-3
Hazard Alert Messages .....	3-3
Validity .....	3-5





## Overview

### Note

In addition to the safety instructions in this guide, local and professional safety rules apply.

Knowledge and observance of these instructions is imperative for the safe operation of the ADIC Storage Systems AML system.

Avoid danger when maintaining and operating the machine by

- behaving in a safety-conscious manner
- acting judiciously

## Hazard Alert Messages

ADIC classifies hazards in several categories. Table 3-1 shows the relationship of the symbols, signal words, actual hazards, and possible consequences.

**Table 3-1** Hazard Alert Message

Symbol	Damage to ...	Signal Word	Definition	Consequence
	Persons	<b>DANGER</b>	Imminent hazardous situation	Death or serious injury
		<b>WARNING</b>	Potential hazardous situation	Possible death or serious injury
		<b>CAUTION</b>	Less hazardous situation	Possible minor or moderate injury
	Persons		Imminent hazardous electrical situation	Death or serious injury
	Persons	<b>Caution</b>	Less hazardous situation	Possible minor or moderate injury
	Material	<b>Attention</b>	Potential damaging situation	Possible damage to the product or environment

**Table 3-1** Hazard Alert Message

Symbol	Damage to ...	Signal Word	Definition	Consequence
	Material	Static Sensitive	Potential electronic damaging situation	Possible damage to the product
		Note	Tips for operators	No hazardous or damaging consequences
			Important or useful information	No hazardous or damaging consequences

Specially emphasized paragraphs in this guide warn of danger or draw attention to important information. These paragraphs and their associated symbols include:



When used with the signal words, **Danger** or **Warning**, this symbol warns of a dangerous situation that threatens personnel with serious injury or death. When used with the signal word **Caution**, the symbol warns of a hazardous situation that could result in minor injury.



The danger exists of a fatal electric shock. At places designated with this symbol, electrical current can be present. Before starting any work, always confirm that all electrical connections are free of electrical current.



This symbol indicates the presence of a laser. Caution - use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.



This symbol means that specific regulations, rules, notices, and working procedures must be observed. Ignoring this symbol can lead to equipment damage or destruction or to other property damage.



This symbol indicates that the risk of equipment damage exist due to static discharge.



This symbol draws attention to user tips. No dangerous or damaging consequences for personnel or property are associated with this symbol.



This symbol indicates important or useful information. No dangerous or damaging consequences for personnel or property are associated with this symbol.

---

---



## Validity

These instructions are valid for ADIC Storage Systems AML systems.

Supplementary safety provisions for any components used on the machine are not invalidated by these instructions.



**Any other manufacturer's documentation forms part of the AML documentation.**



# 4

## DAS ACI Functions

Overview .....	4-5
aci_barcode .....	4-5
Return Values .....	4-6
aci_cancel .....	4-7
Return Values .....	4-8
aci_cleandrive .....	4-9
Return Values .....	4-9
aci_clientaccess .....	4-11
Return Values .....	4-12
aci_clientstatus .....	4-14
Return Values .....	4-15
aci_dismount .....	4-16
Return Values .....	4-17
aci_driveaccess .....	4-18
Return Values .....	4-20
aci_drivestatus .....	4-21
Return Values .....	4-22
aci_drivestatus2 .....	4-22
Return Values .....	4-25
aci_drivestatus3 .....	4-26
Return Values .....	4-29
aci_drivestatus4 .....	4-29
Return Values .....	4-31
aci_drivestatus_one .....	4-32
Return Values .....	4-33



---



---

aci_drivestatus2_one .....	4-34
Return Values .....	4-35
aci_drivestatus3_one .....	4-36
Return Values .....	4-37
aci_eif_conf .....	4-38
Return Values .....	4-39
aci_eject .....	4-39
Return Values .....	4-40
aci_eject2 .....	4-42
Return Values .....	4-43
aci_eject3 .....	4-46
Return Values .....	4-47
aci_eject_complete .....	4-49
Return Values .....	4-50
aci_eject2_complete .....	4-51
Return Values .....	4-53
aci_eject3_complete .....	4-54
Return Values .....	4-56
aci_ejectclean .....	4-57
Return Values .....	4-58
aci_email .....	4-60
Return Values .....	4-61
aci_flip .....	4-61
Return Values .....	4-62
aci_force .....	4-64
Return Values .....	4-64
aci_foreign .....	4-66
Return Values .....	4-67
aci_getvolserdrive .....	4-68
Return Values .....	4-69
aci_getVolserToSide .....	4-70
Return Values .....	4-71
aci_init .....	4-72
Return Values .....	4-73
aci_initialize .....	4-74
Return Values .....	4-74
aci_insert .....	4-75

---



---

Return Values .....	4-76
aci_insert2 .....	4-77
Return Values .....	4-79
aci_inventory .....	4-81
Return Values .....	4-81
aci_killamu .....	4-82
Return Values .....	4-83
aci_list .....	4-84
Return Values .....	4-86
aci_list2 .....	4-87
Return Values .....	4-89
aci_list_foreign .....	4-89
Return Values .....	4-90
aci_mount .....	4-91
Return Values .....	4-91
aci_partial_inventory .....	4-93
Return Values .....	4-95
aci_perror .....	4-96
aci_qversion .....	4-97
Return Values .....	4-97
aci_qvolsrange .....	4-98
Return Values .....	4-101
aci_register .....	4-103
Return Values .....	4-104
aci_robhome .....	4-106
Return Values .....	4-106
aci_robstat .....	4-107
Return Values .....	4-108
aci_scratch_get .....	4-109
Return Values .....	4-110
aci_scratch_info .....	4-111
Return Values .....	4-112
aci_scratch_set .....	4-114
Return Values .....	4-115
aci_scratch_unset .....	4-116
Return Values .....	4-117
aci_shutdown .....	4-118

---

---

Return Values .....	4-118
aci_snmp .....	4-119
Return Values .....	4-119
aci_switch .....	4-120
Return Values .....	4-121
aci_unload .....	4-122
Return Values .....	4-122
aci_view .....	4-123
Return Values .....	4-125
aci_volser_inventory .....	4-126
Return Values .....	4-127
aci_volseraccess .....	4-128
Return Values .....	4-128
aci_volserstatus .....	4-129
Return Values .....	4-130

---

---

## Overview

All ACI function calls and ACI structures are defined in the *aci.h* header file. ACI functions return 0 or -1 for successful and unsuccessful command execution respectively. A command failure sets the DAS error code variable *d\_errno* to the specific error code. In such case, a text error message may be written to standard error by calling *aci\_perror*, which accepts a user defined message string and attaches it to the DAS error message.

## aci\_barcode

The *aci\_barcode* function switches the barcode reader for the volsler on the robot on or off. See Figure 4-1.

```
#include "aci.h"
int aci_barcode(    char *cRobNum,
                   char *Action)
```

**Figure 4-1** aci\_barcode Function Call

See Table 4-1 for a description of the parameters for the *aci\_barcode* function call.

**Table 4-1** Parameters for the *aci\_barcode* Function Call

Parameter	Description	
cRobNum	defined the number of the robot (only on AML/2 systems with 2 robots)	
	1	robot 1 (AML/E, AML/J and robot 1 of AML/2)
	2	robot 2 of AML/2
Action	new condition for the following mount and eject commands from this host	
	OFF	barcode on the cartridge will not be checked
	ON	barcode on the cartridge will be checked on each command



The Scalar 1000 does not support the `aci_barcode` command (barcode on Scalar 1000 will never read on mount and eject).

Use this command to switch the barcode reading after the command `aci_mount`, `aci_cleandrive` or any `aci_eject` ended with failure and `derrno=EBARCODE`. After `aci_barcode` completed, try the previous command again.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EBADCLIENT
- EDASINT
- ETIMEOUT
- EAMUCOMM
- ESWITCHINPROG
- EDASINT
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD

Refer to Figure 4-2 on page 4-7 for an example of the `aci_barcode` function.

```

/* Switch the barcode reading off for robot 1 */
int rc = 0;
char *cRobNum = "1";
char *Action = "OFF";
rc = aci_barcode( cRobNum, Action );
if( rc )
{
    aci_perror( "Command failed: " );
}
else
{
    printf( "barcode reading switched off \n" );}

```

**Figure 4-2** Example of the aci\_barcode Function

## aci\_cancel

The aci\_cancel function cancels a specific DAS request. See Figure 4-3.

```

#include "aci.h"
int aci_cancel( unsigned long request_id )

```

**Figure 4-3** aci\_cancel Function Call

See Table 4-2 for a description of the parameter for the aci\_cancel function call.

**Table 4-2** Parameter for the aci\_cancel Function Call

Parameter	Description
request_id	DAS command sequence number, get information on the sequence number with the aci_list function

The aci\_cancel function cancels a previously issued and not completed client request. Before using this function, use the aci\_list function to get the *request\_id* in order to cancel the correct request.

---

---

The cancel request cancels the command in the DAS server and the AML. If the request is being acted upon in the AML, DAS attempts to cancel it, however this is unlikely to succeed. Once the robotics are in motion, the request may not be canceled. DAS reports that the cancel was successful while the canceled request completes.

For additional information, Refer to *aci\_list* on page 4-84.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable *d\_errno* is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOREQ
- EDASINT
- ERETRYL
- ECANCELED
- EDASINT
- ETIMEOUT
- ESWITCHINPROG
- EHCAPINUSE

See Figure 4-4 for an example of the *aci\_cancel* function.

```
/* Cancel first client request for a client */
int rc = 0;
char *pszthis_client = "clientname";
struct req_entry *prequest = NULL;
rc = aci_list( pszthis_client, prequest );
if( !rc )
{
    rc = aci_cancel( prequest[0].request_id );
    if( rc )
    {
        aci_perror( "Command failed:" );
    }
}
```

**Figure 4-4** Example of the *aci\_cancel* Function

---

---

## aci\_cleandrive

The aci\_cleandrive function mounts a cleaning cartridge to a specific drive. See Figure 4-5.

```
#include "aci.h"
int aci_cleandrive( char *drive)
```

**Figure 4-5** aci\_cleandrive Function Call

See Table 4-3 for a description of the parameter for the aci\_cleandrive function call.

**Table 4-3** Parameter for the aci\_cleandrive Function Call

Parameter	Description
drive	name of the drive to be cleaned



**Only clean the drives when they need to be cleaned.  
Unnecessary cleaning damages the drives.**

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable *d\_errno* is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- ENODRIVE
- EDRVOCUPPIED
- EPROBVOL
- EAMU
- EROBOTCOMM
- EDASINT
- EDEVEMPTY
- ENOTAUTH
- EBADCLIENT

- 
- 
- ERERTRYL
  - EINUSE
  - ECANCELLED
  - EDASINT
  - ECLEANING
  - ETIMEOUT
  - ESWITCHINPROG
  - EHICAPINUSE
  - EBARCODE
  - EINVALIDDEV
  - ENOROBOT
  - EDATABASE
  - ENOTSUPPHCMD
  - EAREAEMPTY
  - ENOPOOL
  - EPROBDEV
  - EBARCODE
  - EAREAFULL

---

---

## ■ aci\_clientaccess

The `aci_clientaccess` function modifies the access lists of a client. See Figure 4-6.

```
#include "aci.h"
int aci_clientaccess( char *clientname,
                    enum aci_command action,
                    char *volser_range,
                    enum aci_media type,
                    char *drive_range )
```

**Figure 4-6** aci\_clientaccess Function Call

See Table 4-4 for a description of the parameters for the `aci_clientaccess` function call.

**Table 4-4** Parameters for the `aci_clientaccess` Function Call

Parameter	Description	
clientname	name of the client which authorization is to be changed	
action	type of the activity (add or remove access rights)	
	ACI_ADD	add access rights
	ACI_DELETE	remove access rights
volser_range	<ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers, separated by commas</li><li>• a range of volsers separated by a hyphen</li><li>• set to empty (" " or '\0') if it is not to be changed</li></ul>	
type	media type of the previously defined volser range Refer to <i>Media Types</i> on page 2-7.	
drive_range	<ul style="list-style-type: none"><li>• a single drive</li><li>• multiple drives, separated by commas</li><li>• a range of drives separated by a hyphen, or set to empty (" " or '\0') if it is not to be changed</li></ul>	

This ACI function changes the access lists of a client named *clientname* by either adding or removing access to a *drive\_range* and/or a *volser\_range*. The `aci_clientstatus` function may be needed to find out the *drive\_range* and *volser\_range* used by the client.



The changes will be lost when the DAS software is shut down. Only use this command if, at the time, you do not have access to the *config* configuration file, or you cannot restart DAS. Otherwise, change the access privileges in the *config* file.

This ACI command allows the administrator to add new volume ranges or drive ranges to the AML system without shutting down the DAS server. The modifications created by using the *aci\_clientaccess* function are only valid while DAS is running. When DAS is shut down, all access modifications set by *aci\_clientaccess* are lost. When the DAS server is restarted, client access returns to the default settings in the DAS configuration file. To permanently register a client, the administrator must add the new *drive\_range* or *volser\_range* to the DAS configuration file.

For additional information, refer to *aci\_clientaccess* on page 4-11.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable *d\_errno* is set to one of the following DAS error codes:

- ERPC
- EINVAL
- EBADHOST
- ENOAUTH
- EBADCLIENT
- ENOSPACE
- ENOTFOUND
- ETIMEOUT
- ESWITCHINPROG

Refer to Figure 4-7 on page 4-13 for an example of the *aci\_clientaccess* function.

```

/* Add a volser range to a clients access list */
int rc = 0;
enum aci_command action = ACI_ADD; /*default action*/
char *client = "SomeClient";
char *volser = "AAB000 - AAB999";
char *drive = "";
enum aci_media type = ACI_3590;
if ((rc = aci_clientaccess ( client,
                            action,
                            volser,
                            type,
                            drive ) ))
{
    aci_perror( "Command failed: " );
}
else
{
    if (*volser)
    {
        printf ( "Volser range %s for client %s
added.\n",
                volser, client );
    }
    if (*drive)
    {
        printf ( "Drive range %s added for client
%s.\n",
                drive, client );
    }
}

```

**Figure 4-7** Example of the aci\_clientaccess Function

---

---

## aci\_clientstatus

The `aci_clientstatus` function queries client access list configuration. See Figure 4-8.

```
#include "aci.h"
int aci_clientstatus( char *clientname,
                    struct aci_client_entry *client )
```

**Figure 4-8** aci\_clientstatus Function Call

Query the current client access configuration status of a client named *clientname*. All configuration information is returned in the structure *aci\_client\_entry*. See Figure 4-9.

For additional information, refer to *aci\_clientaccess* on page 4-11.

```
struct aci_client_entry{
    char clientname[ACI_NAME_LEN];
    struct in_addr ip_addr;
    boolean avc;
    boolean complete_access;
    boolean dismount;
    char
    volser_range[ACI_MAX_RANGES][ACI_RANGE_LEN];
    char drive_range[ACI_RANGE_LEN];
};
```

**Figure 4-9** Returned Configuration Information

See Table 4-5 for a description of the parameters for the `aci_clientstatus` function call.

**Table 4-5** Parameters for the aci\_clientstatus Function Call

Parameter	Description	
clientname	name of the client which authorization is to be changed	
aci_client_entry	returned information to the requested client	
	clientname	requested client name
	in_addr	32-bit dotted decimal noted Internet Protocol (IP) address
	avc	(true or false) Parameter "avoid volume contention" defined the reaction during a mount of an already mounted cartridge
	complete_access	(true or false) Parameter authorized complete or basic command set (Refer to <i>Client Services</i> on page 2-4)
	dismount	(true or false) Parameter controls the automatic dismount if a next mount occur to an occupied drive
	volser_range	for the client configured volser range
	drive_range	for the client defined drives

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable *d\_errno* is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOTAUTH
- EUPELSE
- EBADCLIENT
- ETIMEOUT
- ESWITCHINPROG
- EDASINT

Refer to Figure 4-10 on page 4-16 for an example of the aci\_clientstatus function.

```

/* Query some clients access list configuration */
int rc = 0;
char *client = "SomeClient";
struct aci_client_entry client_entry;
rc = aci_clientstatus ( client, &client_entry );
if( rc )
{
    aci_perror( "Command failed: " );
}

```

**Figure 4-10** Example of the aci\_clientstatus Function

## aci\_dismount

The aci\_dismount function dismounts a volume. See Figure 4-11.

```

#include "aci.h"
int aci_dismount( char *volser,
                 enum aci_media type )

```

**Figure 4-11** aci\_dismount Function Call

Dismount the volume *volser* of defined media type from its drive. The drive is identified by the DAS software.

For additional information, Refer to *aci\_mount* on page 4-91.



**Retries can be configured in the config file or in the AMS configuration.**

See Table 4-6 for a description of the parameters for the aci\_dismount function call.

**Table 4-6** Parameters for the aci\_dismount Function Call

Parameter	Description
volser	volser that is to be moved from a drive to the original position in the AML
type	media type of the named volser Refer to <i>Media Types</i> on page 2-7

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable *d\_errno* is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- ENODRIVE
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- EDEVEMPTY
- ENOTAUTH
- EBADCLIENT
- ENOTMOUNTED
- ECANCELED
- EDASINT
- ENOMATCH
- ETIMEOUT
- ESWITCHINPROG
- EHICAPINUSE
- ECOORDINATE
- EBARCODE
- EINVALIDDEV
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY
- EPROBDEV
- EBARCODE
- EAREAFULL

Refer to Figure 4-12 on page 4-18 for an example of the *aci\_dismount* function.

```

/* Dismount volume from drive */
int rc = 0;
enum aci_media type = ACI_3590;
char *volser = "AAB001";
if (( rc = aci_dismount( volser, type ) ))
{
    aci_perror( "Dismount command failed: " );
}
else
{
    printf( "Dismount of %s successful.\n", volser
);
}

```

**Figure 4-12** Example of the aci\_dismount Function

## aci\_driveaccess

The aci\_driveaccess function modifies allocation status of a drive. See Figure 4-13.

```

#include "aci.h"
int aci_driveaccess( char *clientname,
                    char *drive,
                    enum aci_drive_status status );

```

**Figure 4-13** aci\_driveaccess Function Call

Modify allocation status of a drive for a specified client.

For additional information, Refer to *aci\_drivestatus* on page 4-21.

See Table 4-7 for a description of the parameters for the aci\_driveaccess function Call.

**Table 4-7** Parameters for the aci\_driveaccess Function Call

Parameter	Description	
clientname	client that has allocated the drive or wants to allocate the drive. Using SHARED_ACCESS as a key word for the client name when requesting a drive reservation causes that drive to be shared with other clients. All clients which are configured for that drive can access it.	
drive	one of the device names defined in the DAS configuration file for the specific client	
status	ACI_DRIVE_UP	normal reservation of the drive (other clients can change the reservation back with: ACI_DRIVE_DOWN, if the drive is empty)
	ACI_DRIVE_DOWN	deleted reservation normal (only possible with an empty drive)
	ACI_DRIVE_FUP	force drive allocation (also possible, if the drive is occupied)
	ACI_DRIVE_FDOWN	force delete drive allocation (also possible, if the drive is occupied)
	ACI_DRIVE_EXUP	exclusive reservation of a drive, can only be changed from the client self or the client named DAS-SUPERVISOR
	ACI_DRIVE_DOWN	deleted reservation normal (only possible with an empty drive)



**The drive can only be put in the DOWN status by ACI\_DRIVE\_FDOWN if the drive is occupied.**

A drive may only be available to a single client at a time. The drive status is defined to be either *UP* (active) or *DOWN* (inactive) to requesting clients. When the client sets the status to ACI\_UP, it is exclusively available to that client. If another client already has the drive status set to ACI\_UP, the request is returned with the *d\_errno* set to EUPELSE. If the client indicates a status of ACI\_DOWN, the drive is unavailable to the client requesting drive access.

A drive must be empty to modify the drive access parameter to ACI\_DOWN.

---

---

## Return Values

The `aci_driveaccess` returns the following values:

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENODRIVE
- EDRVOCCUPIED
- ENOHAUTH
- EUPELSE
- EBADCLIENT
- ENOAUTH
- ETIMEOUT
- ESWITCHINPROG
- EEXUP
- EDASINT

See Figure 4-14 for an example of the `aci_driveaccess` function.

```
/* Allocate a drive for client use */
int rc = 0;
char *client = "SomeClient";
char *drive = "Drive1";
enum aci_drive_status status;
status = ACI_DRIVE_UP;
if ( ( rc = aci_driveaccess( client, drive, status ) ) )
{
    aci_perror( "Drive allocation failed: " );
}
else
{
    printf( "Allocation of %s for %s successful\n",
           drive, client );
}
```

**Figure 4-14** Example of the `aci_driveaccess` Function

---

---

## aci\_drivestatus

The `aci_drivestatus` function queries status of up to 15 drives. See Figure 4-15.

```
#include "aci.h"
int aci_drivestatus( char *clientname,
                    struct aci_drive_entry
                    *pstDriveEntry[ACI_MAX_DRIVE_ENTRIES] )
```

**Figure 4-15** aci\_drivestatus Function Call

Return the status of drives which are set to *UP* (active) for the client with name `clientname`. If `clientname` is the NULL string, return status on all drives. The status is returned in `drive_entry`, an array of pointers to `aci_drive_entry` structures. See Figure 4-16.

For additional information, refer to `aci_driveaccess` on page 4-18, and `aci_drivestatus` on page 4-21.

```
struct aci_drive_entry {
    char drive_name[ACI_DRIVE_LEN];
    char amu_drive_name[ACI_AMU_DRIVE_LEN];
    enum aci_drive_status drive_state;
    char type;
    char system_id[ACI_NAME_LEN];
    char clientname[ACI_NAME_LEN];
    char volser [ACI_VOLSER_LEN];
    bool_t cleaning;
    short clean_count;
};
```

**Figure 4-16** Returned Status

For an explanation of the `aci_drive_entry` function, refer to `aci_drivestatus` on page 4-21



**The maximum number of drives displayed is 15.**

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROG
- EBADCLIENT

## aci\_drivestatus2

The `aci_drivestatus2` function queries status of up to 250 drives. See Figure 4-17.

```
#include "aci.h"
int aci_drivestatus2( char *clientname,
struct aci_drive_entry *pstDriveEntry[ACI_MAX_DRIVE_ENTRIES2] )
```

**Figure 4-17** aci\_drivestatus2 Function Call

Return the status of drives which are set to UP (active) for the client with name *clientname*. The status is returned in *drive\_entry*, an array of pointers to `aci_drive_entry` structures. See Figure 4-18 on page 4-23.

For additional information, Refer to *aci\_driveaccess* on page 4-18.

```

struct aci_drive_entry {
    char drive_name[ACI_DRIVE_LEN];
    char amu_drive_name[ACI_AMU_DRIVE_LEN];
    enum aci_drive_status drive_state;
    char type;
    char system_id[ACI_NAME_LEN];
    char clientname[ACI_NAME_LEN];
    char volser [ACI_VOLSER_LEN];
    bool_t cleaning;
    short clean_count;
};

```

**Figure 4-18** Returned Status

See Table 4-8 for a description of the parameters for the `aci_drivestatus2` function call.

**Table 4-8** Parameters for the `aci_drivestatus2` Function Call

Parameter	Description
clientname	name of the client that requested the status of the drives. If <i>clientname</i> is the NULL string, return status on all drives. Using SHARED_ACCESS as a key word for the client shows all drives which are allocated in the SHARED_ACCESS mode. Using EXUP as a key word for the clientname shows all drives which are allocated in the EXUP mode.

**Table 4-8** Parameters for the aci\_drivestatus2 Function Call

Parameter	Description	
aci_drive_entry	returned information about the status of the drives	
	drive_name	name of the drive (name used in DAS and AMS description)
	amu_drive_name	internal AMS drive name e.g. 03 or ZZ
	drive_state	UP or DOWN reservation of the drive Refer to <i>aci_driveaccess</i> on page 4-18
	type	type of the drive (internal AMS code, e.g. E for DLT drive) (See the <i>AMU Reference Guide</i> )
	system_id	empty, reserved for further use
	clientname	name of the client that the drive is presently allocated to
	volser	Volser, if the drive is currently occupied
	cleaning	true if the drive is presently occupied with a medium for cleaning
	clean_count	number of mounts until the next clean activity



The maximum number of drives displayed is 250.

---

---



## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable *d\_errno* is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROG
- EBADCLIENT

Refer to Figure 4-19 on page 4-26 for an example of the `aci_drivestatus2` function.

```

/* Get drive status information for some client */
int rc = 0;
int i = 0;
char *client = "SomeClient";
struct aci_drive_entry
*drive_entry[ACI_MAX_DRIVE_ENTRIES2];
if      (( rc = aci_drivestatus2( client, drive_entry
) ))
{
    aci_perror( "listd failed" );
}
else
{
    printf("Drive status request for client:
           %s successful\n",client );
for (i = 0; i < ACI_MAX_DRIVE_ENTRIES2; i++)
    {
    if ( *drive_entry[i]->drive_name == '\0' )
        break;
    printf( "drive:%s amu drive:%s st:%s type:%c"
           "sysid:%s client:%s volser:%s cleaning:%d"
           "clean_count: %d\n",
           drive_entry[i]->drive_name,
           drive_entry[i]->amu_drive_name,
           drive_entry[i]->drive_state ==
               ACI_DRIVE_UP ? "UP" : "DOWN",
           drive_entry[i]->type,
           drive_entry[i]->system_id,
           drive_entry[i]->clientname,
           drive_entry[i]->volser,
           drive_entry[i]->cleaning,
           drive_entry[i]->clean_count );
    }
}
}

```

**Figure 4-19** Example of the aci\_drivestatus2 Function

## aci\_drivestatus3

The aci\_drivestatus3 function queries the physical status of up to 250 drives. See Figure 4-20.

```

#include "aci.h"
init aci_drivestatus3 ( char *clientname,
                      struct aci_ext_drive_entry *pstDriveEntry[] )

```

**Figure 4-20** aci\_drivestatus3 Function Call

Return the status of drives which are set to UP for the client with the name *clientname*. If *clientname* is the NULL string, the call returns status on all drives. The status is returned in an array of pointers to *aci\_ext\_drive\_entry* structure. The array element can be maximal 250. See Figure 4-21.

```

struct aci_ext_drive_entry {
    char drive_name[ACI_DRIVE_LEN];
    char amu_drive_name[ACI_AMU_DRIVE_LEN];
    enum aci_drive_status drive_state;
    char type;
    char system_id[ACI_NAME_LEN];
    char volser[ACI_VOLSER_LEN];
    bool_t cleaning;
    short clean_count;
    int mount;
    int keep;
};

```

**Figure 4-21** Returned Status

See Table 4-9 for an explanation of the parameters used for the *aci\_drivestatus3* function.

**Table 4-9** Parameters for the *aci\_drivestatus3* Function Call

Parameter	Description
clientname	name of the client that requested the status of the drives. If <i>clientname</i> is the NULL string, return status on all drives. Using SHARED_ACCESS as a key word for the client shows all drives which are allocated in the SHARED_ACCESS mode. Using EXUP as a key word for the clientname shows all drives which are allocated in the EXUP mode.

**Table 4-9** Parameters for the aci\_drivestatus3 Function Call

Parameter	Description	
aci_drive_entry	returned information about the status of the drives	
	drive_name	name of the drive (name used in DAS and AMS description)
	amu_drive_name	internal AMS drive name e.g. 03 or ZZ
	drive_state	UP or DOWN reservation of the drive Refer to <i>aci_driveaccess</i> on page 4-18
	type	type of the drive (internal AMS code, e.g. E for DLT drive) (See the <i>AMU Reference Guide</i> )
	system_id	empty, reserved for further use
	clientname	name of the client that the drive is presently allocated to
	volser	Volser, if the drive is currently occupied
	mount	<ul style="list-style-type: none"><li>• drive logically occupied but the mount is physically not finished (mount=1, keep=0)</li><li>• drive logically occupied and mount is physically finished (mount=0, keep=0)</li></ul>
	keep	<ul style="list-style-type: none"><li>• drive logically empty but the keep is physically not finished (mount=0, keep=1)</li><li>• drive logically empty and the keep is physically finished (mount=0, keep=0)</li></ul>
	cleaning	true if the drive is presently occupied with a medium for cleaning
	clean_count	number of mounts until the next clean activity

---

---

## Return Values

- 0: The call was successful
- -1: The call has failed

The external variable *d\_errno* is set to one of the following DAS error codes:

- EBADCLIENT
- ERPC
- EINVAL
- EDASINT
- ETIMEOUT
- ESWITCHINPROGRESS
- EDASINT

## aci\_drivestatus4

The *aci\_drivestatus4* function queries the physical status of up to 380 drives. See Figure 4-22.

```
#include "aci.h"
init aci_drivestatus4 ( char *clientname,
                      char *drive
                      struct aci_ext_drive_entry4 *pstDriveEntry[ACI_MAX_DRIV_ENTRIES4] )
```

**Figure 4-22** aci\_drivestatus4 Function Call

Return the status of drives which are set to UP for the client with the name *clientname*. If *clientname* is the NULL string, the call returns status on all drives. If a value for the drive field is indicated, the information relates to that single drive. The status is returned in an array of pointers to the *aci\_ext\_drive\_entry* structure. The array element can be maximal 380. See Figure 4-23.

The variable *ACI\_MAX\_DRIVE\_ENTRIES4* is equal to 380.

```

struct aci_ext_drive_entry4 {
    char drive_name[ACI_DRIVE_LEN];
    char amu_drive_name[ACI_AMU_DRIVE_LEN];
    enum aci_drive_status drive_state;
    char type;
    char system_id[ACI_NAME_LEN];
    char clientname[ACI_NAME_LEN];
    char volser[ACI_VOLSER_LEN];
    bool_t cleaning;
    short clean_count;
    int mount;
    int keep;
    char serial_number[ACI_SERIAL_NUMBER_LEN];
};

```

**Figure 4-23** Returned Status

The variable ACI\_SERIAL\_NUMBER\_LEN is equal to 51.

See Table 4-10 for an explanation of the parameters used for the aci\_drivestatus4 function.

**Table 4-10** Parameters for the aci\_drivestatus4 Function Call

Parameter	Description	
clientname	name of the client that requested the status of the drives. If <i>clientname</i> is the NULL string, return status on all drives. Using SHARED_ACCESS as a key word for the client shows all drives which are allocated in the SHARED_ACCESS mode. Using EXUP as a key word for the clientname shows all drives which are allocated in the EXUP mode.	
drive	value associated with a single drive	
aci_drive_entry	returned information about the status of the drives	
	drive_name	name of the drive (name used in DAS and AMS description)
	amu_drive_name	internal AMS drive name e.g. 03 or ZZ

**Table 4-10** Parameters for the `aci_drivestatus4` Function Call

Parameter	Description	
	drive_state	UP or DOWN reservation of the drive Refer to <i>aci_driveaccess</i> on page 4-18
	type	type of the drive (internal AMS code, e.g. E for DLT drive) (See the <i>AMU Reference Guide</i> )
	system_id	empty, reserved for further use
	clientname	name of the client that the drive is presently allocated to
	volser	Volser, if the drive is currently occupied
	cleaning	true if the drive is presently occupied with a medium for cleaning
	clean_count	number of mounts until the next clean activity
	mount	<ul style="list-style-type: none"><li>• drive logically occupied but the mount is physically not finished (mount=1, keep=0)</li><li>• drive logically occupied and mount is physically finished (mount=0, keep=0)</li></ul>
	keep	<ul style="list-style-type: none"><li>• drive logically empty but the keep is physically not finished (mount=0, keep=1)</li><li>• drive logically empty and the keep is physically finished (mount=0, keep=0)</li></ul>
	serial_number	the serial number of the selected drive

## Return Values

- 0: The call was successful
- -1: The call has failed

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROGRESS
- EBADCLIENT
- ENOTSUPPHCMD

## aci\_drivestatus\_one

The `aci_drivestatus_one` function queries the physical status of up to 15 drives. See Figure 4-24.

```
#include "aci.h"
init aci_drivestatus_one ( char *clientname,
                          char *drive
                          struct aci_drive_entry *pstDriveEntry[ACI_MAX_DRIVE_ENTRIES] )
```

**Figure 4-24** aci\_drivestatus\_one Function Call

Return the status of drives which are set to UP for the client with the name `clientname`. If `clientname` is the NULL string, the call returns status on all drives. If a value for the drive field is indicated, the information relates to that single drive. The status is returned in an array of pointers to `aci_drive_entry` structure. The array element can be maximal 15. See Figure 4-25.

The value of `ACI_MAX_DRIVES_ENTRIES` is equal to 15.

```
struct aci_drive_entry {
    char drive_name[ACI_DRIVE_LEN];
    char amu_drive_name[ACI_AMU_DRIVE_LEN];
    enum aci_drive_status drive_state;
    char type;
    char system_id[ACI_NAME_LEN];
    char clientname
    char volser[ACI_VOLSER_LEN];
    bool_t cleaning
    short clean_count
};
```

**Figure 4-25** Returned Status

See Table 4-11 for an explanation of the parameters used for the `aci_drivestatus_one` function.

**Table 4-11** Parameters for the `aci_drivestatus_one` Function Call

Parameter	Description
<code>clientname</code>	name of the client that requested the status of the drives. If <code>clientname</code> is the NULL string, return status on all drives.
<code>aci_drive_entry</code>	returned information about the status of the drives
<code>drive_name</code>	name of the drive (name used in DAS and AMS description)
<code>amu_drive_name</code>	internal AMS drive name e.g. 03 or ZZ
<code>drive_state</code>	UP or DOWN reservation of the drive Refer to <i>aci_driveaccess</i> on page 4-18
<code>type</code>	type of the drive (internal AMS code, e.g. E for DLT drive) (See the <i>AMU Reference Guide</i> )
<code>system_id</code>	empty, reserved for further use
<code>clientname</code>	name of the client that the drive is presently allocated to
<code>volser</code>	Volser, if the drive is currently occupied
<code>cleaning</code>	true if the drive is presently occupied with a medium for cleaning
<code>clean_count</code>	number of mounts until the next clean activity

## Return Values

- 0: The call was successful
- -1: The call has failed

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROGRESS
- EBADCLIENT
- ENOTSUPPHCMD

## aci\_drivestatus2\_one

The `aci_drivestatus2_one` function queries the physical status of up to 250 drives. See Figure 4-26.

```
#include "aci.h"
init aci_drivestatus2_one ( char *clientname,
                           char *drive
                           struct aci_drive_entry *pstDriveEntry[ACI_MAX_DRIVE_ENTRIES2] )
```

**Figure 4-26** aci\_drivestatus\_2\_one Function Call

Return the status of drives which are set to UP for the client with the name `clientname`. If `clientname` is the NULL string, the call returns status on all drives. If a value for the drive field is indicated, the information relates to that single drive. The status is returned in an array of pointers to `aci_drive_entry` structure. The array element can be maximal 250. See Figure 4-27.

The value of `ACI_MAX_DRIVES_ENTRIES2` is equal to 250.

```
struct aci_drive_entry {
    char drive_name[ACI_DRIVE_LEN];
    char amu_drive_name[ACI_AMU_DRIVE_LEN];
    enum aci_drive_status drive_state;
    char type;
    char system_id[ACI_NAME_LEN];
    char clientname
    char volser[ACI_VOLSER_LEN];
    bool_t cleaning
    short clean_count
};
```

**Figure 4-27** Returned Status

See Table 4-12 for an explanation of the parameters used for the `aci_drivestatus2_one` function.

**Table 4-12** Parameters for the `aci_drivestatus2_one` Function Call

Parameter	Description
<code>clientname</code>	name of the client that requested the status of the drives. If <code>clientname</code> is the NULL string, return status on all drives.
<code>aci_drive_entry</code>	returned information about the status of the drives
<code>drive_name</code>	name of the drive (name used in DAS and AMS description)
<code>amu_drive_name</code>	internal AMS drive name e.g. 03 or ZZ
<code>drive_state</code>	UP or DOWN reservation of the drive Refer to <i>aci_driveaccess</i> on page 4-18
<code>type</code>	type of the drive (internal AMS code, e.g. E for DLT drive) (See the <i>AMU Reference Guide</i> )
<code>system_id</code>	empty, reserved for further use
<code>clientname</code>	name of the client that the drive is presently allocated to
<code>volser</code>	Volser, if the drive is currently occupied
<code>cleaning</code>	true if the drive is presently occupied with a medium for cleaning
<code>clean_count</code>	number of mounts until the next clean activity

## Return Values

- 0: The call was successful
- -1: The call has failed

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROGRESS
- EBADCLIENT
- ENOTSUPPHCMD

## aci\_drivestatus3\_one

The `aci_drivestatus3_one` function queries the physical status of up to 250 drives. See Figure 4-28.

```
#include "aci.h"
init aci_drivestatus3_one ( char *clientname,
                           char *drive
                           struct aci_drive_entry *pstDriveEntry[ACI_MAX_DRIVE_ENTRIES2] )
```

**Figure 4-28** aci\_drivestatus\_3\_one Function Call

Return the status of drives which are set to UP for the client with the name `clientname`. If `clientname` is the NULL string, the call returns status on all drives. If a value for the drive field is indicated, the information relates to that single drive. The status is returned in an array of pointers to `aci_drive_entry` structure. The array element can be maximal 250. See Figure 4-29.

The value of `ACI_MAX_DRIVES_ENTRIES2` is equal to 250.

```
struct aci_drive_entry {
    char drive_name[ACI_DRIVE_LEN];
    char amu_drive_name[ACI_AMU_DRIVE_LEN];
    enum aci_drive_status drive_state;
    char type;
    char system_id[ACI_NAME_LEN];
    char clientname
    char volser[ACI_VOLSER_LEN];
    bool_t cleaning
    short clean_count
};
```

**Figure 4-29** Returned Status

See Table 4-13 for an explanation of the parameters used for the `aci_drivestatus3_one` function.

**Table 4-13** Parameters for the `aci_drivestatus3_one` Function Call

Parameter	Description	
<code>clientname</code>	name of the client that requested the status of the drives. If <code>clientname</code> is the NULL string, return status on all drives.	
<code>aci_drive_entry</code>	returned information about the status of the drives	
	<code>drive_name</code>	name of the drive (name used in DAS and AMS description)
	<code>amu_drive_name</code>	internal AMS drive name e.g. 03 or ZZ
	<code>drive_state</code>	UP or DOWN reservation of the drive Refer to <i>aci_driveaccess</i> on page 4-18
	<code>type</code>	type of the drive (internal AMS code, e.g. E for DLT drive) (See the <i>AMU Reference Guide</i> )
	<code>system_id</code>	empty, reserved for further use
	<code>clientname</code>	name of the client that the drive is presently allocated to
	<code>volser</code>	Volser, if the drive is currently occupied
	<code>cleaning</code>	true if the drive is presently occupied with a medium for cleaning
	<code>clean_count</code>	number of mounts until the next clean activity

## Return Values

- 0: The call was successful
- -1: The call has failed

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROGRESS
- EBADCLIENT
- ENOTSUPPHCMD

## aci\_eif\_conf

The `aci_eif_conf` function queries status from up to 20 logical ranges. See Figure 4-30.

```
#include "aci.h"
int aci_eif_conf( struct aci_lora *lora_desc,
                 int *nCount)
```

**Figure 4-30** aci\_eif\_conf Function Call

The call returns `nCount` and the status of the logical range. The status is returned in an array of pointers to the `aci_lora` structure. The array can be a maximum of 20 elements. See Figure 4-31.

```
struct aci_lora {
    char lora_name[ACI_AREANAME_LEN];
    char StartCoord[ACI_COORD_LEN];
    char EndCoord[ACI_COORD_LEN];
    char ctype
    char description[ACI_DESCRIPTION_LEN];
};
```

**Figure 4-31** Returned Status

For the parameters of the `aci_lora` structure, refer to Table 4-14 on page 4-39.

**Table 4-14** Parameters for the aci\_eif\_conf Function Call

Parameter	Description	
aci_lorta	structure used to describe the import/export area and addressing	
	lora_name	the name of the import/export area
	StartCoord	the starting coordinates of the area
	EndCoord	the ending coordinates of the area
	ctype	the cartridge type associated with the area
	description	a description of the import.export area
nCount	the number of returned status (maximum of 300)	

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROG
- EBADCLIENT
- ENOTSUPPHCMD

## aci\_eject

The `aci_eject` function ejects a range of volumes from the AML. See Figure 4-32.

```
#include "aci.h"
int aci_eject( char *eject_area,
              char *volser_range,
              enum aci_media type )
```

**Figure 4-32** aci\_eject Function Call

Eject the volumes in *volser\_range* to the *eject\_area*. The media type of the volumes must match that of the *eject\_area*. Set *type* to the media type of the *volser\_range*. See Table 4-15.

**Table 4-15** Parameters for the *aci\_eject* Function Call

Parameter	Description
clientname	Using SHARED_ACCESS as a key word for the client shows all drives which are allocated in the SHARED_ACCESS mode. Using EXUP as a key word for the clientname shows all drives which are allocated in the EXUP mode.
eject_area	Logical area defined in AML, where the cartridges should be ejected
volser_ranges	<ul style="list-style-type: none"> <li>• a single volser</li> <li>• multiple volsers separated by commas</li> <li>• a range of volsers separated by a hyphen</li> </ul>
types	media type of the named volser Refer to <i>Media Types</i> on page 2-7

The database entry for the volume is not deleted, and the position in the AML that the volume occupied remains reserved for insertion of a volume with a matching volser. This could be useful if the volume is temporarily ejected and will be inserted in the near future. In such case, the position remains reserved and the volume's location within the AML does not change.

The eject will stop, when the eject area is full. The request will either be cancelled or completed after the area is marked empty depending on the `DAS_EJECTAREAFULL` environment variable.

For additional information, refer to *aci\_eject2* on page 4-42, and *aci\_eject\_complete* on page 4-49.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL

- 
- 
- ENOVOLUME
  - EPROBVOL
  - EAMU
  - EAMUCOMM
  - EROBOTCOMM
  - EDASINT
  - ENOAREA
  - ENOTAUTH
  - EBADCLIENT
  - ERETRYL
  - EINUSE
  - ECANCELED
  - EDASINT
  - ENOMATCH
  - ETIMEOUT
  - ESWITCHINPROG
  - EHICAPINUSE
  - ECOORDINATE
  - EBARCODE
  - EINVALIDDEV
  - ENOROBOT
  - EDATABASE
  - ENOTSUPPHCMD
  - EAREAEMPTY
  - EBARCODE
  - EAREAFULL

Refer to Figure 4-33 for an example of the `aci_eject` function.

```
int rc = 0;
rc = aci_eject( "E01", "AAB001", ACI_3590 );
if( rc )
{
    aci_perror( "Command failed: " );
}
else
{
    printf( "Volser AAB001 ejected to E01 \n" );
}
```

**Figure 4-33** Example of the `aci_eject` Function

---

---

## aci\_eject2

The aci\_eject2 function ejects a range of volumes from the AML. See Figure 4-34.

```
#include "aci.h"
int aci_eject2( char *eject_area,
               char *volser_range,
               enum aci_media type,
               int *pnActualCount,
               struct aci_ei_info *psteiInfo)
```

**Figure 4-34** aci\_eject2 Function Call

For the structure of the aci\_ei\_info function, refer to Figure 4-35.

```
struct aci_ei_info {
    char volser[ACI_VOLSER_LEN];
    char media_type[ACI_DRIVE_LEN];
    int errcode
};
```

**Figure 4-35** Structure of the aci\_ei\_info function from aci.h

See Table 4-16 for a description of the parameters for the aci\_eject2 function call.

**Table 4-16** Parameters for the aci\_eject2 Function Call

Parameter	Description
eject_area	logical area defined in the AMS, where the cartridges should be ejected
volser_range	<ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers separated by commas</li><li>• a range of volsers separated by a hyphen</li><li>• set to empty (" " or '\0') if it is not to be changed</li></ul>
type	media type of the named volser range Refer to <i>Media Types</i> on page 2-7
pnActualCount	returned number of ejected volsers

**Table 4-16** Parameters for the aci\_eject2 Function Call

Parameter	Description	
aci_ei_info	returned information on each volser ejected	
	volser	volser of the ejected volume
	type	media type of the named volser Refer to <i>Media Types</i> on page 2-7
	errcodes	error code derrno

If the eject area is full, the system stops the eject procedure. Depending on the DAS\_EJECTAREAFULL environment variable on the AMU, the command will be canceled, or the system starts with the next eject after the operator has removed cartridges from the eject area.

The Attribute of the Coordinate will be set to *ejected* in the AMU database. The compartment is now reserved for this volser, if the compartment needs to be used for other volsers, issue the aci\_eject\_complete2 function.

Use the eject stop, when the eject area is full. Depending on the DAS\_EJECTAREAFULL environment variable, the request will either be cancelled or completed after the area is marked empty.

For additional information, refer to *aci\_insert* on page 4-75, and *aci\_eject\_complete* on page 4-49.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable d\_errno is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ENOAREA

- 
- 
- ENOTAUTH
  - EBADCLIENT
  - ERETRYL
  - EINUSE
  - ECANCELED
  - EDASINT
  - ENOMATCH
  - ETIMEOUT
  - ESWITCHINPROG
  - EHCAPINUSE
  - ECOORDINATE
  - EBARCODE
  - EINVALIDDEV
  - ENOROBOT
  - EDATABASE
  - ENOTSUPPHCMD
  - EAREAEMPTY
  - EBARCODE
  - EAREAFULL

See Figure 4-36 for an example of the aci\_eject2 function.

```

/* Eject volume but reserve archive location */
int rc, i, pnActualCount;
char *volser_range = "000815 - 004711";
char *eject_area = "E02"
struct aci_ei_info ei_info[ACI_EI_MAX_RANGE];
rc = aci_eject2( eject_area, volser_range, ACI_3590
&pnActualCount, &ei_info );
if( rc )
{
    aci_perror( "Command failed: " );
}
else
{
    printf("Volume ejects request successful\n" );
for (i = 0; i < ACI_EI_MAX_RANGE; i++)
    {
        if ( *ei_info[i]->volser == '\0' )
            break;
        printf( "volser:%s media type:%s Error:%d\n",
            ei_info[i]->volser,
            ei_info[i]->media_type,
            ei_info[i]->errcode );
    }
}

```

**Figure 4-36** Example of the aci\_eject2 Function

---

---

## aci\_eject3

The aci\_eject3 function ejects a range of volumes from the AML. See Figure 4-37.

```
#include "aci.h"
int aci_eject3( char *eject_area,
               char *volser_range,
               enum aci_media type,
               int *pnActualCount,
               struct aci_ei_info *psteiInfo)
```

**Figure 4-37** aci\_eject3 Function Call

The volser\_range field has a maximum size of 512 bytes.

For the structure of the aci\_ei\_info function, refer to Figure 4-38.

```
struct aci_ei_info {
    char volser[ACI_VOLSER_LEN];
    char media_type[ACI_DRIVE_LEN];
    int errcode
};
```

**Figure 4-38** Structure of the aci\_ei\_info function

See Table 4-17 for a description of the parameters for the aci\_eject2 function call.

**Table 4-17** Parameters for the aci\_eject3 Function Call

Parameter	Description
eject_area	logical area defined in the AMS, where the cartridges should be ejected
volser_range	<ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers separated by commas</li><li>• a range of volsers separated by a hyphen</li><li>• set to empty (" " or '\0') if it is not to be changed</li></ul>
type	media type of the named volser range Refer to <i>Media Types</i> on page 2-7

**Table 4-17** Parameters for the `aci_eject3` Function Call

Parameter	Description	
<code>pnActualCount</code>	returned number of ejected volsers	
<code>aci_ei_info</code>	returned information on each volsers ejected	
	<code>volsers</code>	volsers of the ejected volume
	<code>type</code>	media type of the named volsers Refer to <i>Media Types</i> on page 2-7
	<code>errcodes</code>	error code <code>derrno</code>

If the eject area is full, the system stops the eject procedure. Depending on the `DAS_EJECTAREAFULL` environment variable on the AMU, the command will be canceled, or the system starts with the next eject after the operator has removed cartridges from the eject area.

The `Attribute` of the `Coordinate` will be set to *ejected* in the AMU database. The compartment is now reserved for this volsers, if the compartment needs to be used for other volsers, issue the `aci_eject_complete2` function.

Use the eject stop, when the eject area is full. Depending on the `DAS_EJECTAREAFULL` environment variable, the request will either be cancelled or completed after the area is marked empty.

For additional information, refer to *aci\_insert* on page 4-75, and *aci\_eject\_complete* on page 4-49.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- `ERPC`
- `EINVALID`
- `ENOVOLUME`
- `EPROBVOL`
- `EAMU`
- `EAMUCOMM`
- `EROBOTCOMM`
- `EDASINT`

- 
- 
- ENOAREA
  - ENOTAUTH
  - EBADCLIENT
  - ERETRYL
  - EINUSE
  - ECANCELED
  - ENOMATCH
  - ETIMEOUT
  - ESWITCHINPROG
  - EHCAPINUSE
  - ECOORDINATE
  - EBARCODE
  - EINVALIDDEV
  - ENOROBOT
  - EDATABASE
  - ENOTSUPPHCMD
  - EAREAEMPTY
  - EBARCODE
  - EAREAFULL

---

---

## aci\_eject\_complete

The `aci_eject_complete` function ejects volumes and removes the database entries. See Figure 4-39.

```
#include "aci.h"
int aci_eject_complete( char *eject_area,
                      char *volser_range,
                      enum aci_media type)
```

**Figure 4-39** aci\_eject\_complete function call

Eject the volumes in *volser\_range* to the *eject\_area*. The media type of the volumes must match that of the *eject\_area*. Set *type* to the media type of the *volser\_range*. The database entry for the volume is deleted, and the position in the AML that the volume occupied becomes free. This could be useful if the volume is to be placed in long-term archive storage or more space is needed in the AML. If the volume is re-inserted into the AML, it is stored in the next available position, and it probably will not occupy the previous position. The volume is re-inserted in the same position only if `aci_eject` is used. See Table 4-18 for a description of the parameters for the `aci_eject_complete` function call.

**Table 4-18** Parameters for the `aci_eject_complete` Function Call

Parameter	Description
<code>eject_area</code>	Logical area defined in AMS, where the cartridges should be ejected
<code>volser_range</code>	<ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers separated by commas</li><li>• a range of volsers separated by a hyphen</li></ul>
<code>types</code>	media types of the named volser Refer to <i>Media Types</i> on page 2-7

The eject will stop, when the eject area is full. Depending on the `DAS_EJECTAREAFULL` environment variable, the request will either be cancelled or completed after the area is marked empty.

For additional information, refer to *aci\_eject* on page 4-39, and *aci\_insert* on page 4-75.

---

---



## Return Values

- 0: The call was successful.
- -1: The call failed.

The *external* variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVALID
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ENOAREA
- ENOTAUTH
- EBADCLIENT
- ERETRYL
- EINUSE
- ECANCELED
- EDASINT
- ENOMATCH
- ETIMEOUT
- ESWITCHINPROG
- EHCAPINUSE
- ECOORDINATE
- EBARCODE
- EINVALIDDEV
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY
- EBARCODE
- EAREAFULL

Refer to Figure 4-40 on page 4-51 for an example of the `aci_eject_complete` function.

```

/* Eject volume from archive and free storage position.
*/
int rc = 0;
rc = aci_eject_complete("E01", "AAB001", ACI_3590 );
if( rc )
{
    aci_perror( "Command failed:" );
}
else
{
    printf( "Volser AAB001 ejected to E01 \n" );
}

```

**Figure 4-40** Example of the `aci_eject_complete` Function

## ■ `aci_eject2_complete`

The `aci_eject2_complete` function ejects a range of volumes from the AML, and deletes the home coordinate. See Figure 4-41.

```

#include "aci.h"
int aci_eject2_complete( char *eject_area,
                        char *volser_range,
                        enum aci_media type,
                        int *pnActualCount,
                        struct aci_ei_info *psteiInfo)

```

**Figure 4-41** `aci_eject2_complete` Function Call

See Figure 4-42 for the structure of the `aci_ei_info` function.

```

struct aci_ei_info {
    char volser[ACI_VOLSER_LEN];
    char media_type[ACI_DRIVE_LEN];
    int errcode
};

```

**Figure 4-42** Structure of the `aci_ei_info` function

See Table 4-19 for a description of the parameters for the aci\_eject2\_complete function call.

**Table 4-19** Parameters for the aci\_eject2\_complete Function Call

Parameter	Description	
eject_area	logical area defined in AML, where the cartridges should be ejected	
volser_range	<ul style="list-style-type: none"> <li>• a single volser</li> <li>• multiple volsers separated by commas</li> <li>• a range of volsers separated by a hyphen</li> <li>• set to empty ("" or '\0') if it is not to be changed</li> </ul>	
type	media type of the named volser range Refer to <i>Media Types</i> on page 2-7	
pnActualCount	returned number of ejected volsers	
aci_ei_info	returned information to each ejected volser	
	volser	volser of the ejected volume
	type	media type of the named volser Refer to <i>Media Types</i> on page 2-7
	errcode	Error code derrno

If the eject area is full the system stops the eject procedure. Depending on the DAS\_EJECTAREAFULL environment variable on the AMU, the command will be canceled, or the system starts with the next eject after the operator has removed cartridges from the eject area.

The attribute of the coordinate will be set to empty in the AMU database. The volser will be set to 0000000000000000, but the type will remain unchanged. The compartment is ready for the other volsers.

For additional information, refer to *aci\_insert* on page 4-75, and *aci\_eject2* on page 4-42.

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ENOAREA
- ENOTAUTH
- EBADCLIENT
- ERETRYL
- EINUSE
- ECANCELED
- EDASINT
- ENOMATCH
- ETIMEOUT
- ESWITCHINPROG
- EHICAPINUSE
- ECOORDINATE
- EBARCODE
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY
- EBARCODE
- EAREAFULL

Refer to Figure 4-43 on page 4-54 for an example of the `aci_eject2_complete` function.

```

/* Eject volume complete from AML system*/
int rc, i, pnActualCount;
char *volser_range = "000815 - 004711";
char *eject_area = "E02"
struct aci_ei_info ei_info[ACI_EI_MAX_RANGE] ;
rc = aci_eject2_complete( eject_area, volser_range,
                        ACI_3590, & pActualCount, &ei_info );
if( rc )
{
    aci_perror( "Command failed: " );
}
else
{
    printf("Volume ejects request successful\n" );
    for (i = 0; i < ACI_EI_MAX_RANGE; i++)
    {
        if ( *ei_info[i]->volser == '\0' )
            break;
        printf( "volser:%s media type:%s Error:%d\n",
                ei_info[i]->volser,
                ei_info[i]->media_type,
                ei_info[i]->errcode );
    }
}

```

**Figure 4-43** Example of the aci\_eject2\_complete Function

## aci\_eject3\_complete

The aci\_eject3\_complete function ejects a range of volumes from the AML, and deletes the home coordinate. See Figure 4-44.

```

#include "aci.h"
int aci_eject3_complete( char *eject_area,
                        char *volser_range,
                        enum aci_media_type,
                        int *pnActualCount,
                        struct aci_ei_info *psteiInfo)

```

**Figure 4-44** aci\_eject3\_complete Function Call

The volser\_range field has a maximum size of 512 bytes.  
 See Figure 4-45 for the structure of the aci\_ei\_info function.

```

struct aci_ei_info {
    char volser[ACI_VOLSER_LEN];
    char media_type[ACI_DRIVE_LEN];
    int errcode
};
  
```

**Figure 4-45** Structure of the aci\_ei\_info function

See Table 4-20 for a description of the parameters for the aci\_eject3\_complete function call.

**Table 4-20** Parameters for the aci\_eject3\_complete Function Call

Parameter	Description	
eject_area	logical area defined in AML, where the cartridges should be ejected	
volser_range	<ul style="list-style-type: none"> <li>• a single volser</li> <li>• multiple volsers separated by commas</li> <li>• a range of volsers separated by a hyphen</li> <li>• set to empty ("" or '\0') if it is not to be changed</li> </ul>	
type	media type of the named volser range Refer to <i>Media Types</i> on page 2-7	
pnActualCount	returned number of ejected volsers	
aci_ei_info	returned information to each ejected volser	
	volser	volser of the ejected volume
	type	media type of the named volser Refer to <i>Media Types</i> on page 2-7
	errcode	Error code derrno

If the eject area is full the system stops the eject procedure. Depending on the DAS\_EJECTAREAFULL environment variable on the AMU, the command will be canceled, or the system starts with the next eject after the operator has removed cartridges from the eject area.

---

---

The attribute of the coordinate will be set to empty in the AMU database. The volsr will be set to 0000000000000000, but the type will remain unchanged. The compartment is ready for the other volsers.

For additional information, refer to *aci\_insert* on page 4-75, and *aci\_eject2* on page 4-42.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ENOAREA
- ENOTAUTH
- EBADCLIENT
- ERETRYL
- EINUSE
- ECANCELED
- EDASINT
- ENOMATCH
- ETIMEOUT
- ESWITCHINPROG
- EHICAPINUSE
- ECOORDINATE
- EBARCODE
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY
- EBARCODE
- EAREAFULL

---

---

## aci\_ejectclean

The `aci_ejectclean` function ejects all exhausted cleaning cartridges from one Cleanpool. See Figure 4-46.

```
#include "aci.h"
int aci_ejectclean( char *areaname,
                  char *Cleanpoolname,
                  int *pnActualCount,
                  struct aci_ei_info *psteiInfo)
```

**Figure 4-46** aci\_ejectclean Function Call

See Figure 4-47 for the structure of the `aci_ei_info` function.

```
struct aci_ei_info {
    char volsers[ACI_VOLSER_LEN];
    char media_type[ACI_DRIVE_LEN];
    int errcode
};
```

**Figure 4-47** Structure of the `aci_ei_info` function from `aci.h`

See Table 4-21 for a description of the parameters for the `aci_ejectclean` function Call.

**Table 4-21** Parameters for the `aci_ejectclean` Function Call

Parameter	Description
areaname	Logical area defined in AMS, where the cartridges should be ejected, e.g. E01
Cleanpoolname	Name of the group of cleaning cartridges, e.g. CLP01, defined in the AML configuration
pnActualCount	returned number of ejected volsers

**Table 4-21** Parameters for the aci\_ejectclean Function Call

Parameter	Description	
aci_ei_info	returned information to each ejected volser	
	volser	volser of the ejected volume
	type	media type of the named volser Refer to <i>Media Types</i> on page 2-7
	errcode	error code derrno

If the eject area is full the system stops the eject procedure. Depending on the DAS\_EJECTAREAFULL environment variable on the AMU, the command will be canceled, or the system starts with the next eject after the operator has removed cartridges from the eject area.

The attribute of the coordinate will be set to empty in the AMU database. The volser will be set to 0000000000000000, and the type will be set to AMU-Dynamic. The compartment is ready for the other volsers.



**The compartments for cleaning cartridges are not reserved. Organize enough compartments for the cleaning cartridges every time.**

For additional information, refer to *aci\_insert* on page 4-75, and *aci\_eject2* on page 4-42.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ENOAREA
- ENOTAUTH

- 
- 
- EBADCLIENT
  - ERETRYL
  - EINUSE
  - ECANCELED
  - EDASINT
  - ENOMATCH
  - ETIMEOUT
  - ESWITCHINPROG
  - ENOPOOL
  - EAREAFULL
  - EHICAPINUSE
  - ECOORDINATE
  - EBARCODE
  - EINVALIDDEV
  - ENOROBOT
  - EDATABASE
  - ENOTSUPPHCMD
  - EAREAEMPTY
  - EBARCODE
  - EAREAFULL

Refer to Figure 4-48 on page 4-60 for an example of the `aci_ejectclean` function.

```

/* Eject clean cartridges from AML system*/
int res, i, pnActualCount;
char *Cleanpoolname = "CLP01";
char *areaname = "E02"
struct aci_ei_info *ei_info[ACI_EI_MAX_RANGE];
res =      aci_ejectclean( areaname, Cleanpoolname,
                        ei_info);
if( rec )
{
    aci_perror( "Command failed: " );
}
else
{
    printf("Volume ejects request successful\n" );
for (i = 0; i < ACI_EI_MAX_RANGE; i++)
    {
        if ( *ei_info[i]->volser == '\0' )
            break;
        printf( "volser:%s media type:%s Error:%d\n",
                ei_info[i]->volser,
                ei_info[i]->media_type,
                ei_info[i]->errcode );
    }
}
}

```

**Figure 4-48** Example of the aci\_ejectclean Function

## aci\_email

The aci\_email function sends email messages. See Figure 4-49.

```

#include "aci.h"
int aci_email (char *Adr
              char *Msg)

```

**Figure 4-49** aci\_email Function Call

See Table 4-22.

**Table 4-22** Parameter for the aci\_email Function Call

Parameter	Description
Adr	A non-empty email address of no more than 64 characters
Msg	defines the email message of no more than 255 characters



Only supported by the Scalar DLC software.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROG
- EBADCLIENT
- ENOTSUPPHCMD

## aci\_flip

The `aci_flip` function turns an Optical Disk (O. D.) in a drive. See Figure 4-50.

```
#include "aci.h"
int aci_flip( char *drive)
```

**Figure 4-50** aci\_flip Function Call

In the drive named *drive*, the dismounted O. D. will be turned 180° and mounted in the same drive. Refer to Table 4-23 for a description of the parameter for the `aci_flip` function.

For additional information, refer to `aci_mount` on page 4-91, and `aci_dismount` on page 4-16.

---

---

**Table 4-23** Parameter for the aci\_flip Function Call

Parameter	Description
drive	name of the optical disk drive for the flip operation

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- ENODRIVE
- EDRVOCCUPIED
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- EDEVEMPTY
- ENOTAUTH
- EBADCLIENT
- ENOTMOUNTED
- ECANCELED
- EDASINT
- ECLEANING
- ETIMEOUT
- ESWITCHINPROG
- EHICAPINUSE
- ECOORDINATE
- EBARCODE
- EINVALIDDEV
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY

- 
- 
- EBARCODE
  - EAREAFULL

See Figure 4-51 for an example of the `aci_flip` function.

```
/* Flip a volume in a optical disk drive */
int rc = 0;
char *drive = "od01";
if (( rc = aci_flip( drive ) ))
{
    aci_perror( "Flip command failed: " );
}
else
{
    printf("Flip of in drive %s successful
completed.\n", drive );
}
```

**Figure 4-51** Example of the `aci_flip` Function

---

---

## aci\_force

The `aci_force` function dismounts any cartridge from a specific drive. See Figure 4-52.

```
#include "aci.h"
int aci_force( char *drive )
```

**Figure 4-52** aci\_force Function Call

Force a dismount from a drive named *drive*, regardless of which *volser* is in the drive. See Table 4-24.

For additional information, refer to *aci\_dismount* on page 4-16, and *aci\_mount* on page 4-91.

**Table 4-24** Parameter for the `aci_force` Function Call

Parameter	Description
drive	name of the drive for the dismount

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- ENODRIVE
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- EDEVEMPTY
- ENOTAUTH
- EUPELSE

- 
- 
- EBADCLIENT
  - ENOTMOUNTED
  - ECANCELED
  - EDASINT
  - ENOMATCH
  - ETIMEOUT
  - ESWITCHINPROG
  - EHCAPINUSE
  - ECOORDINATE
  - EBARCODE
  - EINVALIDDEV
  - ENOROBOT
  - EDATABASE
  - ENOTSUPPHCMD
  - EAREAEMPTY
  - EBARCODE
  - EAREAFULL

See Figure 4-53 for an example of the `aci_force` function.

```
/* Dismount any volume from drive */
int rc = 0;
rc = aci_force( "Drive1" );
if( rc )
{
    aci_perror( "Command failed: " );
}
else
{
    printf( "Dismount of Drive1 successful.\n" );
}
```

**Figure 4-53** Example of the `aci_force` Function

---

---

## aci\_foreign

The aci\_foreign function catalogs a foreign volume. See Figure 4-54.

```
#include "aci.h"
int aci_foreign( enum aci_command action,
                char *volser,
                enum aci_media type,
                char *coordinate,
                short position )
```

**Figure 4-54** aci\_foreign Function Call

When a foreign volume named *volser* of media *type* has been added to or removed from the AML system in a foreign mount area, DAS must be informed of the status. This function notifies DAS of the existence of the volume, and its coordinate. If added, the volume can be used simply by referencing this *volser* and *type* in a further *aci\_mount()* or *aci\_dismount()* request. See Table 4-25.

**Table 4-25** Parameters for the aci\_foreign Function Call

Parameter	Descriptions	
action	select the command for the foreign catalog procedure	
	ACI_ADD	new volser will be added to the foreign media area in DAS and AML database
	ACI_DELETE	volser entry for a foreign media that will be removed from the DAS and AMU database
volser	volser, that should be used in the application for the mount (volser with up to 16 digits and alphanumeric symbols, no special characters)	
type	media type of the named volser Refer to <i>Media Types</i> on page 2-7	
coordinate	10 digit logical coordinate of the compartment of the foreign volume in the AMS, e.g. E501010110 Refer to the <i>AMU Reference Guide</i>	

**Table 4-25** Parameters for the `aci_foreign` Function Call

Parameter	Descriptions
position	reserved for compatibility, not used



This version does not have a command to display occupied symbolic volsters. Please note this assignment; the symbolic volster will be needed for the `rmf` command.

For additional information, refer to `aci_dismount` on page 4-16, and `aci_mount` on page 4-91.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EDASINT
- ENOTAUTH
- EBADCLIENT
- ENOSPACE
- EDASINT
- ENOMATCH
- ETIMEOUT
- ERSWITCHINPROG
- EINVALIDDEV
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY

Refer to Figure 4-55 on page 4-68 for an example of the `aci_foreign` function.

```

/* Add foreign media to DAS catalog */
int rc = 0;
enum aci_media type = ACI_3590;
char *volser = "FOR001";
char *coord = "E301010310";
short pos = 0;
if ((rc = aci_foreign(ACI_ADD, volser, type,
                    coord, pos )))
{
    aci_perror("Foreign media location failed: ");
}
else
{
    printf("Foreign volser %s added.\n", volser);
}

```

**Figure 4-55** Example of the aci\_foreign Function.

## aci\_getvolsertodrive

The aci\_getvolsertodrive function gets the configured relation between the specified drive and the volser. See Figure 4-56.

```

#include "aci.h"
int aci_getvolsertodrive ( char *Drive,int num
                        struct aci_voltodrive_entry
                        *Idrive_inf[ACI_DRIVE_NUMBERS] )

```

**Figure 4-56** aci\_getvolsertodrive Function Call

This call returns the configured relation between the specified drive and volsers. If 'Drive' is the Null String, the call returns the relation of all drives that are configured. The response is returned in InfoVolserToDrive, an array of pointers to an aci\_voltodrive\_entry structure. Refer to Figure 4-57 on page 4-69.

```

struct aci_voltodrive_entry{
    char Drive[ACI_DRIVE_LEN] ;
    char VolserRange[ACI_RANGE_LEN] ;
}

```

**Figure 4-57** aci\_voltodrive\_entry Structure

See Table 4-26 for a description of the parameters for the aci\_getvolsertodrive function call.

**Table 4-26** Parameters for the aci\_getvolsertodrive Function Call

Parameter	Description	
Drive	name of the drive, that the reserved volsers requested	
num	number of reported entries	
aci_voltodrive_entry	information returned for the selected drive	
	Drive	name of drive
	VolserRange	<ul style="list-style-type: none"> <li>• a single volser</li> <li>• multiple volsers separated by commas</li> <li>• a range of volsers separated by a hyphen</li> </ul>

## Return Values

- 0: The call was successful
- -1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- ERPC
- ENODRIVE
- EDASINT
- ETIMEOUT
- ESWITCHINPROG

Refer to Figure 4-58 on page 4-70 for an example of the aci\_getvolsertodrive function.

```

/* Display volumes reserved for a drive*/
int rc, i, num;
char *Drive = "Drive1";
struct aci_voltodrive_entry
    *drive_inf[ACI_MAX_RANGES];
rc = aci_getvolsertodrive( Drive, num, drive_inf);
if( rc )
{
    aci_perror( "Command failed: " );
}
else
for ( i = 0; i < ACI_MAX_RANGES; i++)
{
    if ( *drive_inf[i]->volser == '\0' )
        break;
    printf( "drive:%s Volser Range%d\n",
        drive_inf[i]->Drive,
        drive_inf[i]->VolserRange );
}

```

**Figure 4-58** Example of the aci\_getvolertodrive Function

## aci\_getVolserToSide

The aci\_getvolsertoside function returns the second volser to an optical disk (a volume with two volsers). See Figure 4-59.

```

int aci_getVolserToSide (char *volser,
    struct aci_sideinfo
    *sideinfo[ACI_SIDE_NUMBER] )

```

**Figure 4-59** aci\_getVolserToSide Function Call

This function returns in the *'sideinfo'* parameter, the volser attached to one of a two sided volume. The *'volser'* parameter can be the A-side or the B-side volser. When a volser of a volume with one side is specified, an error ENODOUBLESIDE error is returns.

The *sideinfo[0]* parameter gives the attachment of the A-side, and *sideinfo[1]* gives the attachment of the B-side.

The media type for the volser in the AMS configuration must be Optical disk (O0 or O1). Refer to Figure 4-60 on page 4-71.

```

struct aci_sideinfo {
    char  cVolumeSide;
    char  szVolser [ACI_VOLSER_LEN] ;
}

```

**Figure 4-60** Structure of Type aci\_sideinfo

The define 'ACI\_SIDE\_NUMBER' parameter is set, in aci.h, to 2. See Table 4-27.

**Table 4-27** Parameters for the aci\_getvolsertoside Function Call

Parameter	Description	
volser	name of the volser, for which information is requested	
aci_sideinfo	information returned for the selected volser	
	CVolumeside	<ul style="list-style-type: none"> <li>• A: for the Volser located on the top label</li> <li>• B: for the Volser located on the bottom label on the cartridge</li> </ul>
	sZVolser	Volser from the AMU database

## Return Values

- 0: The call was successful
- -1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- ERPC
- EINVAL
- ENOVOLUME
- ENOTAUTH
- ETIMEOUT
- ESWITCHINPROG
- ENODOUBLESIDE

Refer to Figure 4-61 on page 4-72 for an example of the aci\_getvolsertoside function.

```

/* Display volsers for the optical disk*/
int rc = 0;
char *volser = "00815F";
struct aci_sideinfo *sideinfo[ACI_SIDE_NUMBER];
rc = aci_getvolsertoside( volser, sideinfo);
if( rc )
{
    aci_perror( "Command failed: " );
}
else
    printf( "Side:%s Volser:%d\n",
        side_info[0]->Side,
        side_info[0]->Volser,
        side_info[1]->Side,
        side_info[1]->Volser);
}

```

**Figure 4-61** Example of the aci\_getvolsertoside Function

## aci\_init

The aci\_init function initializes the AML for client use. See Figure 4-62.

```

#include "aci.h"
int aci_init( void )

```

**Figure 4-62** aci\_init Function Call

Most clients wish to start from a known status, the aci\_init call is provided so that an initialization, or restart, of a client may request that any resources previously held are freed. Normally this call can be placed in the initialization of the client code. This function requests that the DAS server dismount any occupied drives defined to the requesting client.

For additional information, refer to *aci\_initialize* on page 4-74.

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- EDASINT
- EBADCLIENT
- EDASINT
- ETIMEOUT
- ESWITCHINPROG

See Figure 4-63 for an example of the `aci_init` function.

```
/* Initialize client and free drive resources */
int rc = 0;
rc = aci_init( );
if( rc )
{
    aci_perror( "ACI failed initialization:" );
}
```

**Figure 4-63** Example of the `aci_init` Function

---

---

## aci\_initialize

The `aci_initialize` function initializes ACI library for client use. See Figure 4-64.

```
#include "aci.h"
int aci_initialize( void )
```

**Figure 4-64** aci\_initialize Function Call

This function initializes the DAS 3.01 ACI library. This function should be called as the first activity, before the use of any other functions from the ACI library.

For additional information, refer to *aci\_init* on page 4-72.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EDASINT
- EDASINT
- ESWITCHINPROG

See Figure 4-65 for an example of the `aci_initialize` function.

```
/* Initialize client, do not change drive state */
int rc = 0;
rc = aci_initialize( );
if( rc )
{
    aci_perror( "ACI failed initialization:" );
}
```

**Figure 4-65** Example of the `aci_initialize` Function

---

---

## aci\_insert

The aci\_insert function inserts volumes into the AML. See Figure 4-66.

```
#include "aci.h"
int aci_insert( char *insert_area,
               char *volser_ranges,
               enum aci_media type )
```

**Figure 4-66** aci\_insert Function Call



**This function is for compatibility. Please use the aci\_insertgen function.**

The cartridges which are actually located in the insert area of the AML and registered by the AMU (automatically inventoried after closing the area) will be inserted.

- Volsers which already have a entry in the AMU database, will be moved to this position.
- Volsers which have no entry in the AMU database, will be moved to the first free slot (AMU database Attribute: "Empty" of this media type of the Type AMU-Dynamic)
- Cartridges with an invalid volser (barcode not readable) will moved to the problembox.

See Table 4-28 for a description of the parameters for the aci\_insert function call.

**Table 4-28** Parameters for the aci\_insert Function Call

Parameter	Description
insert_area	Logical insert range of the Insert/Eject unit of the AML in the AMS (e.g. I03)
volser_range	The volumes found in the insert_area are returned in the volser_ranges array of strings, where each volser is separated by a comma. Each range is ACI_RANG_LEN long and there are up to ACI_MAX_RANGES ranges. An empty string indicates the end of the ranges
type	media type of the volser in the insert area Refer to <i>Media Types</i> on page 2-7



Use the `insert2` function instead of this command. This function experiences difficulties with large I/O units with long volsers (16-digit) since the buffer for displaying the inserted volser is restricted. For compatibility reasons this function continues to be supported.

For additional information, refer to `aci_insert` on page 4-75, and `aci_eject2` on page 4-42.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ENOAREA
- ENOAUTH
- ERETRYL
- ECANCELLED
- EDASINT
- ENOMATCH
- ETIMEOUT
- ESWITCHINPROG
- EHICAPINUSE
- ECOORDINATE
- EBARCODE
- EINVALIDDEV
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY
- ENOPOOL

- 
- 
- EBARCODE
  - EAREAFULL

Refer to Figure 4-67 on page 4-77 for an example of the `aci_insert` function.

```
/* Insert media into AML */
int rc, i;
enum aci_media type = ACI_3590;
char *area_name = "I01";
char *volser_ranges[ACI_MAX_RANGES];
rc = aci_insert(area_name, volser_ranges, &type);
if( rc )
{
    aci_perror("Command failed: ");
}
else
{
    for (i = 0; i < ACI_MAX_RANGES; i++)
        if (*volser_ranges[i] == '\0')
            break;
        else
            printf("%s\n", volser_ranges[i]);
}
```

**Figure 4-67** Example of the `aci_insert` Function

## aci\_insert2

The `aci_insert2` function inserts volumes, including clean media, into the AML. See Figure 4-68

```
#include "aci.h"
int aci_insert2( char *insertopt,
                char *areaname,
                char *cleanPoolname,
                int *pnActualCount,
                struct aci_ei_info *pstEiInfo)
```

**Figure 4-68** `aci_insert2` Function Call

The cartridges which are located in the Insert area of the AML and registered by the AMU (automatically inventoried after closing the area), will be inserted.

- Volsers which already have a entry in the AMU database, will be moved to this position.
- Volsers which have no entry in the AMU database, will be moved to the first free slot (AMU database Attribute: "Empty" of this media type of the Type AMU-Dynamic)
- With insertopt -c will move the cartridges to the first free slot (AMU database Attribute: "Empty") of this media type of the Type AMU-Dynamic. The attribute will automatic change to Clean
- Cartridges with an invalid volser (barcode not readable) will be moved to the problembox.

The function returned the inserted volser with the following structure. See Figure 4-69.

For additional information, refer to *aci\_eject* on page 4-39.

```

struct aci_ei_info {
    char  volser [ACI_VOLSER_LEN] ;
    char  media_type [ACI_DRIVE_LEN;
    int  errcode
}

```

**Figure 4-69** aci\_ei\_info Structure from aci.h

See Table 4-29 for a description of the parameters for the aci\_insert2 function call.

**Table 4-29** Parameters for the aci\_insert2 Function Call

Parameter	Description	
insertopt	defined the type of media for the insert operation	
	-n	normal (data cartridges)
	-c	clean (cleaning cartridges)
areaname	Logical insert range of the Insert/Eject unit of the AML in the AMS (e.g. I03)	
cleanPoolname	Name of the Cleanpool defined in AML (must be NULL, if insertopt= n)	
pnActualCount	Number of inserted volsers and pointer to an array of structure	

---

---

**Table 4-29** Parameters for the aci\_insert2 Function Call

Parameter	Description	
aci_ei_info	returned information on each volser ejected	
	volser	volser of the ejected volume
	type	media type of the named volser Refer to <i>Media Types</i> on page 2-7
	errcodes	error code derrno

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable d\_errno is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ENOAREA
- ENOAUTH
- ERETRYL
- ECANCELLED
- EDASINT
- ENOMATCH
- ECLEANING
- ETIMEOUT
- ESWITCHINPROG
- ENOPOOL
- EHICAPINUSE
- ECOORDINATE
- EBARCODE
- EINVALDEV
- ENOROBOT

- 
- 
- EDATABASE
  - ENOTSUPPHCMD
  - EAREAEMPTY
  - ENOPOOL
  - EBARCODE
  - EAREAFULL

See Figure 4-70 for an example of the `aci_insert2` function.

```
/* insert clean volume in the AML system*/
int res, i, pnActualCount;
char *cleanPoolname = "CLP01";
char *areaname = "I02"
struct aci_ei_info *pstEiInfo[ACI_EI_MAX_RANGE];
res = aci_insert2( "-c", areaname, cleanPoolname,
                  &pnActualCount, pstEiInfo;
if( rec )
{
    aci_perror( "Command failed: " );
}
else
{
    printf("Volume insert request successful\n" );
    for (i = 0; i < ACI_EI_MAX_RANGE; i++)
    {
        if ( *ei_info[i]->volser == '\0' )
            break;
        printf( "volser:%s media type:%s Error:%d\n",
                ei_info[i]->volser,
                ei_info[i]->media_type,
                ei_info[i]->errcode );
    }
}
}
```

**Figure 4-70** Example of the `aci_insert2` Function

---

---

## aci\_inventory

The aci\_inventory function performs a physical inventory of the AML. See Figure 4-71.

```
#include "aci.h"
int aci_inventory( void )
```

Figure 4-71 aci\_inventory Function Call

This command instructs the robot to perform a physical inventory of the archive and to update the database. The inventory command is issued to the archive and the function will not wait for the completion of the inventory operation. The aci\_list() function may be called to determine whether the inventory command is still active (result for a running inventory is PINV)

### **Attention**

**The inventory function is intended for testing and startup. An error function will be displayed in the AMU log during operation (and not returned to the calling process). The entire database will be overwritten with a symbolic volser “\*Ixxxx” if the barcode reader malfunctions.**

For additional information, refer to *aci\_qvolsrange* on page 4-98, and *aci\_view* on page 4-123.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable d\_errno is set to one of the following DAS error codes:

- EPC
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ERETRYL
- EDASINT
- ETIMEOUT
- ESWITCHINPROG

- 
- 
- EHCAPINUSE
  - ECOORDINATE
  - EBARCODE

See Figure 4-72 for an example of the aci\_inventory function.

```
/* Inventory the AML */
int rc = 0;
rc = aci_inventory( );
if( rc )
{
    aci_perror( "Command failed:" );
}
```

**Figure 4-72** Example of the aci\_inventory Function

## aci\_killamu

The aci\_killamu function homes the robots and shuts down all programs running on the AMU PC (including OS/2). See Figure 4-73.

```
#include "aci.h"
int aci_killamu(void)
```

**Figure 4-73** aci\_killamu Function Call

The call of this function shuts down the complete AMU-PC. DAS sends a response to the client. Wait 5 minutes before powering off.



### **Attention**

**Inform all administrators also using the AML system before starting the command. The command may cause disruption to their operation.**

**DAS sends a positive acknowledgment, before the process is complete. Wait at least 5 minutes following the positive acknowledgment before switching off the power supply to the machine. Switching off the power supply to the AMU PC too soon can lead to loss of data.**

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ENOTAUTH
- ERPC
- EINVAL
- EDASINT
- ETIMEOUT
- EAMUCOMM
- EHICAPINUSE
- ESWITCHINPROG

See Figure 4-74 for an example of the `aci_killamu` function.

```
/* Shutdown of the AMU */
int rc = 0;
rc = aci_killamu( );
if( rc )
{
    aci_perror( "Shutdown of AMU PC failed:" );
}
```

**Figure 4-74** Example of the `aci_killamu` Function

---

---

## aci\_list

The `aci_list` function lists outstanding requests for a client. See Figure 4-75.

```
#include "aci.h"
int aci_list( char *clientname,
             struct aci_req_entry
             *request_list[ACI_MAX_REQ_ENTRIES] )
```

**Figure 4-75** aci\_list Function Call

List outstanding requests belonging to the client *clientname*. Return the requests in the *request\_list* array of `aci_req_entry` *request\_list* structures. The structure's request types are defined in the header file "aci\_das.h". See Figure 4-76.

For additional information, refer to *aci\_cancel* on page 4-7.

```
struct aci_req_entry {
    u_long request_no;
    u_long individ_no;
    char clientname[ACI_NAME_LEN];
    char req_type[ACI_REQTYPE_LEN + 1];
};
```

**Figure 4-76** Example of the Returned Structure

Refer to Table 4-30 for a description of the parameters for the `aci_list` function call.

---

---

**Table 4-30** Parameters for the aci\_list Function Call

<b>Parameter</b>	<b>Description</b>	
clientnamet	Name of the client that active request are reported to.	
aci_req_entry	Returned information about outstanding commands	
	request_no	DAS command sequence serial number
	individ_no	reserved, not used
	clientname	name of the requesting client
	req_type	type of the outstanding command Refer to Table 4-31

See Table 4-31 for an explanation of the req\_types.

**Table 4-31** Explanation of the Req\_types

<b>req_types</b>	<b>Explanation</b>
BACO	switch barcode reading on or off (aci_barcode)
EJCL	eject of cleaning cartridges (aci_ejectclean)
INCL	insert media from I/O unit with aci_insertgen
INVT	insert media from I/O with aci_insert
KEEP	keep media from drive (aci_dismount)
MOUNT	mount media to a drive (aci_mount)
MOVE	eject media to I/O unit (aci_eject, aci_eject_complete)
PINV	Complete archive inventory and database update (aci_inventory)
PRGE	Delete a command from the command list (aci_cancel)
SHUT	Shutdown off the complete AMU (aci_killamu)

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- EDASINT
- ETIMEOUT
- ESWITCHINPROG

See Figure 4-77 for an example of the `aci_list` function.

```
/* List outstanding client requests */
int rc, i;
char *client = "SomeClient";
struct aci_req_entry *requests[ACI_MAX_REQ_ENTRIES];
if ( rc = aci_list( client, requests ) )
{
    aci_perror( "Command failed: " );
}
else
{
    printf ("List for client %s successful\n",
           client);
    for (i=0; (i<ACI_MAX_REQ_ENTRIES)&&(requests[i]-
    >request_no!=0);i++)
    {
        printf("client = %s\n\trequest =
        %u\n\tindivid_no = %ld\n"
              "\ttype = %s\n",
              requests[i]->clientname,
              requests[i]->request_no,
              requests[i]->individ_no,
              requests[i]->req_type);
    }
}
```

**Figure 4-77** Example of the `aci_list` Function

---

---

## aci\_list2

The `aci_list2` function lists executing requests for a client. See Figure 4-78.

```
#include "aci.h"
int aci_list2( char *clientname,
              struct aci_req_entry2
              *req_status[])
```

**Figure 4-78** aci\_list2 Function Call

List executing requests belonging to the client *clientname*. Return the requests in the array of `aci_req_entry2` structures. The array element can be maximum size of 15. See Figure 4-79.

```
struct aci_req_entry2 {
    u_long request_no;
    u_long individ_no;
    char clientname[ACI_NAME_LEN];
    char req_type[ACI_REQTYPE_LEN2 + 1];
    char Volser[ACI_VOLSER_LEN];
    char Drive[ACI_DRIVE_LEN];
    char AreaName[ACI_AREANAME_LEN];
    char PoolName[ACI_POOLNAME_LEN];
    char VolserRange[ACI_RANGE_LEN];
    char StartCoord[ACI_COORD_LEN];
    char EndCoord[ACI_COORD_LEN];
};
```

**Figure 4-79** Example of the Returned Structure

Refer to Table 4-32 for a description of the parameters for the `aci_list2` function call.

**Table 4-32** Parameters for the aci\_list2 Function Call

Parameter	Description	
clientname	Name of the client that receives the active request information.	
aci_req_entry2	Returned information about executing commands	
	request_no	DAS command sequence serial number
	individ_no	reserved, not used
	clientname	name of the requesting client
	req_type	type of the outstanding command Refer to Table 4-31
	Volser	the volser number
	Drive	the drive number
	AreaName	the import or export area
	PoolName	the pool name (scratch, clean)
	VolserRange	the range of the volser
	StartCoord	starting coordinates of the range
	EndCoord	the ending coordinates of the range

See Table 4-33 for an explanation of the req\_types.

**Table 4-33** Explanation of the Req\_types

req_types	Explanation
BACO	switch barcode reading on or off (aci_barcode)
EJCL	eject of cleaning cartridges (aci_ejectclean)
INCL	insert media from I/O unit with aci_insertgen
INVT	insert media from I/O with aci_insert
KEEP	keep media from drive (aci_dismount)
MOUNT	mount media to a drive (aci_mount)
MOVE	eject media to I/O unit (aci_eject, aci_eject_complete)

**Table 4-33** Explanation of the Req\_types

req_types	Explanation
PINV	Complete archive inventory and database update (aci_inventory)
PRGE	Delete a command from the command list (aci_cancel)
SHUT	Shutdown off the complete AMU (aci_killamu)

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- EDASINT
- ETIMEOUT
- ESWITCHINPROG
- ENOTSUPPHCMD

## aci\_list\_foreign

The `aci_list_foreign` function queries status from up to 300 foreign volsers for a client. See Figure 4-80.

```
#include "aci.h"
int aci_list_foreign( char *volser,
                    int *nCount,
                    aci_foreign_desc *pszForeign)
```

**Figure 4-80** aci\_list\_foreign Function Call

Returns the status of the foreign volser. If the volser is the NULL string, return `nCount` status on all foreign volsers. The status is returned in an array of pointers to `aci_foreign_desc` structure. The array element can be maximum size of 300. See Figure 4-81.

```

struct aci_foreign_desc {
    char volser[ACI_VOLSER_LEN];
    char coord[ACI_COORD_LEN];
    enum aci_media_type eType;
    char attrib
};

```

**Figure 4-81** Example of the Returned Structure

Refer to Table 4-34 for a description of the parameters for the aci\_list\_foreign function call.

**Table 4-34** Parameters for the aci\_list\_foreign Function Call

Parameter	Description	
volser	the volser number	
coord	coordinates of the foreign volser	
aci_media_type	eType	the medium type of the volser as listed in the <i>DAS Administration Guide</i>
attrib	the attributes of the foreign volser	

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROG
- EBADCLIENT
- ENOTSUPPHCMD

---

---

## aci\_mount

The `aci_mount` function mounts a volume in a drive. See Figure 4-82

```
#include "aci.h"
int aci_mount( char *volser,
               enum aci_media type,
               char *drive )
```

**Figure 4-82** aci\_mount Function Call

Mount the volume named *volser* of media type *type* in the drive named *drive*. The volume will then be available to the requesting client. See Table 4-35.

For additional information, refer to *aci\_dismount* on page 4-16, and *aci\_scratch\_set* on page 4-114, and *aci\_view* on page 4-123.

**Table 4-35** Parameters for the `aci_mount` Function Call

Parameter	Description
volser	Volser which should be mounted (also foreign volser possible after the cataloging with carf)
type	Media type of the named volser Refer to <i>Media Types</i> on page 2-7
drive	Name of the drive which should be mounted. If the drive is set to the NULL string, the drive is automatically selected from the list of available drives to the client. The client host must have Automatic Volume Recognition (AVR) active to detect the mount.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- ENOVOLUME
- ENODRIVE

- 
- 
- EDRVOCCUPIED
  - EPROBVOL
  - EAMU
  - EAMUCOMM
  - EROBOTCOMM
  - EDASINT
  - EDEVEMPTY
  - ENOTAUTH
  - EUPELSE
  - EBADCLIENT
  - ERETRYL
  - EINUSE
  - ENOTFOUND
  - ECANCELLED
  - EDASINT
  - ENOMATCH
  - ECLEANING
  - ETIMEOUT
  - ESWITCHINPROG
  - EHCAPINUSE
  - ECOORDINATE
  - EBARCODE
  - EINVALIDDEV
  - ENOROBOT
  - EDATABASE
  - ENOTSUPPHCMD
  - ECOORDINATE
  - EPROBDEV
  - EBARCODE
  - EAREAFULL

Refer to Figure 4-83 on page 4-93 for an example of the `aci_mount` function.

```

/* Mount volume in specific drive */
int rc = 0;
rc = aci_mount( "AAB001", ACI_3590, "Drive2" );
if( rc )
{
    aci_perror( "Command failed:" );
}
else
{
    printf( "Mount of %s successful.\n", volser );
}

```

Figure 4-83 Example of the aci\_mount Function

## aci\_partial\_inventory

The aci\_partial\_inventory function inventories part of the AML (only in one device). See Figure 4-84.

```

#include "aci.h"
int aci_partial_inventory (char *SourceCoor,
                          char *TargetCoor)

```

Figure 4-84 aci\_partial\_inventory Function Call

Start the compare between physical AML (barcode of the Volser or database of the Scalar 1000) with the AMU database and update the AMU database.



**When aci\_partial\_inventroy is called with NULL stings for SourceCoor and TargetCoor parameters, a complete inventory will be invoked. If the archive is large, it could take several hours for the inventory to complete.**

Refer to Table 4-36 on page 4-94 for a description of the parameters for the aci\_partial\_inventory function call.

---

---

**Table 4-36** Parameters for the aci\_partial\_inventory Function Call

<b>Parameter</b>	<b>Description</b>
SourCoord	10 digit logical coordinate of the device for the start of the inventory (defined in the AMU database), e.g. L501010101
TargetCoord	10 digit logical coordinate of the device for the end of the inventory (defined in the AMU database), e.g. L501011310 Source and targeted must be in the same device.

 **Attention**

The aci\_partial\_inventory function is intended for testing and startup. An error function will be displayed in the AMU log during operation (and not returned to the calling process). The database segments that are defined in the function cell will be overwritten with a symbolic volser “\*Ixxx” if the barcode reader malfunctions.

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ERETRYL
- ENOTFOUND
- ECANCELLED
- EDASINT
- ETIMEOUT
- ESWITCHINPROG
- EHICAPINUSE
- ECOORDINATE
- EBARCODE

See Figure 4-85 for an example of the `aci_partial_inventory` function.

```
/* Partial Inventory in AML */
int rc = 0;
rc =aci_partial_inventory("L501010101", L501011310");

if( rc )
{
    aci_perror( "Command failed:" );
}
else
{
    printf( "Inventory started successful.\n");
}
```

**Figure 4-85** Example of the `aci_partial_inventory` Function

---

---

## aci\_perror

The `aci_perror` function writes DAS error text to standard error. See Figure 4-86.

```
#include "aci.h"
int aci_perror( char *error_prefix )
```

**Figure 4-86** aci\_perror Function Call

The `aci_perror` function writes an error message to the standard error device, describing the last error encountered. The error message is either returned by the DAS server, or if not available, the error message is selected according to the value stored in `d_errno`. The parameter `error_prefix` is attached to the message. See Table 4-37.

**Table 4-37** Parameter for the `aci_perror` Function Call

Parameter	Description
Error_prefix	message (error, warning or information) stored in <code>d_errno</code>

See Figure 4-87 for an example of the `aci_perror` function.

```
/* Write DAS error message with usr text prepended */
if ( d_errno )
{
    aci_perror( "This text is prepended: " );
}
```

**Figure 4-87** Example of the `aci_perror` Function

---

---

## aci\_qversion

The aci\_qversion function queries the version string of ACI and DAS component. See Figure 4-88.

```
#include "aci.h"
int aci_qversion( char *aciver,
                 char *dasver )
```

**Figure 4-88** aci\_qversion Function Call

Query the version of the installed ACI and DAS component. This function allows the client to determine that the correct software component prerequisite is installed. See Table 4-38

**Table 4-38** Parameters for the aci\_qversion Function Call

Parameter	Description
aciver	displays the release of the used ACI (function library), e.g. 3.01
dasver	displays the release of the used DAS software on the AMU, e.g. 3.01

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROG

Refer to Figure 4-89 on page 4-98 for an example of the aci\_qversion function.

```

/* Check DAS and ACI version */
int rc = 0;
char szACIVersion[ ACI_MAX_VERSION_LEN ] = "";
char szDASVersion[ ACI_MAX_VERSION_LEN ] = "";
if( ( rc = aci_qversion( (char *) &szACIVersion,
                        (char *) &szDASVersion ) ) )
{
    aci_perror("Version request failed: ");
}
else
{
    printf("DAS-Version : %s\n", szDASVersion );
}
printf("ACI-Version : %s\n", szACIVersion ); /*always OK */

```

**Figure 4-89** Example of the aci\_qversion Function

## aci\_qvolrange

The aci\_qvolrange queries the list of available volsers. See Figure 4-90.


```

#include "aci.h"
int aci_qvolrange( char *startvolser,
                  char *endvolser,
                  int num_of_requested_volsers,
                  char *client_name,
                  int *number_of_returned_volsers,
                  struct aci_volserinfo *list )

```

**Figure 4-90** aci\_qvolrange Function Call

The function returns a list of volsers from the archive catalog. Figure 4-91 on page 4-99 shows the relation of the configuration to the amount of returned volsers.



**Figure 4-91** Amount of Listed Volsers

See Figure 4-92 for the aci\_volserinfo function structure.

```

struct aci_volserinfo {
    char volser[ACI_VOLSER_LEN];
    enum aci_media media_type;
    char attrib;
};

```

**Figure 4-92** Structure for the aci\_volserinfo

See Table 4-39 for a description of the parameters for the aci\_qvolserange function call.

**Table 4-39** Parameters for the aci\_qvolserange Function Call

Parameter	Description
startvolser	first volser in the range of displayed volsers
endvolser	last volser in the range of displayed volsers
num_of_requested_volser	number of volsers to be displayed
client_name	optional parameter to specify the volsers for a client other than the local one

**Table 4-39** Parameters for the aci\_qvolserange Function Call

Parameter		Description
number_of_returned_volser		number of the volsers actually found in the range
aci_volserinfo	volser	barcode number of the volser
	media_type	media type of the volser
	attrib	status of the volser

If the *startvolser* and *endvolser* parameters are set to the NULL string ("" or '\0'), a search will start at the smallest database entry defined for the client and end at the largest database entry defined for the client. However, the maximum string length of *startvolser* must be the string length of ACI\_VOLSER\_LEN

Refer to Table 4-40 on page 4-100 for an explanation of the attrib values.

For further information, refer to *aci\_view* on page 4-123.

**Table 4-40** Explanation of the Attrib Values

Name	attrib	Explanation
ACI_VOLSER_ATTRIB_MOUNTED	M	Mounted (slot empty, medium has been placed in a drive)
ACI_VOLSER_ATTRIB_EJECTED	E	ejected (slot empty, medium has been placed in the I/O unit)
ACI_VOLSER_ATTRIB_OCCUPIED	O	occupied (slot occupied, medium is in its home position)
ACI_VOLSER_ATTRIB_UNDEFINED	U	undefined (special attribute used by HCC/MVS)
ACI_VOLSER_ATTRIB_EMPTY	Y	empty (slot empty, no medium defined for the slot)
ACI_VOLSER_ATTRIB_REVERSESIDEMOUNTED	R	reverse side mounted (slot empty, optical disk has been placed in the jukebox)
ACI_VOLSER_ATTRIB_JUKEBOX	J	in jukebox (slot empty, optical disk has been placed in the jukebox)
ACI_VOLSER_ATTRIB_INITIAL	I	initial (attribute not used)

**Table 4-40** Explanation of the Attrib Values

Name	attrib	Explanation
ACI_VOLSER_ATTRIB_TEMP_HERE	T	temp here (slot occupied, medium in the problem box)
ACI_VOLSER_ATTRIB_TEMP_AWAY	A	temp away (medium temporarily not at the specified coordinates, in transit on AML/2 with double robotic controller systems)

## Return Values

- 0: The call was successful.
- 1: More data is available.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- EINVALID
- EDASINT
- ENOVOLUME
- EBADCLIENT
- ERPC
- ETIMEOUT
- ESWITCHINPROG

See Figure 4-93 for an example of the `aci_qvolsrange` function.

```

/* Query volser range */
int rc = 0;
char szBeginVolser[ ACI_VOLSER_LEN ] = "";
char szEndVolser [ ACI_VOLSER_LEN ] = "";
char szClient [ ACI_NAME_LEN ] = "";
int nCount = ACI_MAX_QUERY_VOLSRANGE;
int nActualCount = 0;
int nFor;
struct aci_volserinfo stVolsRange[ nCount ];
rc = aci_qvolstrange((char *) &szBeginVolser,
                    (char *) &szEndVolser,
                    nCount,
                    (char *) &szClient,
                    &nActualCount,
                    (struct aci_volserinfo *) &stVolsRange );
if( rc == -1 )
    aci_perror("Command failed: ");
else
{
    printf( "\nnext volser %s", szBeginVolser );
    printf( "\ncount %ld", nActualCount );
    printf( "\n%smore
data", d_errno==EMOREDATA?"":"no" );
    for( nFor = 0; nFor < nActualCount; nFor++ )
        printf( "\nvolser %s media %ld attrib %c",
                stVolsRange[ nFor ].volser,
                stVolsRange[ nFor ].media_type,
                stVolsRange[ nFor ].attrib );
}

```

**Figure 4-93** Example of the aci\_qvolstrange Function

---

---

## aci\_register

The aci\_register function registers a client. See Figure 4-94.

```
#include "aci.h"
int aci_register( char *client,
                 char *host,
                 enum aci_command action,
                 bool_t avc,
                 bool_t complete,
                 bool_t dismount,
```

**Figure 4-94** aci\_register Function Call

Clients are defined for the DAS server by the DAS configuration file. However, clients may be registered temporarily with the aci\_register function. This function registers client information and serves three purposes:

- create a new client profile
- change an existing client profile
- remove a client profile

When the DAS server is shut down, the change is lost. To permanently create, modify or delete a client, the administrator must edit the definition in the DAS configuration file. See Table 4-41.

**Table 4-41** Parameters for the aci\_register Function Call

Parameter	Description	
client	name of the client which configuration should be changed	
host	either the hostname or IP address where the client resides	
action	action with the client	
	ACI_ADD	new temporary client
	ACI_MODIFY	change an existing client
	ACI_DELETE	delete a client

**Table 4-41** Parameters for the aci\_register Function Call

Parameter	Description	
avc	true or false	option avoid volume contention (Refer to the <i>DAS Administration Guide</i> )
complete	true or false	selection between basic or complete command set (Refer to <i>Client Services</i> on page 2-4)
dismount	true or false	optional dismount; for configuring an automatic dismount without DAS command (Refer to the <i>DAS Administration Guide</i> )

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- EDASINT
- EBADHOST
- ENOSPACE
- ETIMEOUT
- ESWITCHINPROG

Refer to Figure 4-95 on page 4-105 for an example the `aci_register` function.

---



---

```

/* Modify existing client configuration */
int rc =0;
char *client = "SomeClient";
char * ipname = "CLIENT1";
enum aci_command action;
short avc;
short c;
short dism;
int i, j;
struct aci_client_entry client_entry;
rc = aci_clientstatus (client, &client_entry);
if ( !rc )
{
    action = ACI_MODIFY;
    avc = client_entry.avc;
    dism= client_entry.dismount;
    c = FALSE;

rc=aci_register(client,ipname,action,avc,c,dism);
    if( rc )
        aci_perror("Command failed: ");
    else
        printf ("Client %s updated.\n", client);
}

```

**Figure 4-95** Example of the aci\_register Function

---

---

## aci\_robhome

The aci\_robhome function sets the robot (accessor in Scalar 1000) in the AML to off-line and moves it to the home position. See Figure 4-96.

```
#include "aci.h"
int aci_robhome(char *szRobot)
```

**Figure 4-96** aci\_robhome Function Call

The call of this function sends the robot with number 'szRobot' to the home position. See Table 4-42.

**Table 4-42** Parameter for the aci\_robhome Function Call

Parameter	Description	
szRobot	the defined robot of a twin AML system	
	R1	Robot 1 of the AML (must also be used for all single AML systems)
	R2	Robot 2 of the twin AML

## Return Values

- 0: The call was successful
- -1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- ERPC
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ERETRYL
- ECANCELLED
- EDASINT
- ETIMEOUT
- ESWITCHINPROG

- 
- 
- EHICAPINUSE
  - ECOORDINATE
  - EDATABASE
  - ENOTSUPPHCMD

See Figure 4-97 for an example of the `aci_robhome` function.

```
/* Robot Homing */
int rc = 0;
rc =aci_robhome("R1");
if( rc )
{
    aci_perror( "Command failed:" );
}
else
{
    printf( "robot is now home.\n" );
}
```

**Figure 4-97** Example of the `aci_robhome` Function

## `aci_robstat`

The `aci_robstat` function starts the robot or gets the status of the robot. See Figure 4-98.

```
#include "aci.h"
int aci_robstat(char *szRobot , char *szAction)
```

**Figure 4-98** `aci_robstat` Function Call

See Table 4-43 for a description the parameters for the `aci_robstat` function call.

**Table 4-43** Parameters for the aci\_robstat Function Call

Parameter	Description	
szRobot	the defined robot of a twin AML system	
	R1	Robot 1 of AML (must also be used for all single AML system)
	R2	Robot 2 of the twin AML
szAction		
	START or start	in szRobot, set the defined Robot to on-line
	STAT or stat	ask the AMS for the status of the robots, parameter szRobot must set to NULL

## Return Values

- 0: The call was successful
- -1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- ERPC
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ERETRYL
- ECANCELLED
- EDASINT
- ETIMEOUT
- ESWITCHINPROG
- ECOORDINATE
- EDATABASE
- ENOTSUPPHCMD

Refer to Figure 4-99 on page 4-109 for an example of the aci\_robstat function.

```

/* Check robot status */
int rc;
char szRobot[ 3 ] = "R1";
char szAction[ 5 ] = "STAT";
if( ( rc = aci_robstat(szRobot, szAction))
{
    aci_perror("Version request failed: ");
}
else
{
    printf("Robstat 1 : %s\n", szSourceCoord );
    printf ("robstat sucessful\n)
}

```

**Figure 4-99** Example of the aci\_robstat Function

## ■ aci\_scratch\_get

The aci\_scratch\_get function gets a scratch volume. See Figure 4-100.

```

#include "aci.h"
int aci_scratch_get( char *subpool,
                    enum aci_media type
                    char *volser, )

```

**Figure 4-100** aci\_scratch\_get Function Call

Get a scratch volume from *subpool* and return the volume name in *volser*. The displayed volume is after the command in the database automatically set to unscratch. Refer to Table 4-44 on page 4-110.

For additional information, refer to *aci\_scratch\_set* on page 4-114, and *aci\_scratch\_unset* on page 4-116.

**Table 4-44** Parameters for the aci\_scratch\_get Function Call

Parameter	Description
subpool	stored name of the pool for scratch media in the AMU database If the volume is to be taken from a default subpool of a media type, set type to the media type of the volser and set subpool to the NULL string (" " or '\0')
type	type of media in the named subpool (Refer to <i>Media Types</i> on page 2-7)
volser	first scratch volser of the named subpool found in the AMU database, independent of the status of the volser (ejected, mounted, etc.)

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- EINVAL
- EDASINT
- ENOPOOL
- ERETRYL
- ERPC
- ETIMEOUT
- ESWITCHINPROG
- EDATABASE
- ENOTSUPPHCMD

Refer to Figure 4-101 on page 4-111 for an example of the `aci_scratch_get` function.

```

/* Get volser of new scratch media */
int rc;
char *pszPoolName = "";
enum aci_media type = ACI_3590;
char szVolser[ACI_VOLSER_LEN];
rc = aci_scratch_get (pszPoolName, type, pszVolser);
if( rc )
{
    aci_perror ("Command failed: ");
}
else
{
    printf ("Scratch volser %s found.\n", szVolser);
}

```

**Figure 4-101** Example of the `aci_scratch_get` Function

## aci\_scratch\_info

The `aci_scratch_info` function gets information about a scratch pool. See Figure 4-102.

```

#include "aci.h"
int aci_scratch_info( char *subpool,
                    enum aci_media type,
                    long *volcount,
                    long *scratchcount )

```

**Figure 4-102** `aci_scratch_info` Function Call

Query information regarding the scratch pool with the name *subpool*, or the default scratch pool, if the subpool name is not specified. The information returns the number of volsers defined in the pool and the number of volsers that have been selected as scratch. Refer to Table 4-45 on page 4-112.

For additional information, refer to *aci\_scratch\_unset* on page 4-116.

---

---

**Table 4-45** Parameters for the aci\_scratch\_info Function Call

Parameter	Description
subpool	stored name of the pool for scratch media. If the information is to be taken from a default subpool of a media type, set type to the media type of the volser and seat subpool to the NULL string ("" or '\0')
type	type of the media in the subpool (Refer to <i>Media Types</i> on page 2-7)
volcount	number of volsers in the named pool (independent of the status scratch or not defined)
scratchcount	number of the volser with the status scratch in the named subpool, independent of the status of the volser (eject, mounted, etc.)

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- EINVAL
- EDASINT
- ENOPOOL
- ERPC
- ETIMEOUT
- ESWITCHINPROG

Refer to Figure 4-103 on page 4-113 for an example of the `aci_scratch_info` function.

```

/* List scratch pool information */
int rc;
char *pszPoolName = "";
enum aci_media type = ACI_3590;
long lVolserCount, lScratchCount;
if ((rc =
        aci_scratch_info (pszPoolName, type,
                        &lVolserCount, &lScratchCount)) != 0
)
{
    aci_perror ("Command failed: ");
}
else
{
    if (strcmp (pszPoolName, "") == 0)
    {
        printf ("DEFAULT_POOL:VolserCount:%d,
                ScratchCount:%d\n",
                lVolserCount, lScratchCount);
    }
    else
    {
        printf ("%s: VolserCount: %d,
                ScratchCount: %d \n",
                pszPoolName, lVolserCount,
                lScratchCount);
    }
}
}

```

**Figure 4-103** Example of the aci\_scratch\_info Function

---

---

## aci\_scratch\_set

The `aci_scratch_set` function sets volume status to scratch. See Figure 4-104.

```
#include "aci.h"
int aci_scratch_set( char *subpool,
                    enum aci_media type,
                    char *volser )
```

**Figure 4-104** aci\_scratch\_set Function Call

Set volume named *volser* of media type *type* to *scratch* status in the scratch pool named *subpool*.

The subpool is created if it does not exist. If a subpool is not specified and set to the NULL string ("" or '\0'), the default pool will be used.

If the volume is already defined to another pool, an error (EOTHERPOOL) will be returned. If this is a new scratch volume, *subpool* will be the pool from which the volume can be selected using the `aci_get_scratch` function. See Table 4-46.

**Table 4-46** Parameters for the `aci_scratch_set` Function Call

Parameter	Description
subpool	the stored name of the pool for scratch media in the AMU database. If the information is to be taken from a default subpool of a media type set type to the media type of the volser and set subpool to the NULL string ("" or '\0')
type	type of the media in the subpool (Refer to <i>Media Types</i> on page 2-7)
volser	set volser to scratch in the named subpool in the AMU database (only possible, if the volser is already defined in the AMU database but the status of the volser (ejected, mounted, etc.) is not relevant).

 **Attention**

**Data stored on the media may be lost. The command automatically sets the specified medium as a scratch medium (without a confirmation prompt). The data on the medium is overwritten by the next scratch mount command.**



The command will be rejected with the message EOTHERPOOL if the medium already exists in another scratch pool.

For additional information, refer to *aci\_scratch\_unset* on page 4-116.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- EINVAL
- EDASINT
- ENOPOOL
- ERPC
- ETIMEOUT
- ESWITCHINPROG
- EDATABASE
- ENOTSUPPHCMD

See Figure 4-105 for an example of the `aci_scratch_set` function.

```
/* Add volume to default scratch pool */
int rc;
char *pszPoolName = "";
char *pszVolser = "VOL001";
enum aci_media type = ACI_3590;
rc = aci_scratch_set(pszPoolName, type, pszVolser);
if( rc )
{
    aci_perror ("aci_scratch_set failed");
}
else
{
    printf("Scratch volume %s set.\n ",
    pszVolser);
}
```

Figure 4-105 Example of the `aci_scratch_set` Function

---

---

## aci\_scratch\_unset

The `aci_scratch_unset` function resets the scratch status of a volume. See Figure 4-106.

```
#include "aci.h"
int aci_scratch_unset( char *subpool,
                      enum aci_media type,
                      char *volser )
```

**Figure 4-106** aci\_scratch\_unset Function Call

Reset the status of volume named *volser* in the scratch pool named *subpool* from scratch to non-scratch media and remove the *volser* from *subpool*. If *subpool* is set to the NULL string ("" or '\0') the default pool will be used. If the requested volume is the last volume in the pool, the pool will be deleted. See Table 4-47.

For additional information, refer to *aci\_scratch\_set* on page 4-114.

**Table 4-47** Parameters for the `aci_scratch_unset` Function Call

Parameter	Description
subpool	the stored name of the pool for scratch media in the AMU database. If the information is to be taken from a default subpool of a media type set <i>type</i> to the media type of the <i>volser</i> and set <i>subpool</i> to the NULL string ("" or '\0')
type	type of the media in the subpool (Refer to <i>Media Types</i> on page 2-7)
volser	set <i>volser</i> to scratch in the named subpool in the AMU database (only possible, if the <i>volser</i> is already defined in the AMU database but the status of the <i>volser</i> (ejected, mounted, etc.) is not relevant).

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- EINVALID
- EDASINT
- ENOPOOL
- ERPC
- ETIMEOUT
- ESWITCHINPROG
- EDATABASE
- ENOTSUPPHCMD

See Figure 4-107 for an example of the `aci_scratch_unset` function.

```
/* Change volume's scratch status */
int rc;
char *pszPoolName = "";
enum aci_media type = ACI_3590;
char *pszVolser = "VOL001"

rc = aci_scratch_unset(pszPoolName, type, pszVolser);
if( rc )
{
    aci_perror ("aci_scratch_unset failed");
}
else
{
    printf ("Volser %s removed from
scratchpool.\n",
           pszVolser);
}
```

**Figure 4-107** Example of the `aci_scratch_unset` Function

---

---

## aci\_shutdown

The `aci_shutdown` function shuts down the DAS software. See Figure 4-108.

```
#include "aci.h"
int aci_shutdown (char *now)
```

**Figure 4-108** aci\_shutdown Function Call

This function shuts down the DAS server. Once the request has been accepted, no other request will be accepted. A restart of the DAS server is necessary to resume DAS operations. See Table 4-48.

**Table 4-48** Parameter for the `aci_shutdown` Function Call

Parameter	Description
now	By default, DAS waits for outstanding requests to be completed before termination. It however, the <code>now</code> parameter or the <code>now</code> string is specified, the shut down is immediate.

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EDASINT
- ESWITCHINPROG

Refer to Figure 4-109 on page 4-119 for an example of the `aci_shutdown` function.

```

/* Shut down DAS operation */
int rc;
char *now = NULL;
if ((rc = aci_shutdown(now))
{
    aci_perror("Shut down failed:");
}
else
{
    printf("Shut down successful.\n");
}

```

Figure 4-109 Example of the aci\_shutdown Function

## aci\_snmp

The aci\_snmp function sends SNMP messages. See Figure 4-110.

```

#include "aci.h"
int aci_snmp (char *Msg)

```

Figure 4-110 aci\_snmp Function Call

See Table 4-49.

Table 4-49 Parameter for the aci\_snmp Function Call

Parameter	Description
Msg	defines the SNMP message



Only supported by the Scalar DLC software.

## Return Values

- 0: The call was successful.
- -1: The call failed.

---

---

The external variable `d_errno` is set to one of the following DAS error codes:

- ERPC
- EINVAL
- ETIMEOUT
- ESWITCHINPROG
- EBADCLIENT
- ENOTSUPPHCMD

## aci\_switch

The `aci_switch` function switches the passive AMU to active. See Figure 4-111.

```
#include "aci.h"
int aci_switch (char *Switch)
```

**Figure 4-111** aci\_switch Function Call

Allow the second AMU to be used without manual intervention, if the first AMU-PS is down. An installed and running Dual-AMU is necessary for this function. See Table 4-50.

**Table 4-50** Parameter for the `aci_switch` Function Call

Parameter	Description
Switch	defines the priority of the switch
	-n normal switch, allowed to complete all running commands, and synchronization of the database before switching will start
	-f force switch, immediately without any synchronization to the second AMU, but necessary if the first AMU is already down

### **Caution**

Only use the `-f` option if the `-n` option is no longer functioning. There is a risk that anomalies may be caused in the AMU database.

---

---

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- ENOTAUTH
- ERPC
- EINVAL
- EDASINT
- ETIMEOUT
- EAMUCOMM
- EHICAPINUSE
- ESWITCHINPROG
- ENOTSUPPHCMD

See Figure 4-112 for an example of the `aci_switch` function.

```
/* Switch to the Dual AMU */
int rc;
char *Switch = "-n";
if ((rc = aci_switch(Switch))
{
    aci_perror("Swicht actual not possible:");
}
else
{
    printf("Now the Dual AMU is active.\n");
}
```

**Figure 4-112** Example of the `aci_switch` Function

---

---

## aci\_unload

The aci\_unload function presses one or more buttons on a drive in the AML. See Figure 4-113.

```
#include "aci.h"
int aci_unload(char *szDrive)
```

**Figure 4-113** aci\_unload Function Call

See Table 4-51 for a description of the parameter for the aci\_unload function.

**Table 4-51** Parameter for the aci\_unload Function Call

Parameter	Description
szDrive	Name of the drive for unload, defined in Description in the AMS configuration

## Return Values

- 0: The call was successful
- 1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- EAMU
- EAMUCOMM
- EROBOTCOMM
- EPROBDEV
- ERPC
- EINVALID
- EDASINT
- ETIMEOUT
- ESWITCHINPROG
- EINVALIDDEV
- ENOROBOT
- EDATABASE
- ENOTSUPPHCMD
- EAREAEMPTY
- EPROBDEV

---

---

## aci\_view

The `aci_view` function is used to view a database entry for a volume. See Figure 4-114.

```
#include "aci.h"
int aci_view( char *volser,
             enum aci_media type,
             struct aci_volume_desc *desc )
```

**Figure 4-114** aci\_view Function Call

Return the database entry for the volume named *volser* of media type *type*. The database entry is returned in the `aci_volume_desc` structure. See Figure 4-115.

For additional information, refer to *aci\_qvolstrange* on page 4-98, and *aci\_inventory* on page 4-81.

```
struct aci_volume_desc {
    char coordinate[ACI_COORD_LEN];
    char owner;
    char attrib;
    char type;
    char volser[ACI_VOLSER_LEN]
    char vol_owner;
    int use_count;
    int crash_count;
};
```

**Figure 4-115** Volser Information Contained in the `aci_volume_desc` Structure

The structure returns the AMU archive catalog, which robot owns the volume, a volume attribute of mounted, ejected, occupied, or undefined, and the volser media type. Refer to Table 4-51 on page 4-122.

**Table 4-52** Parameters for the aci\_view Function Call

Parameter	Description	
volser	volser specifying the medium for which information is being queried	
type	media type to which the volser belongs Refer to <i>Media Types</i> on page 2-7	
aci_volume_desc	structure with the returned data from the AMU database table COORDINATES	
	coordinate	10-digit logical coordinate specifying the slot (Refer to the <i>AMU Reference Manual</i> )
	owner	number of the robot which can access the home coordinate of the named volser (1 = robot 1, 2 = robot 2, 3= both robots)
	attrib	current status of the slot (attributes) (Refer to Table 4-54 on page 4-125)
	type	type of slot, but not the media type (coordinate in the archive) (See Table 4-53)
	volser	queried volser (search criterion in the AMU database)
	vol_owner	not used
	use_count	number of accesses to the slot (not volser) by the robotic controller
	crash_count	not used

See Table 4-53 for an explanation of the table types.

**Table 4-53** Table Types

attrib	Explanation
A	AMU Dynamic (dynamic storage locations in the AML system)
S	storage (dynamic storage locations in the AML system)
N	clean (cleaning media storage location)

---

---

See Table 4-54 for an explanation of the table attributes.

**Table 4-54** Table Attributes

<b>attrib</b>	<b>Explanation</b>
O	occupied (slot occupied, medium is in its home position)
E	ejected (slot empty, medium has been placed in the I/O unit)
M	mounted (slot empty, medium has been placed in a drive)
I	initial (attribute not used)
J	in jukebox (slot empty, optical disk has been placed in the jukebox)
R	reverse side mounted (slot empty, optical disk has been placed in a drive)
Y	empty (slot empty, no medium defined for the slot)
U	undefined (special attribute, used by HCC/MVS)
T	temp here (slot occupied, medium in the problem box)
A	temp away (medium temporarily not at specified coordinated, in transit on AML/2 with double robotic controller systems)

## Return Values

- 0: The call was successful.
- -1: The call failed.

The external variable `d_errno` is set to one of the following DAS error codes:

- EAMU
- EAMUCOMM
- EINVALID
- EDASINT
- ENOVOLUME
- ERPC
- ETIMEOUT
- ESWITCHINPROG

Refer to Figure 4-116 on page 4-126 for an example of the `aci_view` function.

```

/* Get volume information */
int rc;
enum aci_media type = ACI_3590;
char *volser = "";
struct aci_vol_desc desc;
if ( rc = aci_view(volser, type, &desc ) )
{
    aci_perror("view failed");
}
else
{
    printf("Volser=%s Type=%c Attrib=%c\n\tcoordinate
=s\n"
          "\tuse count = %d\n",
          desc.volser,
          desc.type,
          desc.attrib,
          desc.coord,
          desc.use_count;
}

```

**Figure 4-116** Example of the aci\_view Function

## aci\_volser\_inventory

The aci\_volser\_inventory function inventories the volsers within the AML. See Figure 4-117.

```

#include "aci.h"
int aci_volser_inventory(char *pszVolser, int status)

```

**Figure 4-117** aci\_volser\_inventory Function Call

Start the comparison between the physical barcode volser and the AMU database and update the AMU database as necessary. Refer to Table 4-55 on page 4-127.

**Table 4-55** Parameters for the aci\_volser\_inventory Function Call

Parameter	Description	
pszVolser	Pointer to an individual volser	
status	Indicator to determine manipulate of the database	
	ACI_INVNT_NOTUPDT	0 = do not update the database
	ACI_INVNT_UPDT	0 = update the database

## Return Values

- 0: The call was successful
- -1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- ERPC
- EINVALID
- ENOVOLUME
- EPROBVOL
- EAMU
- EAMUCOMM
- EROBOTCOMM
- EDASINT
- ERETRYL
- ENOTFOUND
- ECANCELLED
- ETIMEOUT
- ESWITCHINPROG
- EHICAPINUSE
- ECOORDINATE
- EBARCODE
- ENOTSUPPHCMD

---

---

## aci\_volseraccess

The aci\_volseraccess function sets ownership of a volser or range of volsers. See Figure 4-118.

```
#include "aci.h"
int aci_volseraccess(char *ClientName ,
                    char *VolserRange,
                    enum aci_volser_status status)
```

**Figure 4-118** aci\_volseraccess Function Call

Modify allocation status of a volser for a specified client. Refer to Table 4-56 .

**Table 4-56** Parameters for the aci\_volseraccess Function Call

Parameter	Description	
clientName	name of the client which authorization of a volser range should be changed	
VolserRange	Range of volser for the modification in one of the following form: <ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers separated by commas</li><li>• a range of volsers separated by a hyphen</li></ul>	
status	new authorization status of the drive	
	ACI_UP	reservation of named volser for the client
	ACI_DOWN	Deleted reservation of named volser for the client. Only complete ranges can be deleted not subranges from another range

## Return Values

- 0: The call was successful
- -1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- 
- 
- EUPELSE
  - ERPC
  - EINVALID
  - ENOVOLUME
  - EDASINT
  - EBADCLIENT
  - ENOTAUTH
  - ETIMEOUT
  - ESWITCHINPROG
  - EUPOWN

## aci\_volserstatus

The `aci_volserstatus` function queries ownership of the volser. See Figure 4-119.

```
#include "aci.h"
int aci_volserstatus(char *ClientName,
                    int *num,
                    char *VolserRange,
                    struct aci_volser_entry *VolserEntry[ACI_MAX_VOLSER_ENTRIES])
```

**Figure 4-119** aci\_volserstatus Function Call

Returns the status of volsers which are set to UP for the client with name `clientname`. If `clientname` is the NULL string, the call return status on all volsers specified in `VolserRange`. The status is returned in `VolserEntry`, an array of pointers to `aci_volser_entry` structure.

The structure `aci_volser_entry` is stated, in `aci.h`, see Figure 4-120

```
struct aci_volser_entry {
    char ClientName[ACI_NAME_LEN];
    char VolserStatus[ACI_VOLSERSTATUS_LEN];
    char volser[ACI_VOLSER_LEN];
    enum aci_media media_type;
}
```

**Figure 4-120** aci\_volser\_entry Structure

See Table 4-57 for a description of the parameters for the aci\_volserstatus function call.

**Table 4-57** Parameters for the aci\_volserstatus Function Call

Parameter	Description	
ClientName	name of the client which allocated volser should be displayed	
num	number of volser ranges	
VolserRange	Range of the allocated Volser in on of the following forms: <ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers separated by commas</li><li>• a range of volsers separated by a hyphen</li></ul>	
aci_volser_entry	details to the allocated range	
	ClientName	Owner of the volser
	VolserStatus	UP
	volser	allocated volser range
	media_type	media type to which the volser belongs Refer to <i>Media Types</i> on page 2-7

## Return Values

- 0: The call was successful
- -1: The call failed

The external variable d\_errno is set to one of the following DAS error codes

- EBADCLIENT
- ERPC
- EINVAL
- EDASINT
- ETIMEOUT
- EHCAPINUSE
- ESWITCHINPROG

# 5

## DAS ACI 3.0 Asynchronous Support Layer

Overview .....	5-3
How It Works .....	5-3
Sadmin Sample Application .....	5-3
Sadmin Syntax .....	5-4
Contents of the Async Support Layer Library .....	5-4
aci_async_add() .....	5-5
Parameters .....	5-5
das_mount .....	5-6
das_dismount .....	5-7
das_force .....	5-7
das_insert .....	5-8
das_eject .....	5-9
das_eject_complete .....	5-10
Return Values .....	5-11
aci_async_create() .....	5-13
Return Values .....	5-13
aci_async_find() .....	5-14
Return Values .....	5-15
aci_async_free() .....	5-16
Return Values .....	5-16
Macros .....	5-16
aci_mount .....	5-16
Return Values .....	5-17
aci_dismount .....	5-17
Return Value .....	5-17
aci_force .....	5-17
Return Values .....	5-18
aci_insert .....	5-18
Returned values .....	5-18



---

---

aci_eject .....	5-19
Return Values .....	5-19
aci_eject_complete .....	5-19
Return Values .....	5-20
Response Technique .....	5-21
Setup .....	5-21
Signal Handler Routine .....	5-22
Data structures .....	5-23
aci_async_entry .....	5-23
Parameter Data (Parms Structure) .....	5-25
Response Data (Structure) .....	5-26
st_response .....	5-26
st_mount_parms .....	5-26
st_insert_response .....	5-27

---

---

## Overview

Asynchronous Support Layer library works as a filter between existing ACI libraries (version 3 or later) and the client application, which wants to issue asynchronous ACI calls. Since the native ACI interface is synchronous, a client had to wait for the completion of the request. Now using special programming techniques, developers who want to use ACI in an asynchronous manner can use the Asynchronous Support Layer library of this purpose.

## How It Works

In early ACI releases, all programmers using the ACI library, had to consider that any ACI call issued by the application would wait until the work is complete. Now, each incoming request is stored into the shared memory area and each request is executed in forked process.

After the application issues a request, it is given a request ID. The request ID is actually the process ID of the forked child process. The operating system does not allow two processes with the same ID. The request ID ensures the uniqueness of each ID.

After the request is completed, it stores the results in the appropriate location in that shared table and terminates. To retrieve the information back to the client, define a special function that terminates (SIGCHLD) a child process. This routine could also transmit the data into an application internal data buffer and free the entry in the table. Doing this ensures that the entry (process) ID will never be repeated in the shared memory table.

## Sadmin Sample Application

For the convenience and ease of understanding the programming techniques required to write the asynchronous ACI applications, the sadmin sample application is provided. This application represents a cut version of the standard dasadmin application. It the following commands:

- mount: mount a volser
- dismount: dismount the volser or force the drive to dismount
- insert: insert volsers

- 
- 
- eject: eject/elect complete volsters
  - allocv: allocate volser
  - allocd: allocate drive
  - script: run the commands from a script file

This application can run in both single command and scripting modes. To stop this application, press <Ctrl>+<C> or use the **KILL** command.

## Sadmin Syntax

The syntax of the sadmin sample application has two general forms:

- sadmin <command> [-h] | [[<arg1>] [<arg2>] ... [<argN>]]
- sadmin script < [<script file name>]

In the first case, sadmin is running in single command mode. In the second case, it is executing the specifically prepared script. The script contains all usual sadmin commands, written in same syntax. For example:

```
mount -t DECDLT 000030 DE02
```

```
eject -t OD-Thick P702010101-P702010122 E02
```

```
dism -d DE02
```

Each line must be EOL terminated. Sadmin responds with a help message when run without arguments. The script command isn't included in the message.

## Contents of the Async Support Layer Library

Currently the Asynchronous Support Layer library supports only the following commands:

- MOUNT
- DISMOUNT
- FORCE
- INSERT
- EJECT
- EJECT COMPLETE

The asynchronous API consists of the following four functions:

---



---

<code>aci_async_add</code> -	adds an entry in the shared memory area
<code>aci_async_create</code> -	creates and initializes the shared memory area
<code>aci_async_find</code> -	finds required shared memory table entry
<code>aci_async_free</code> -	frees required shared memory table entry

There is also a header file for C developers, *aci\_async.h*, defining all the required structures and macros for development of software using the ACI asynchronous support.

## `aci_async_add()`

The `aci_async_add()` function adds a new `aci_async_entry` element to the shared memory array. See Figure 5-1.

```
#include "aci_async.h"
#include "aci_xdr.h"
aci_async_entry* aci_async_add(int aci_func, ...);
```

**Figure 5-1** Example of a Generic `aci_async_add()` Function

## Parameters

The `aci_func` parameters are as follows:

- `das_mount`
- `das_dismount`
- `das_force`
- `das_insert`
- `das_eject`
- `das_eject_complete`

---

---

## **das\_mount**

The `aci_async_add` function with the `das_mount` parameter mounts a volume in a drive. See Figure 5-2

```
aci_asyncn_add (das_mount, *volser, *type, *drive)
```

**Figure 5-2** `aci_async_add` Function with the `das_mount` Parameter

Mount the volume named *volser* of media type *type* in the drive named *drive*. The volume will then be available to the requesting client. See Table 5-1.

**Table 5-1** Parameters for the `das_mount` Parameter

Parameter	Description
volser	Volser which should be mounted (also foreign volser possible after the cataloging with carf)
type	Media type of the named volser Refer to <i>Media Types</i> on page 2-7
drive	Name of the drive which should be mounted. If the drive is set to the NULL string, the drive is automatically selected from the list of available drives to the client. The client host must have Automatic Volume Recognition (AVR) active to detect the mount.

Refer to Figure 5-3 on page 5-6 for an example of the `aci_async_add` function with the `das_mount` parameter.

```
aci_async_add (DAS_MOUNT, "000030", C3480, "DE02")
```

**Figure 5-3** Example of the `aci_async_add` Function with the `das_mount` Parameter

---

---

## **das\_dismount**

The `aci_async_add` function with the `das_dismount` parameter dismounts a volume. See Figure 5-4.

```
aci_async_add (das_dismount, *volser, *type)
```

**Figure 5-4** `aci_async_add` Function with the `das_dismount` Parameter

Dismount the volume *volser* of defined media type from its drive. The drive is identified by the DAS software.

For additional information, refer to *das\_mount* on page 5-6.



**Retries can be configured in the config file or in the AMS configuration.**

See Table 5-2 for a description of the parameters for the `aci_async_add` function with the `das_dismount` parameter.

**Table 5-2** Parameters for the `das_dismount` Parameter

Parameter	Description
volser	volser that is to be moved from a drive to the original position in the AML
type	media type of the named volser Refer to <i>Media Types</i> on page 2-7

## **das\_force**

The `aci_async_add` function with the `das_force` parameter dismounts any cartridge from a specific drive. See Figure 5-5.

```
aci_async_add (das_force, *drive)
```

**Figure 5-5** `aci_async_add` Function with the `das_force` Parameter

Force a dismount from a drive named *drive*, regardless of which volser is in the drive. Refer to Table 5-3 on page 5-8.

For additional information, refer to *das\_dismount* on page 5-7, and *das\_mount* on page 5-6.

**Table 5-3** Parameter for the das\_force Parameter

Parameter	Description
drive	name of the drive for the dismount

## das\_insert

The aci\_async\_add function with the das\_insert parameter inserts volumes into the AML. See Figure 5-6.

```
aci_async_add (das_insert, *insert_area, *volser_range,  
*type)
```

**Figure 5-6** aci\_async\_add Function with the das\_insert Parameter



**This function is for compatibility. Please use the aci\_insertgen function.**

The cartridges which are actually located in the insert area of the AML and registered by the AMU (automatically inventoried after closing the area) will be inserted.

- Volsers which already have a entry in the AMU database, will be moved to this position.
- Volsers which have no entry in the AMU database, will be moved to the first free slot (AMU database Attribute: "Empty" of this media type of the Type AMU-Dynamic)
- Cartridges with an invalid volser (barcode not readable) will moved to the problembox.

See Table 5-4 for a description of the parameters for the aci\_insert function call.

**Table 5-4** Parameters for the das\_insert Parameter

Parameter	Description
insert_area	Logical insert range of the Insert/Eject unit of the AML in the AMS (e.g. I03)
volser_range	The volumes found in the insert_area are returned in the volser_ranges array of strings, where each volser is separated by a comma. Each range is ACI_RANG_LEN long and there are up to ACI_MAX_RANGES ranges. An empty string indicates the end of the ranges
type	media type of the volser in the insert area Refer to <i>Media Types</i> on page 2-7



Use the insert2 function instead of this command. This function experiences difficulties with large I/O units with long volsers (16-digit) since the buffer for displaying the inserted volser is restricted. For compatibility reasons this function continues to be supported.

## das\_eject

The aci\_async\_add function with the das\_eject parameter ejects a range of volumes from the AML. See Figure 5-7.

```
aci_async_add (das_eject, *eject_area, *volser_ranges,  
*type)
```

**Figure 5-7** aci\_async\_add Function with the das\_eject Parameter

Eject the volumes in *volser\_range* to the *eject\_area*. The media type of the volumes must match that of the *eject\_area*. Set *type* to the media type of the *volser\_range*. See Table 5-5.

**Table 5-5** Parameters for the `das_eject` Parameter

Parameter	Description
<code>eject_area</code>	Logical area defined in AML, where the cartridges should be ejected
<code>volser_ranges</code>	<ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers separated by commas</li><li>• a range of volsers separated by a hyphen</li></ul>
<code>types</code>	media type of the named volser Refer to <i>Media Types</i> on page 2-7

The database entry for the volume is not deleted, and the position in the AML that the volume occupied remains reserved for insertion of a volume with a matching volser. This could be useful if the volume is temporarily ejected and will be inserted in the near future. In such case, the position remains reserved and the volume's location within the AML does not change.

The eject will stop, when the eject area is full. The request will either be cancelled or completed after the area is marked empty depending on the `DAS_EJECTAREAFULL` environment variable.

## **das\_eject\_complete**

The `asi_async_add` function with the `das_eject_complete` parameter ejects volumes and removes the database entries. See Figure 5-8.

```
aci_async_add (das_eject_complete, eject_area,  
volser_range, type)
```

**Figure 5-8** `aci_async_add` Function with the `das_eject_complete` Parameter

Eject the volumes in `volser_range` to the `eject_area`. The media type of the volumes must match that of the `eject_area`. Set `type` to the media type of the `volser_range`. The database entry for the volume is deleted, and the position in the AML that the volume occupied becomes free. This could be useful if the volume is to be placed in long-term archive storage or more

---

---

space is needed in the AML. If the volume is re-inserted into the AML, it is stored in the next available position, and it probably will not occupy the previous position. The volume is re-inserted in the same position only if `das_eject` is used. See Table 5-6 for a description of the parameters for the `das_eject_complete` parameter.

**Table 5-6** Parameters for the `das_eject_complete` Parameter

Parameter	Description
<code>eject_area</code>	Logical area defined in AMS, where the cartridges should be ejected
<code>volser_range</code>	<ul style="list-style-type: none"><li>• a single volser</li><li>• multiple volsers separated by commas</li><li>• a range of volsers separated by a hyphen</li></ul>
<code>types</code>	media types of the named volser Refer to <i>Media Types</i> on page 2-7

The eject will stop, when the eject area is full. Depending on the `DAS_EJECTAREAFULL` environment variable, the request will either be cancelled or completed after the area is marked empty.

For additional information, refer to *das\_eject* on page 5-9, and *das\_insert* on page 5-8.

## Return Values

The call was successful if a pointer to the newly added entry is returned.

The call failed if zero is returned.

Refer to Figure 5-9 on page 5-12 for an example of the `aci_async` function call.

```

. . .
/*
 * sadmin sample application, dasadmin.c file
 * aci_async.h, ACI_INSERT macro
 */
aci_async_entry *async_entry;
if ((async_entry = aci_async_add(
DAS_INSERT,
insert_area,
volser_ranges,
type ) ) != 0)
{
    if ((async_entry->pid = fork()) == 0)
    {
        /* map the current process virtual memory to the
shared buffer */
        if ((int) (async_table =
(void*)shmat(async_table_desc, 0, 0)) == -1)
        {
            d_errno = ENOSHARED;
            strcpy(d_text, "shmat failed");
        }

        res = aci_insert(insert_area, volser_ranges, type);

        async_entry->d_errno = d_errno;
        strcpy(async_entry->d_text, d_text);

        shmdt(async_table);
        exit(res);
    }
}
. . .

```

**Figure 5-9** Example of an aci\_async\_add Function

---

---

## aci\_async\_create()

The aci\_async\_create function creates a shared memory array of the *entry\_num* size, that will hold the requests sent. See Figure 5-10

```
#include "aci_async.h"
aci_async_entry* aci_async_create(long entry_num);
```

**Figure 5-10** aci\_async\_create Function Call

See Table 5-7 for a description of the parameter for the aci\_async\_create function.

**Table 5-7** Parameter for the aci\_async\_create Function

Parameter	Description
entry_num	entry_num - number of entries allocated to hold the request information.

## Return Values

The call was successful if a pointer to the start of shared memory array mapped into virtual address space of the process.

The call failed zero is returned.



**The entry\_num value and pointer returned are stored globally in the Asynchronous Layer Library for later use. You must call this function only once. Repeated calls will destroy global values and will not free previously allocated shared memory arrays.**

Refer to Figure 5-11 on page 5-14 for an example of the aci\_async\_create function.

```

. . .
/*
 * sadmin sample application, dasadmin.c file
 * creating a table in shared memory - 50 entries
 */
if( ( async_entry = aci_async_create( 50L ) ) == 0 )
{
    aci_perror( "create async failed" );
    return 1;
}
. . .

```

**Figure 5-11** Example if the aci\_async\_create Function

## aci\_async\_find()

The aci\_async\_find function looks for the appropriate aci\_async\_entry in shared memory array. If an entry has the same value in the *pid* field as *pid* parameter it is returned. See

```

#include "aci_async.h"
aci_async_entry* aci_async_find(pid_t pid);

```

**Figure 5-12** aci\_async\_find Function Call

See Table 5-8 for a description of the parameter for the aci\_async\_find function.

**Table 5-8** Parameter for the aci\_async\_find Function

Parameter	Description
pid	identifies the request entry in the shared memory array

---

---

## Return Values

The call was successful if a pointer to the found value is returned.

The call failed if zero is returned

The structure of the `aci_async_entry` uses a `pid_t` type member `pid` as a unique identifier of an entry. When calling several asynchronous calls at a time the system can assign the same process id to a new process when a previous call has terminated. This could cause duplicate values the in `pid` fields of shared memory array entries. Refer to *Response Technique* on page 5-21.

See Figure 5-13 for an example of the `aci_async_find` function.

```
. . . .
/*
 * sadmin sample application. wait_for_child.c file
 */
if ((async_entry = aci_async_find(pid)) != 0)
{
    printf("results: getting results...\n");
    switch(async_entry->aci_func)
    {
        case DAS_MOUNT:
            . . . .
        }

    aci_async_free(async_entry);
    printf("results: results done...\n");
}
. . . .
```

**Figure 5-13** Example of the `aci_async_find` Function

---

---

## ■ aci\_async\_free()

The `aci_async_free` function clears the `async_table` entry. See Figure 5-14.

```
#include "aci_async.h"
void aci_async_free(aci_async_entry* async_entry);
```

**Figure 5-14** aci\_async\_free Function Call

**Table 5-9** Parameters for the `aci_async_free` Function

Parameter	Description
<code>async_entry</code>	pointer to an <code>aci_async_entry</code> that should be cleaned

## ■ Return Values

None

This call only clears the `pid` field in the appropriate `aci_async_entry` structure.

## ■ Macros

The `aci_async.h` header file contains macros that substitute all the techniques, required to issue an asynchronous ACI call. However, they require some additional conditions provided by programmer.

## ■ aci\_mount

The `aci_mount` function mounts a volume in a drive. See Figure 5-15

```
#include "aci_async.h"
ACI_MOUNT(volser, type, drive_name)
```

**Figure 5-15** Example of `aci_mount` Asynchronous ACI Call

---

---

All the parameters must comply with the rules for `aci_mount` function call.

The local variables *int res* must be defined before using this macro.

## Return Values

The `d_errno` and `d_text` globals are copied to `d_errno` and `d_text` fields of shared memory array entry. The process is terminated by the `exit()` call with the *res* exit code. If there are problems with shared memory attachment, `d_errno` global will be set to `ENOSHARED`.

## `aci_dismount`

The `aci_dismount` function dismounts a volume. See Figure 5-16.

```
#include "aci_async.h"
ACI_DISMOUNT(volser, type)
```

**Figure 5-16** `aci_dismount` Asynchronous ACI Call

All the parameters must comply with the rules for the `aci_dismount` function call.

The local variable *int res* must be defined before using this macro.

## Return Value

The `d_errno` and `d_text` globals are copied to `d_errno` and `d_text` fields of shared memory array entry. The process is terminated by the `exit` call with the *res* exit code. If there are problems with shared memory attachment, `d_errno` global will be set to `ENOSHARED`.

## `aci_force`

The `aci_force` function dismounts any cartridge from a specific drive. Refer to Figure 5-17.

```
#include "aci_async.h"
ACI_FORCE(drive)
```

**Figure 5-17** aci\_force Asynchronous ACI Call

All the parameters must comply with the rules for the aci\_force function call.

The local variable *int res* must be defined before using this macro.

## Return Values

The d\_errno and d\_text globals are copied to d\_errno and d\_text fields of shared memory array entry. The process is terminated by the *exit* call with the *res exit* code. If there are problems with shared memory attachment, d\_errno global will be set to ENOSHARED.

## aci\_insert

The aci\_insert function inserts volumes into the AML. See Figure 5-18.

```
#include "aci_async.h"
ACI_INSERT(insert_area, volser_ranges, type)
```

**Figure 5-18** aci\_insert Asynchronous Function Call

All the parameters must comply with the rules for the aci\_insert function call.

The local variable *int res* must be defined before using this macro.

## Returned values

The d\_errno and d\_text globals are copied to the d\_errno and d\_text fields of the shared memory array entry. The process is terminated by the *exit* call with the *res exit* code.

---

---

## **aci\_eject**

The `aci_eject` function ejects a range of volumes from the AML. See Figure 5-19.

```
#include "aci_async.h"
ACI_EJECT(eject_area, volser_range, type)
```

**Figure 5-19** `aci_eject` Asynchronous Function Call

All the parameters must comply with the rules for the `aci_eject` function call.

The local variable *int res* must be defined before using this macro.

## **Return Values**

The `d_errno` and `d_text` globals are copied to the `d_errno` and `d_text` fields of the shared memory array entry. The process is terminated by the *exit* call with the *res exit* code. If there are problems with the shared memory attachment, the `d_errno` global will be set to `ENOSHARED`.

## **aci\_eject\_complete**

The `aci_eject_complete` function ejects volumes and removes the database entries. See Figure 5-20.

```
#include "aci_async.h"
ACI_EJECT_COMPLETE(eject_area, volser_range, type)
```

**Figure 5-20** `aci_eject_complete` Asynchronous Function Call

All the parameters must comply with the rules for the `aci_eject_complete` function call.

The local variable *int res* must be defined before using this macro.

---

---



## Return Values

The `d_errno` and `d_text` globals are copied to the `d_errno` and `d_text` fields of the shared memory array entry. The process is terminated by the `exit` call with the *res exit* code. If there are problems with the shared memory attachment, the `d_errno` global will be set to `ENOSHARED`.

---

---

## Response Technique

This section describes the most desirable response processing technique.

### Setup

The following code should be executed upon startup. This code installs a signal handler, which will be automatically run every time one of the child processes terminates. At this point retrieve the results, place them into internal data structures and free the shared memory array entry. See Figure 5-21.

```
. . .
/* dasadmin sample application, dasadmin.c file */
int ( *func )();
struct sigaction action;
aci_async_entry *async_entry;

action.sa_handler = wait_for_child;
sigemptyset(&action.sa_mask);
action.sa_flags = 0;

if (sigaction(SIGCHLD, &action, (struct sigaction*)0)
== (int)SIG_ERR)
{
    fprintf( stderr, "Unable to set signal handler for
SIGCHLD\n");
    return( 1 );
}
. . .
```

**Figure 5-21** Setup Signal Handler

---

---

## Signal Handler Routine

The following code processes the result of child process work. At the point this function is run, the results are placed in the shared memory array entry, and developer should program the logic that will take the results from there and place them somewhere else.

The dasadmin sample application puts all the data into the standard output. See Figure 5-22.

```
/* dasadmin sample application, wait_for_child.c file */
void wait_for_child(int sig_no)
{
    pid_t pid;
    aci_async_entry* async_entry;
    int exit_code;
    int i;

    pid = wait(&exit_code);

    if ((async_entry = aci_async_find(pid)) != 0)
    {
        printf("results: getting results...\n");
        . . .
    }
}
```

**Figure 5-22** dasadmin Sample Application

---

---

## Data structures

This section provides an overview of the data structures used in asynchronous ACI data interchange. The shared memory array consists of several entries of type `aci_async_entry`. The exact number should be set in the `aci_async_create` call. This consists of three sections:

- Common information (`pid`, `aci_func`, `d_errno`, `d_text` member variables)
- Parameter data (`parms` structure)
- Response data (`response` structure)

### `aci_async_entry`

Refer to Figure 5-23 on page 5-24 for the common structure, that a shared memory array contains.

```

struct _aci_async_entry
{
    pid_t pid;                               /* process id, -1
means slot is empty */
    int aci_func;                             /* DAS_MOUNT,
DAS_DISMOUNT, DAS_FORCE,
DAS_INSERT, DAS_EJECT,
DAS_EJECT_COMPLETE
*/
    int d_errno;                             /* DAS error code
*/
    char d_text [DAS_SZ_MSG_LEN]; /* error message
*/

    union _parms                             /*
parameters data */
    {
        async_drive_parms st_drive_parms; /* mount,
dismount, force parameters */
        async_ei_parms st_ei_parms;      /* insert, eject,
eject_complete
parameters
*/
    } parms;

    union _response                           /*
response data */
    {
        async_mount_parms st_mount_parms; /*
mount command response */
        async_response st_response;      /*
dismount, force, eject,
eject_complete
response */
        async_insert_response st_insert_response; /*
insert command response */
    } response;
} aci_async_entry;

```

**Figure 5-23** Common Structure for aci\_async\_entry

---

---

## Parameter Data (Parms Structure)

This union contains several structures that hold the data required for making an appropriate ACI call. All the constants, starting with XDR, are defined in *aci\_xdr.h* file.



**Some of the structures contain unusable data fields. This is done for better compatibility with RPC structures. Developers who do not use the macros, may need to fill in the structures. If the macros are used, the developer only needs to take note of what the macros do.**

See Figure 5-24 for the structure of the *async\_drive\_parms*.

```
struct async_drive_parms {
    char volser[XDR_VOLSER_LEN]; /* volser name
    */
    enum media type;           /* media type
    */
    char drive[XDR_DRIVE_LEN]; /* drive name
    */
    enum drive_status drive_state; /* drive status - not
    used here                    */
    async_common common;        /* common data - not
    used here                    */
};
```

**Figure 5-24** *async\_drive\_parms* Structure

See Figure 5-25 for the structure of *async\_ei\_parms*.

```
struct async_ei_parms {
    char area_name[XDR_AREANAME_LEN]; /* I/E area name
    */
    char volser_range[XDR_RANGE_LEN]; /* volser range
    */
    enum media type;           /* media type
    */
    struct common common;      /* common data - not
    used here                  */
};
```

**Figure 5-25** *async\_ei\_parms* Structure

---

---

## Response Data (Structure)

This union contains several structures where the asynchronous call results are stored after the call is completed.

### **st\_response**

This structure is reserved for possible future use. Asynchronous ACI developer could use it for storing data. See Figure 5-26.

```
struct async_response {
    int code;
    char text[XDR_TEXT_LEN];
};
```

**Figure 5-26** async\_response Structure

### **st\_mount\_parms**

This structure is reserved for possible future use. Asynchronous ACI developer could use it for storing data. See Figure 5-27.

```
struct async_mount_parms {
    async_response stResponse;
    char volser[XDR_VOLSER_LEN];
    enum media type;
    char drive[XDR_DRIVE_LEN];
    enum drive_status drive_state;
    char drvmedia[XDR_TEXT_LEN];
};
```

**Figure 5-27** async\_mount\_parms Structure

---

---

## st\_insert\_response

This structure is supported by ACI\_INSERT macro, described above. If you do not use macros, you could fill it with appropriate data after aci\_insert() call returns. ACI\_INSERT macro also fills the member volser\_ranges\_len with the actual size of volser\_ranges\_val array, which could be less than XDR\_NO\_RANGES in most cases. See Figure 5-28.

```
struct async_insert_response {
    async_response resp;    /* not used
*/
    struct {                /* this structure returns
the volsers inserted */
        u_int volser_ranges_len; /* number of
volser_ranges_val array entries,
                                which contain inserted
volsers                        */
        char
volser_ranges_val[XDR_NO_RANGES][XDR_RANGE_LEN]; /*
this array contains
                                all the volsers inserted
*/
    } volser_ranges;
    enum media mediatype; /* media type, not used
*/
    char szMediaType[XDR_AREANAME_LEN]; /* not used
*/
};
```

**Figure 5-28** async\_insert\_response Structure



# A

## Application Notes

Overview .....	A-3
Error Recovery Procedures .....	A-3
Terms .....	A-9





---

---

## Overview

This section contains information on error recovery procedures and explanations of terms used throughout this document.

## Error Recovery Procedures

This section contains information on error recovery procedures. See Table A-1.

**Table A-1** Error Code Reactions

Number	d_error Name	Recommended Reactions to the Error Code
0	EOK	No error.
1	ERPC	Communication problem, test the TCP/IP to the AMU PC and, if possible, try an alternate route.
2	EINVALID	A parameter in the command is wrong, try it with other parameters.
3	ENOVOLUME	Volser from the command with the media type is not found in the AMU database. Check the media type in the command. If a mismatch is detected between the archive and the database, update the AMU database with the inventory command. Otherwise try the command with another volser
4	ENODRIVE	The drive parameter in the command does not match any drives in the AML. Change the parameter in the command.
5	EDRVOCUPPIED	The drive named is already used for another cartridge. <ul style="list-style-type: none"><li>• Send an unload command to the drive.</li><li>• Send a dismount command to the DAS software.</li><li>• Wait until the previous mount (also possible for cleaning) is completed.</li></ul>

**Table A-1** Error Code Reactions

Number	d_error Name	Recommended Reactions to the Error Code
6	EPROBVOL	The AMS returned a error code from robot control or information about an unrecoverable situation in the AML. Stop the command that returned this error. Refer to the AMU-Log for more information.
7	EAMU	The AMS returned an unexpected error. Stop the command that returned this error. Refer to the AMU-Log for more information.
8	EAMUCOMM	An internal error was detected in the AMS software (AMS error code 1001 in the AMU-log), wait a moment, then enter this, or another test command again. Otherwise, the AMS software will need to be stopped and restarted.
9	EROBOT	not used
10	EROBOTCOMM	There is a problem in the communication between AMU and robot control or the robot is switched logically, or physically to not ready. Check the status with aci_robstat and, if possible, set the status to ready. Try the command again.
11	ENODAS	On ACI Version 1.2 mapped to the Error EDASINT (Refer to <i>EDASINT</i> on page A-7).
12	EDEVEMPTY	AMS returned the error code 1094, the drive named is in the AMU database with the attribute Empty. If there is a cartridge in the drive (previous error with database mismatch or manual intervention), the AMU database must be updated. Use the AMS screen or remote SQL-commands to set the drive coordinate: <ul style="list-style-type: none"><li>• Volser: volser in the drive</li><li>• Attribute: 'O' (Occupied)</li><li>• set the home coordinate of the Volser</li><li>• Attribute: 'M' (Mounted)</li><li>• if the drive is an Optical Disk drive the second site of the OD must also be set.</li><li>• Attribute 'R' (Reverse side Mounted)</li></ul>
13	ENOTREG	not used

**Table A-1** Error Code Reactions

Number	d_error Name	Recommended Reactions to the Error Code
14	EBADHOST	DAS was unable to resolve the IP-name to an address, or the address is invalid. Check the TCP/IP command. Set the IP-configuration and change configuration data in AMU or the environment.
15	ENOAREA	The named insert or eject area was not found in the configuration. Try the command with another area name, or change the AMS configuration.
16	ENOTAUTH	Access privilege limitations for the requesting client are defined in the config file parameters. Change the configuration. This can be temporarily done by aci_register. For a longer term change, use another client or change the config file.
18	EUPELSE	DAS has found that the drive is reserved by another client. <ul style="list-style-type: none"><li>• Check which client has reserved the drive and the status of the drive (occupied or empty) with aci_drivestatus2.</li><li>• Set the drive for the other client down with aci_driveaccess (if occupied use FDOWN).</li><li>• If the drive is occupied, send an unload command to the drive and to DAS with aci_dismount.</li><li>• Set the drive for the Client UP with aci_driveaccess.</li></ul>
19	EBADCLIENT	The Client only BASIC rights. Change the Clientname on the ACI to a Client with Complete rights or change the Configuration file.
20	EBADDYN	not used
21	ENOREQ	The aci_cancel command was used with a invalid sequence number. <ul style="list-style-type: none"><li>• check the command queue for the correct sequence number with aci_list</li><li>• try the aci_cancel command with the correct sequence number</li></ul>

**Table A-1** Error Code Reactions

Number	d_error Name	Recommended Reactions to the Error Code
22	ERERTRYL	<p>The maximum number of automatic retries for recovering has been exceeded. There is a problem in the AMS. Check the AMU-Log for more information:</p> <ul style="list-style-type: none"><li>• &lt;0420&gt; Cartridge not ejected.<ul style="list-style-type: none"><li>• The dismount manager is not configured correctly (Refer to the <i>AMU Reference Guide</i>).</li><li>• The drive has not received the unload command (send unload via data path to the drive or to DAS aci_unload.</li><li>• The drive has a physical problem (call Service).</li></ul></li><li>• &lt;1191&gt; Tower not available. The tower can be set back to the ready status with the status command, if the tower does not have a physical problem (call Service).</li><li>• &lt;1123&gt; Too many commands; possible AMS overload.<ul style="list-style-type: none"><li>• Restart the AMU. Do not send so many commands at one time, or request AMU hardware with more performance.</li></ul></li><li>• &lt;1290&gt; Command Canceled from AMS. Internal problem in the AMS software, try a restart of the AMU.</li></ul>
23	ENOTMOUNTED	<p>AMS returned the error code 1162, the volser named is not in the AMU database.</p> <ul style="list-style-type: none"><li>• Check the Volser in the command.</li><li>• If there is a cartridge in the drive (previous error with database mismatch or manual intervention), the AMU database must be updated.</li></ul>
24	EINUSE	<p>The requested volser is already in use. Wait until the usage of the cartridge is completed or send a unload and a dismount of the drive, that is using the requested volser.</p>
25	ENOSPACE	<p>Problem with the aci_register, aci_clientaccess and aci_foreign commands. The limits for configured ranges have been exceeded. Remove old ranges, before registering something new.</p>

**Table A-1** Error Code Reactions

Number	d_error Name	Recommended Reactions to the Error Code
26	ENOTFOUND	Problem with parameters in the command. Check the command and confirm the parameters with the AMS configuration.
27	ECANCELLED	A command was canceled with the aci_cancel command or on the AMS.
28	EDASINT	An internal DAS error has occurred. Restart DAS. Save the Log and inform ADIC support about the error situation.
29	EACIINT	An internal ACI error has occurred. Restart DAS. Save the Log and inform ADIC support about the error situation.
30	EMOREDATA	Return code from aci_qvolsrange command, if the number of volsers in the range exceed the number of displayed volsers. Try the aci_qvolsrange again with the last volser in the first range in the parameter of the first volser.
31	ENOMATCH	Parameters in the command are not correct confirm, that the parameter type (Mediatype) is correct for the command. Confirm the AMS configuration with the parameter in the command.
32	EOTHERPOOL	Return code to aci_scratch_set, if the volser is already defined in a pool with another name. Use the command aci_scratch_unset for the other pool and issue the aci_scratch_set command again.
33	ECLEANING	The command can not be executed, because the drive or the volser is being used for the drive cleaning. Wait until the cleaning process is complete, and try the command again.
34	ETIMEOUT	The maximum wait time for the command has been exceed. Check the life of the DAS software with aci_qversion and the life of the robot wit aci_robstat. Check the communication with ping command. If you have very high load in the system, you have to change the time-out parameters in the configuration (Refer to the <i>Environment Variables</i> in the <i>DAS Administration Guide</i> ).

**Table A-1** Error Code Reactions

Number	d_error Name	Recommended Reactions to the Error Code
35	ESWITCHINPROG	The commands can not be executed. DAS and AMS are being switched to the other AMU. Wait until the switching process is completed and try again.
36	ENOPOOL	There has been an attempt to insert or eject cleaning cartridges to a cleanpool that has not been configured. Confirm the cleanpool name in the command with the cleanpool names in the AMS configuration.
37	EAREAFULL	The aci_ejectclean command returns that the Eject area is full. Empty the area and try the command again.
38	EHICAPINUSE	The commands can not be executed, because the HICAP is open and the robot is not ready. Close the HICAP, press the start button on the controller and try the command again.
39	ENODOUBLESIDE	The volser in the aci_getvolsertoside command was not from type optical disk (AMU mediatype O0 and O1) Check the AMS configuration and AMU database.
40	EEXUP	The aci_driveaccess command returned that the requested drive is exclusively used by a other client. Request the other client to release the drive or use the Client DAS_SUPERVISOR for the release.
41	EPROBDEV	AMS returned <1033> (position not in AMU database). Check the AMU database, use AMS command update device for actualizing the database.
42	ECOORDINATE	AMS returned <1142> (the logical coordinate is not in the AMS configuration). Compare the AMS configuration with the DAS parameter in the command.
43	EAREAEMPTY	Returned AMS <1156> (Insert area empty) during insert. Open and close the I/O unit, the AMS will start the automatic inventory of the range.
44	EBARCODE	Switch the barcode reading off with aci_barcode and try the command again

**Table A-1** Error Code Reactions

Number	d_error Name	Recommended Reactions to the Error Code
45	EUPOWN	The Client tried to allocate volsers that are already allocated.
46	ENOTSUPPHCMD	The AMU has a command exclusion feature that can be used to configure which DAS commands are supported. The command that was sent to the AMU is configured as a not supported host command. Refer to the <i>AMU Administration Guide</i> if this needs to be changed.
47	EDATABASE	Check the AMU log for a more detailed message. Also check the AMU error message.
48	ENOROBOT	Check the AMU configuration
49	EINVALIDDEV	Check the device parameter and correct it if necessary.
50	NO_ECOCES	Number of error codes in header file increment when adding new codes to the end of the list

## Terms

This section contains explanations of terms used throughout this document.

ACI	AML Client Interface Application Program Interface for the AML
AML	Automated Mixed-Media Library; AML software and physical archive. <ul style="list-style-type: none"><li>• /2 stands for 2nd version</li><li>• /E stands for Entry</li><li>• /J stands for Junior</li></ul>
AMS	AML (Archive) Management Software The complete software package which controls the AML
AMU	AML (Archive) Management Unit Central intelligence of the DAS system. Consists of hardware and software.

---



---

API	<p><b>Application Program Interface</b></p> <p>A program residing on the client's platform used to interpret the client's requests and to provide all the network communication compatible with the interface requirements.</p>
Archive	<p>The archive consists of:</p> <ul style="list-style-type: none"> <li>• physical archive</li> <li>• logical archive.</li> </ul> <p>The physical archive consists of storage segments for tape cartridges and optical disks (= media). The logical archive (archive catalog) is the list of volsers assigned to the compartments in the physical archive.</p>
Archive catalog	<p>An OS/2 database with the logical archive. Contains the assignment of volsers to the compartments in the physical archive as well as additional vital information about the media and the drives.</p>
Bar code	<p>An array of rectangular bars and spaces in a predetermined pattern (e.g., UPC symbol.)</p>
Bin	<p>A single medium storage location. Also referred to as a slot in some archives.</p>
Cassette	<p>A shell having two co-planar hubs, designed to hold magnetic recording tape. Used loosely, the same as Volume.</p>
Cartridge	<p>One or more physical volumes, bound in a transportable package with a human- readable external label.</p>
Client	<p>A volume server user that may be an application program.</p>
Console	<p>A human interface mechanism for controlling and monitoring system operation.</p>
DAS	<p><b>Distributed AML Server</b></p>
Data	<p>This term refers to information transferred over the network not including requests and operation responses.</p>
dismount	<p>The robotic action to remove media from a drive to storage.</p>

---



---

Drive	A device used to read and write data on a medium.
eject	The physical action of removing a medium from an archive. For a robotic archive, the medium is robotically moved to the unload port for removal by the operator.
Eject area	The logical location within the I/O unit that accepts ejected media.
Ethernet	Interface standard defined by IEEE Standard 802.3
File	An individual collection of related data (e.g.; a letter, a table, a digitized photograph).
Foreign (non-system) media	Cartridges not listed with a volser in the archive catalog. They are processed by the DAS system via the I/O unit.
ID	Identifier. In DAS the ID is usually referring to the volser, which is the identifier for a volume.
insert	The action of physically entering a medium into an archive. For a robotic archive, the operator places the medium in the archive's load port from which the robot places the medium in the assigned bin.
Insert area	Logical location within the I/O unit that accepts inserted media.
I/O unit	A mechanical device into which an operator places media which are to be entered or removed from a robotic archive.
inventory	A physical action by the archive's robot to determine the storage contents of the AML.
Media	More than one medium.
Medium	A storage object that, when mounted in a drive/recorder/reproducer, is available for read and write operations, but also for clean. Types include magnetic tape, magnetic disk, optical tape, and optical disk, cleaning tape.
mount	The robotic action to move media from storage to a drive.

---



---

Network	The physical and logical connection of computers and peripheral devices that allows communication and data sharing.
Network Protocols	A set of rules defining the physical and logical connection.
OS/2	Operating system (multitasking, single user) that is used on the AMU controller PC.
PC	Personal Computer.
RAM	Random Access Memory
Robotic archive	A storage system featuring one or more robots for media handling.
RPC	Remote Procedure Call - with XDR, RPC is the Session Layer (layer 5) and XDR is the Presentation Layer (layer 6) of the ISO/OSI layered client interface.
Scratch media	Media that has no client data and is free for use and reclassification.
Scratch pool	A collection of scratch media of the same media type.
Shelf archive	An identifiable set of contiguous bins for storing media.
Slot	A single medium storage location. Also referred to as a bin in some archives.
Stage	A type of media storage area containing no assignable bin/slot locations.
System Administrator (SA)	The primary human controller of a computer system. The SA configures each archive, issues restricted commands, and generates reports appropriate to efficient management of the overall system.
Terabyte (TB)	10 <sup>12</sup> bytes, or one million megabytes.
User	Also known as the client or the client system.
Volume	A removable entity of tape media.

---

---

Volser, VSN

**Volume Serial Number**

An up to sixteen-digit alphanumeric designation. It identifies one medium (cartridge, optical disk) in the archive.

Exception: optical disk has one logical compartment but two volsers (A and B side). The volser is attached to the rear of the medium on a barcode label and can be read by the handling unit.



# Index

## - A -

ACI .....	2-4	aci_eject_complete .....	2-6, 5-19
ACI (AML Client Interface) .....	2-4	aci_eject2 .....	4-42
ACI client		aci_eject2_complete .....	4-51
administration .....	2-5	aci_ejectclean .....	4-57
ACI client services		aci_flip .....	4-61
basic .....	2-5	aci_force .....	2-6, 4-64, 5-17
complete .....	2-5	aci_foreign .....	2-6, 4-66
ACI interface types		aci_getvolserdrive .....	4-68
command line .....	2-4	aci_init .....	2-6, 4-72
aci.h .....	2-8	aci_initialize .....	4-74
aci_asunc_find .....	5-14	aci_insert .....	2-6, 4-75, 5-18
aci_async.h .....	5-5, 5-16	aci_insert2 .....	4-77
aci_async_add .....	5-5	aci_inventory .....	2-6, 4-81
DAS_DISMOUNT .....	5-7	aci_killamu .....	4-82
DAS_EJECT .....	5-9	aci_list .....	2-6, 4-84
DAS_EJECT_COMPLETE .....	5-10	aci_mount .....	2-6, 4-91, 5-16
DAS_FORCE .....	5-7	aci_perrpr .....	4-96
DAS_INSERT .....	5-8	aci_qcersion .....	4-97
DAS_MOUNT .....	5-6	aci_qversion .....	2-6
aci_async_create .....	5-13	aci_qvolserange .....	2-6
aci_async_entry .....	5-23	aci_qvolserange .....	4-98
aci_async_free .....	5-16	aci_register .....	2-6
aci_barcode .....	4-5	aci_scratch_get .....	2-7
aci_cancel .....	2-5, 4-7	aci_scratch_info .....	2-7, 4-111
aci_cleandrive .....	4-9	aci_scratch_set .....	2-7, 4-114
aci_clientaccess .....	2-5, 4-11	aci_scratch_unset .....	2-7
aci_clientstatus .....	2-5, 4-14	aci_shutdown .....	2-7, 4-118
aci_dismount .....	2-5, 4-16, 5-17	aci_view .....	2-7
aci_driveaccess .....	2-5, 4-18	aci_xdr.h .....	5-25
aci_drivestatus .....	2-5, 4-21	acu_register .....	4-103
aci_drivestatus2 .....	4-21	Add volume to scratch pool	
aci_eject .....	2-5, 2-6, 4-39, 5-19	ACI client .....	2-7
		Administration access	

add volume to scratch pool	2-7
cancel	2-5
change client access	2-5
change client drive status	2-5
dismount	2-5
drive status	2-5
eject	2-5, 2-6
eject complete	2-6
force	2-6
foreign media	2-6
initialize AML	2-6
insert media	2-6
inventory	2-6
list DAS requests	2-6
list requested range	2-6
mount	2-6
mount scratch volume	2-7
query client status	2-5
query DAS and ACI version	2-6
query scratch volume information	2-7
register	2-6
remove volume from scratch pool	2-7
shutdown	2-7
view database entry	2-7
AML Client Interface	2-4
AML Management Software (AMS)	2-4
AML Management Unit (AMU)	
controller	2-4
Assistance	1-5
Associated Documents	1-4
async_drive_parms	5-25
async_ei_parms	5-25

**- B -**

Basic user services	2-4, 2-5
---------------------	----------

**- C -**

Cancel	4-7
ACI client	2-5
Change client access	
ACI client	2-5
Client access	4-11
temporary	2-6
Client profile	
change	2-6
Client services	
administration	2-4
basic	2-4

complete	2-4
Client status	4-14
ACI client	2-5
Complete access	
add volume to scratch pool	2-7
cancel	2-5
client access	2-5
client status	2-5
dismount	2-5
drive access	2-5
drive status	2-5
eject	2-5, 2-6
eject complete	2-6
force	2-6
foreign media	2-6
initialize AML	2-6
insert	2-6
inventory	2-6
list	2-6
list requested range	2-6
mount	2-6
mount scratch volume	2-7
query scratch volume	2-7
query version	2-6
register	2-6
remove volume from scratch pool	2-7
shutdown	2-7
view	2-7
Complete user services	2-4, 2-5
Controller	
AMU	2-4

**- D -**

DAS ACI (AML Client Interface)	2-4
DAS calls	2-4
DAS server	2-4
DAS_DISMOUNT	5-7
DAS_EJECT	5-9
DAS_EJECT_COMPLETE	5-10
DAS_FORCE	5-7
DAS_INSERT	5-8
DAS_MOUNT	5-6
derrno.h	2-8
Dismount	4-16
ACI client	2-5
dismount	4-16
Document Organization	1-3
Drive access	4-18
ACI client	2-5

---

---

Drive status .....4-5, 4-9, 4-21  
ACI client .....2-5

**- E -**

Eject .....4-39, 4-42, 4-51, 4-57  
ACI client .....2-5, 2-6  
Eject complete  
ACI client .....2-6

**- F -**

Force .....4-61, 4-64  
ACI client .....2-6  
Foreign .....4-66  
Foreign media  
ACI client .....2-6

**- G -**

Get scratch .....4-109

**- H -**

Hazard Alert Messages .....1-5  
Header file  
aci.h .....2-8  
aci\_async.h .....5-5, 5-16  
aci\_xdr.h .....5-25  
derrno.h .....2-8

**- I -**

Init .....4-68, 4-72  
Initialize .....4-74  
Initialize AML  
ACI client .....2-6  
Insert .....4-75, 4-77  
Insert media  
ACI client .....2-6  
Intended Audience .....1-3  
Inventory .....4-81  
ACI client .....2-6

**- L -**

List .....4-84  
List DAS requests  
ACI client .....2-6  
List requested range  
ACI client .....2-6

**- M -**

Media type  
3590/8590 .....2-7  
512 MO/WORM optical disks .....2-8  
CD CADDY .....2-8  
D2 (small & medium) tape .....2-8  
DAT 4mm tape .....2-7  
DEC DLT .....2-8  
EXABYTE 8mm tape .....2-8  
Metrum VHS .....2-8  
reflection optical disks .....2-8  
SONY BETACAM .....2-8  
SONY DTF .....2-8  
TRAVAN .....2-8  
Media types  
ACI media name .....2-7  
supported .....2-7  
Mount .....4-91  
ACI client .....2-6  
Mount scratch volume  
ACI client .....2-7

**- O -**

OS/2 shutdown .....4-82

**- P -**

Perror .....4-96  
Personal Computer (PC) .....2-4  
Power off .....4-82

**- Q -**

Query scratch volume information  
ACI client .....2-7  
Query version .....4-97  
ACI client .....2-6  
Query volser range .....4-98

**- R -**

Register .....4-103  
ACI client .....2-6  
Remove volume from scratch pool  
ACI client .....2-7  
RPC (Remote Procedure Calls) .....2-4

**- S -**

Scratch info .....4-111  
Scratch set .....4-114

---



---

Scratch unset .....	4-116
Set scratch .....	4-111
Setenv .....	4-111
Shutdown .....	4-118
ACI client .....	2-7
shutdown .....	4-82
Signal Handler .....	5-21
Routine .....	5-22
Setup .....	5-21
st_insert_response .....	5-27
st_mount_parms .....	5-26
st_response .....	5-26
Symbols	
Hazard Alert Messages .....	1-5
symbols	
formats .....	1-4
information/note .....	1-4

**- T -**

Terms .....	A-9
Test .....	4-118

**- U -**

Used Terms .....	A-9
------------------	-----

**- V -**

View database entry	
ACI client .....	2-7