

Scalar 218 Theory of Operation

Overview


The **adic** Scalar 218 design allows speedy fault isolation to the Field Replaceable Unit (FRU) level. Each FRU can be rapidly replaced resulting in very short down-times for the customer.

The Scalar 218 is best thought of as three separate units: the library robotics section and each of the two drives. The host computer views each of these units as separate SCSI devices.

The Scalar 218 is composed of the following functional sections:

- Controller Section
- Media Handling Mechanism
- Drive Assembly Section
- Power Supply Section

Below is a functional block diagram of the Scalar 218:



Functional Block Diagram

Functional Sections

Controller

The Controller can be logically divided into the **SCSI-2 Interface** and the **Robotics Controller**.

SCSI-2 Interface

The 218 connects to the host computer's SCSI channel through this interface. The SCSI channel is the control, communications, and data bus through which commands, messages, and data are passed between the Scalar, the drives, and the host computer. The **SCSI-2 Interface** passes commands to the **Robotics Controller** from the applications software.

Robotics Controller

The multi-microprocessor-based **Robotics Controller** receives SCSI commands from the host computer via the **SCSI-2 Interface**. The operational firmware for the Master (Main) Processor and Slave (Motion) Processor are stored in Flash EEPROM (firmware) mounted on the main controller board. Non-volatile RAM (NVRAM) is used to store 218 configuration information and operational logs. The **Robotics Controller** controls the **Media Handling Mechanism**, monitors and controls the drives, and the **Operator Panel**.

Embedded Control Firmware

The embedded control firmware for the 218 is divided among four processors, the Main Processor, Motion Processor, Picker Processor, and the Micro-Stepping Motor Control (Micro-Stepper) Processor.

Main Processor

The **Main Processor**'s internal EPROM (Boot ROM) code provides elemental SCSI interface intelligence, serial port control, and inter-processor communication. While executing the Boot Code, the **Main Processor** checks to see if the Flash Memory contains valid operating code (operational firmware). If the operational firmware is valid, the **Main Processor** signals to the **Motion Processor** to notify the keyboard and then proceeds to download code from the Flash Memory to the **Motion Processor**'s RAM. When completed, the **Main Processor** signals the **Motion Processor** to switch to RAM-based code and then switches its addressing so that it begins operating out of the Flash Memory instead of its internal Boot ROM.

If valid operational firmware is not found in the Flash Memory, the **Main Processor** continues to execute the Boot Code, monitoring the SCSI chip for a valid request to download code to the Flash Memory.

Once executing the operational firmware in Flash Memory, the **Main Processor** performs the following functions:

- Provides complete SCSI interface protocol.

- Provides a monitor function, mirroring SCSI commands and inter-processor commands via serial port Comm 1.
- Maintains the operational logs stored in the NVRAM.
- Communicates commands and receives status from the **Motion Processor** via the inter-processor serial communication port.

Motion Processor

The **Motion Processor** contains code in its internal EPROM (Boot Code) which has elemental inter-processor communication, diagnostic LED control, and keypad I/O capability. During the boot process, the **Motion Processor** communicates with the keyboard as dictated by the **Main Processor**. When commanded by the **Main Processor**, the **Motion Processor** switches to operating code in its RAM memory (see Main Processor description on previous page).

Once executing the code in its RAM memory, the **Motion Processor** performs the following functions:

- Initializes all ports and registers.
- Maintains position tables for the X-axis coordinates of the **Media Picker** assembly and relates them to element addresses as assigned in the SCSI interface specification.
- Monitors position by maintaining X-axis coordinate counts from the X-axis encoder interrupts.
- Calculates position offsets for motion commands received from the Main Processor and communicates them to the **Micro-Stepper Processor**.
- Writes a binary pattern to the Diagnostic LED's (located on the Main Controller board) associated with currently active firmware processes.
- Writes data to the keyboard, and LED's. Reads switch information after an interrupt, reads door open sensors and cartridge present sensors on a polled basis.
- Controls and monitors the **Picker Processor** via one of the two serial ports.
- Controls the Drive Mux Bus. Selects the appropriate drive assembly, monitors the assembly's serial stream information via the assembly's serial multiplexer board, monitors the drive door switch status via the Drive Mux Bus, and controls the **Door Open Stepper Motor** via the Drive Mux Bus.

Picker Processor

The **Picker Processor**, mounted inside the Media Picker, interfaces to the **Motion Processor** via a balanced differential serial port. The **Picker Processor** controls the following picker functions:

- Monitors **Media Picker Entry/Exit Port** cartridge sensors.
- Monitors and keeps track of the Gripper Carriage position via the three carriage optical sensors.
- Controls the enable and direction of the gripper motor. Monitors the gripper limit signal which indicates that the jaws have stalled or reached a limit.
- Controls the enable, direction, and break of the roller motor.
- Controls the enable, direction, and break of the carriage motor.
- Controls the trigger on the Barcode reader and monitors the serial Barcode reader data.

Micro-Stepper Processor

The **Micro-Stepper Processor** takes high level movement commands and breaks them down into finite steps of the X Stepper Motor. The four finite motor steps, are displayed on the four diagnostic LED's. The four digital steps are broken down further into 16 sub-steps. These sub-steps are of variable amplitudes such that the resultant waveform of a full step approximates a sine wave. The **Micro-Stepper Processor** controls the following:

- Quad output D to A converter.
- Four diagnostic LED's.
- Data input and output registers.

Door Open Stepper Motors

Each drive assembly employs a door over the drive cartridge opening. This door must be physically opened or closed to load or unload a cartridge. Damage to the drive and/or media will occur if the door is opened or closed while the drive is still loaded (the tape is still wound through the read/write head mechanism). To prevent damage to the drive and media, the drive illuminates an Operate Handle LED on its front panel to indicate when it is unloaded (the tape is fully rewound into the cartridge). When the Operate Handle LED is illuminated the drive assembly outputs an "OK to Open Door" status message via its serial port.

To automate the insertion and removal of cartridges the 218 employs a **Door Open Stepper Motor** that rotates the door's hinge shaft, thus opening or closing the door. This **Door Open Stepper Motor** is mounted on the drive assembly's drive mounting plate directly above the drive. The **Controller Section** monitors each of the drive assembly's serial port, via the Drive Mux Bus, and opens or closes the door when the "OK to Open Door" status message appears.

Media Handling Mechanism

This section controls all movement of media within the 218. It is used to pick and place media between the DLT drives and the 18 cartridge locations. The **Media Handling Mechanism** components include the **Media Picker**, X Stepper Motor, X carriage, carriage rails, and associated drive belts and sensors.

Media Picker

Entry/Exit Port

The pass-through **Entry/Exit Port** allows the **Media Picker** to pick or place data cartridges from/to the storage slots and drives without needing an additional media handling mechanism or having to rotate a cartridge. **Cartridge Sensors** are mounted in both openings of the **Entry/Exit Port**. These sensors monitor the position of the data cartridge. If the cartridge is not fully positioned in the **Cartridge Gripper Assembly**, the **Picker Processor** informs the **Main Processor** via the **Motion Processor**. The **Motion Processor** will prevent all movement of the **Media Picker** until the incorrectly positioned cartridge is cleared.

Cartridge Gripper Assembly

The cartridge gripper assembly is an integral part of the **Media Picker**. The gripper is engaged by a DC motor (Gripper Motor) which is controlled by the robotics firmware. The Gripper Motor servo control senses torque, when a preset torque level is reached, the gripper stops.

Picker-Home Sensors

The **Picker Home Sensors** tells the robotics controller when the **Media Picker** is positioned at the exact home position. To have a starting reference position the **Media Picker** must start after a reset from the Picker-Home position (at the left side of the carriage rails). This position is determined by the **Picker-Home Sensor**, which report its status to the robotics controller. It is the only time that the controller has an indication of the physical position of the **Media Picker**. All other positions are referenced from this point.

Barcode Reader

The **Barcode Reader** is used to scan barcode labels on the data cartridges located in the storage slots. This information is passed to the application software via the SCSI bus, which stores it in its cartridge inventory log. The barcode codes supported by the Scalar 218 are: Code 3 of 9 and Code 128.

The **Barcode Reader** uses a Charge Coupled Device (CCD) sensor and a Light Emitting Diode (LED) light source. The depth of field ranges from approximately 2 inches up to 20 inches (barcode size dependent). The red light from the LED appears as a red stripe on the barcode. The scanner is positioned so that the light is reflected back to the CCD for reading. The **Barcode Reader** receives its trigger from the **Picker Processor**, and outputs the scanned barcode data over the serial bus.

Operator Panel

The **Operator Panel** includes an eight-key keypad and a 4-line by 20-character scrollable LCD display. The keypad and display provide a means for the operator to change operating parameters of the 218, such as the SCSI ID of the robotics. Additionally, an Off-Line Diagnostics Menu is available via the **Operator Panel**, through which a qualified technician can examine error, event, and operation logs, perform manual pick and place operations, and calibrate the location of the **Media Picker**. The **Operator Panel** interfaces to the Controller PCB.

Cartridge Sensors

Mounted beneath each of the 18 cartridge storage slots, the **Cartridge Sensors** monitor cartridge presence. The contents of the 218 (inventory) can quickly be determined by polling these sensors.

Door Open Sensor

The sliding access door open sensor alerts the **Motion Processor** of the door's position (opened or closed). If the door is opened during On-Line Mode operation, a SCSI UNIT ATTENTION message is sent to the host. It is up to the software application running on the host to handle this condition with the proper routine. If the door is opened while the 218 is performing a pick and place operation, the **Motion Processor** automatically causes all **Media Picker** motion to stop.

Drive Assembly Section

One or two drive assemblies may be mounted in the **Drive Assembly Section**. The drive assemblies respond to operating commands, and communicate directly with the host computer's SCSI channel. Each drive assembly receives operating voltages from the **Power Supply Section** of the 218. The only other interface between an assembly and the 218 is the drive assembly multiplexer (Mux) card. The 218 monitors the drive assembly status through the Drive Mux Bus (see *Door Open Stepper Motors*).

Power Supply Section

The **Power Supply Section** contains 2 separate power supplies.

80 watt Switching Supply

The 80 watt switching supply is mounted in the **Power Supply Section**. It provides the operating voltages for DLT drives 1 and 2.

50 watt Switching Supply

The 50 watt switching supply, mounted in the **Power Supply Section**, provides operating voltages to the remainder of the 218.