



Errata Sheet: SuperLoader 3A User's Guide And A-Series FTP File Server User's Guide

The following errors or omissions were noted in the SuperLoader 3A User's Guide 81-81643-02_A01.pdf and the A-Series FTP File Server User's Guide 81-81800-01_A01.pdf after publication.

Document in which error or clarification is required	Page (of English version)	Error or Omission	Correction
81-81643-02_A01.pdf SuperLoader 3A User's Guide	86	<p>Read compatibility LTO Ultrium 1, LTO Ultrium 2, LTO Ultrium 3</p> <p>Write compatibility LTO Ultrium 2, LTO Ultrium 3</p>	<p>Read and Write compatibility LTO Ultrium 3, only.</p> <p>Note: Only new LTO3 media or LTO3 media that has been used in the A-series product can be used in the SuperLoader 3A</p>
81-81800-01_A01.pdf A-Series FTP File Server User's Guide	43	<p>Note: From the Contextual menu, Unlock system... is disabled for the standalone A-Series tape drive. It is available when using the Quantum SuperLoader 3A Series. This autoloader is configured with the A-Series tape drive.</p>	<p>From the Contextual menu, click Prepare for magazine unload. (Note: This command is disabled for the standalone A-Series tape drive.) This will disconnect all current FTP connections and move all tapes back to slots within an A-Series autoloader.</p> <p>Running this command assures that a desired cartridge does not remain in the tape drive while unloading magazines from an autoloader.</p>
81-81800-01_A01.pdf A-Series FTP File Server User's Guide	52	<p>It is not documented that after updating server firmware the browser should be closed and re-opened for the update to take effect.</p>	<p>Note: Restart your browser after the update process. This assures that the FTP Client feature gets refreshed properly.</p>