

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
2	Operations	Change Mode			Partitions	Online / Offline
3	Operations	Import			Partitions / Media	Import
4	Operations	Auto Import			Partitions	AMP Distribution
5	Operations	Export			Partitions / Media	Export
6	Operations	Import Cleaning Media			Library	Cleaning Import
7	Operations	Export Cleaning Media			Library	Cleaning Export
8	Operations	Drives			Drives	Operations panel
9	Operations	Move Media			Media	Move
10	Operations	Inventory			Partitions	Inventory
11	Operations	System Shutdown			Header/Shutdown	
12	Operations	Log Off			Header/Log Off	
13	Operations	Restart LMC			Header/Restart	
14	Monitor	System			Various north panel and Information panel results	
15	Monitor	Drives			Drives	North Panel
16	Monitor	Connectivity	IO Blade		Devices	North Panel
17	Monitor	Connectivity	Fibre Channel		Devices	North Panel
18	Monitor	Connectivity	Ethernet Blade		Devices	North Panel
19	Monitor	IE Station			Devices	North Panel
20	Monitor	Extended IE Slots			Library North Panel / Partitions	Resources
21	Monitor	Slots			Library North Panel / Partitions	Resources
22	Monitor	Media			Media	North Panel
23	Monitor	Sensors			Status (partial, some data as in voltage and cooling fan status not shown)	North Panel

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
24	Monitor	Email Configuration Record			Reports	Save/Send
25	Monitor	Users			User Access	North Panel
26	Monitor	Partitions	Status		Partitions	North Panel
27	Monitor	Partitions	Policies		Partitions	various policy configurations
28	Monitor	EKM Servers			Encryption	North panel and information panel
29	Setup	Setup Wizard			No equivalent - Configure the library walking the menu system top down	
30	Setup	Partitions	Configure		Partitions	Add... or Resources
31	Setup	Partitions	Control Path		Partitions	Control Path
32	Setup	Partitions	Automated Media Pool	Assign Magazines	Partitions	Assign AMP...
33	Setup	Partitions	Automated Media Pool	Assign Media	Media	AMP Deposit... and AMP Withdrawal...
34	Setup	Partitions	Policies	EDLM Configuration	Partitions	EDLM...
35	Setup	Partitions	Policies	Active Vault Configuration	Partitions	Active Vault...
36	Setup	Partitions	Policies	StorNext Access	Partitions	option in EDLM... and Active Vault... policy
37	Setup	Partitions	Policies	Auto Import Configuration	Partitions	AMP Distribution...
38	Setup	Partitions	Policies	Auto Export Configuration	Partitions	Active Vault...

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
39	Setup	SNW Wizard			No equivalent - not needed, SNW license assignments are done by code per selected features that require SNW support. No user interaction required.	
40	Setup	Drives	FC Settings		Drives	Modify...
41	Setup	Drives	Access	Data Path Failover	Drives	Modify...
42	Setup	Blades	Access	Channel Zoning	Devices	Blade Settings
43	Setup	Blades	Access	FC Host	Devices	Blade Settings
44	Setup	Blades	Access	LUN Mapping Wizard	Devices	Host Mapping
45	Setup	Blades	Connectivity	Port Configuration	Devices	Port Setting
46	Setup	Blades	Connectivity	Datapath Conditioning	Feature removed in WebGUI	
47	Setup	Blades	Connectivity	FC Host Port Failover	Devices	Port Setting
48	Setup	Network Configuration	Interface 1	IPv4 Configuration	Network, then north panel interface selection	IPv4...
49	Setup	Network Configuration	Interface 1	IPv6 Configuration	Network, then north panel interface selection	IPv6...
50	Setup	Network Configuration	Interface 2	IPv4 Configuration	Network, then north panel interface selection	IPv4...
51	Setup	Network Configuration	Interface 2	IPv6 Configuration	Network, then north panel interface selection	IPv6...
52	Setup	Network Configuration	DNS Configuration		Network, then north panel interface selection	DNS...

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
53	Setup	System Settings	Physical Library		Library	Settings
54	Setup	System Settings	Aisle Lights		System	Settings
55	Setup	System Settings	Preferences		Library	Settings
56	Setup	System Settings	Health Check Internals		Library	Settings
57	Setup	System Settings	Camera HostIP		System	Settings
58	Setup	User Configuration	Local Users		User Access North Panel and Information panel	
59	Setup	User Configuration	LDAP		User Access	LDAP
60	Setup	Notifications	System Setup		System	Contact...
61	Setup	Notifications	Media Security		System	Media Security...
62	Setup	Notifications	Partition Utilization		Notifications	
63	Setup	Notifications	Trap Registration		Notifications	Add... Trap selection
64	Setup	Notifications	Tickets Filter		Notifications	north panel selection then RAS Tickets... selection
65	Setup	Date and Time			System (also header double click on date/time)	Date/Time
66	Setup	Licenses			Licences	Add...
67	Setup	Email Configuration			System	E-Mail...
68	Setup	Security			Network/User Access/System	Connectivity/Settings/SNMP/SMI-S
69	Setup	Cleaning Slots			Library	Cleaning Slots...
70	Setup	Encryption	Server Configuration		Encryption	Add...

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
71	Setup	Encryption	Partition Configuration		Partitions	EKM...
72	Tools	Tickets			RAS Tickets	
73	Tools	Drives			Drives	
74	Tools	Connectivity			Devices	North panel FCB or EEB selection
75	Tools	Capture Snapshot			Service	Library Snapshot...
76	Tools	Update Software	Library		System	Library Firmware...
77	Tools	Update Software	Drives		System/Drives	Drive Firmware... / Firmware Update...
78	Tools	Update Software	Plug-In		System	Plug-In (Application Interface)...
79	Tools	Teach			Service	Teach...
80	Tools	Save/Restore			System	Save/Restore...
81	Tools	Verification Tests			Diagnostics	north panel selection then RAS Tickets... selection
82	Tools	Reports	Reporting Options		Reports	North panel report selection and View... filter option
83	Tools	Reports	Drive Utilization		Reports	North panel Drive Utilization selection
84	Tools	Reports	Tickets		Reports/Tickets	North panel Tickets selection
85	Tools	Reports	LUN Mapping		Not supported	
86	Tools	Reports	Media	Integrity Analysis	Reports	North panel Media Integrity report selection
87	Tools	Reports	Media	Usage	Reports	North panel Media Usage report selection
88	Tools	Reports	Media	Security	Reports	North panel Media Security report selection

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
89	Tools	Reports	Media	Moves	Reports	North panel Cross Partition Media Moves report selection
90	Tools	Reports	Library Configuration		Not supported as report	Shown as Library Center panel and north panel display
91	Tools	Library Explorer			Library / Partitions	North panel / Resources...
92	Tools	Command History Log			Logs	North panel SCSI Command History log selection
93	Tools	IE Stations			Devices	North panel I/E station selection, then Lock... Unlock...
94	Tools	Partitions Defragmentation			Deprecated - <u>Use Partitions->Resources....</u>	
95	Tools	EKM Management	Import Communication Certificates		Encryption	Load Certificates...
96	Tools	EKM Management	Encryption Certificate	Import	Feature removed in WebGUI	
97	Tools	EKM Management	Encryption Certificate	Export	Feature removed in WebGUI	
98	Tools	EKM Management	Encryption Key	Import	Feature removed in WebGUI	
99	Tools	EKM Management	Encryption Key	Export	Feature removed in WebGUI	
100	Tools	EKM Management	Retrieve SKM Logs		Feature removed in WebGUI	

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
101	Tools	EKM Management	EKM Audit Report		Reports	EKM Media Status and EKM Partition Activity report selections
102	Tools	EDLM	Test Selection		Media	EDLM Test...
103	Tools	EDLM	Test Results		Reports / Media	EDLM Test Results / EDLM Sessions....
104	Tools	EDLM	Status		Reports / Media	EDLM Test Results / EDLM Sessions....
105	Tools	Sift Sort	Export		Feature removed in WebGUI	
106	Tools	Sift Sort	Capture Report		Feature removed in WebGUI	
107	Tools	Retrieve MIBs			System	MIB Retrieval...
108	Tools	Library	Robot State		Devices	north panel robot selection
109	Tools	Towers			Devices	North panel tower selection
110	Tools	Capture Network Trace			Not implemented yet	
111	View	Library Name (Physical)			Network center panel and also System Information panel and header/title bar	
112	View	Partition Name (Partition Amp)			Partitions	North Panel and Information panel
113	View	Partition Name (Partition Active Vault)			Partitions	North Panel and Information panel
114	Connection	New			browser tab slection with new IP address...	
115	Help	Content			Header	

	A	B	C	D	E	F
1	Java Menu	SubMenu 1	SubMenu2	SubMenu3	WebGUI Menu/Header	Operations/North Panel
116	Help	About			Header	
117						