

Quantum[®]

User's Guide

Quantum DXi4000

with DXi 2.1.1 Software



Quantum DXi4000 User's Guide, 6-67092-04 Rev A, January 2012, Product of USA.

This document is for DXi 2.1.1 Software.

Quantum Corporation provides this publication "as is" without warranty of any kind, either express or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Quantum Corporation may revise this publication from time to time without notice.

COPYRIGHT STATEMENT

© 2012 Quantum Corporation. All rights reserved.

Your right to copy this manual is limited by copyright law. Making copies or adaptations without prior written authorization of Quantum Corporation is prohibited by law and constitutes a punishable violation of the law.

TRADEMARK STATEMENT

Quantum, the Quantum logo, DLT, DLTtape, the DLTtape logo, SuperLoader, Scalar, DXi, and DXi Accent are registered trademarks of Quantum Corporation, registered in the U.S. and other countries.

Preserving the World's Most Important Data. Yours., Backup. Recovery. Archive. It's What We Do., the DLT logo, DLTSage, Dynamic Powerdown, FastSense, FlexLink, GoVault, MediaShield, Optyon, Pocket-sized. Well-armed, SDLT, SiteCare, SmartVerify, StorageCare, Super DLTtape, and Vision are trademarks of Quantum.

LTO and Ultrium are trademarks of HP, IBM, and Quantum in the U.S. and other countries. All other trademarks are the property of their respective companies.

Specifications are subject to change without notice.



Contents

Preface	xix
----------------	------------

Chapter 1	DXi4000 System Description	1
	Overview	2
	Features and Benefits	3
	What's New in DXi 2.1.1 Software	4
	Data Reduction	6
	Data Deduplication	6
	Compression	6
	Space Reclamation	7
	Remote Replication	8
	DXi4000 System	8
	Hard Drive Storage	10
	HDDs	10
	Network Attached Storage (NAS)	11
	OpenStorage (OST)	13
	Supported RAID Configurations	14
	DXi Advanced Reporting	15

Network Configuration	16
---------------------------------	----

Chapter 2	Basic Operations	17
------------------	-------------------------	-----------

DXi4000 System	17
System Front Panel Features and Indicators	18
System Back Panel Connectors	20
Hard Drive Carrier Indicators	21
Ethernet Port Indicators	23
Power Supply Indicators	23
Turning On and Shutting Down the System	24
Locating Serial Numbers	25

Chapter 3	DXi4000 Remote Management	27
------------------	----------------------------------	-----------

Accessing Remote Management	28
Supported Browsers	28
Logging On to the DXi4000	28
Logging Off of the DXi4000	31
The Remote Management Console	31
System Banner	31
Main Menu	34
DXi4000 Management Pages	34

Chapter 4	DXi4000 Configuration Wizards	41
------------------	--------------------------------------	-----------

NAS Wizard	42
Step 1: About	43
Step 2: Protocol	43
Step 3: Windows	44
Step 4: Add Share	46
Step 5: Confirm	47
OST Wizard	48
Step 1: About	49
Step 2: Add Storage Servers	49
Step 3: Add LSUs	50
Step 4: Add Users	51

Step 5: Confirm	52
Step 6: Download OST Client Plug-In	53
Replication Wizard	54
Step 1: About	55
Step 2: System	55
Step 3: NAS Shares	57
Step 4: Confirm.	59
Email Alerts Wizard	60
Step 1: About	60
Step 2: Server	61
Step 3: Recipients	62
Step 4: Confirm.	63
Support Wizard	64
Step 1: About	64
Step 2: Registration	65
Step 3: Guardian.	66
Step 4: System Log	67
Step 5: Licensed Features	68

Chapter 5	DXi4000 Home Page	71
	DXi4000 System Overview	72
	Disk Usage Overview	73
	Data Reduction Statistics Overview	75
	Replication Overview	76
	Current Activity Overview	78
	Scheduled Activity Overview	79

Chapter 6	DXi4000 Replication	81
	Understanding Data Replication	82
	Replication	82
	Directory/File Based Replication	83
	OST Optimized Duplication.	84
	Performing Data Replication	84
	Task Overview: Setting Up and Performing Replication.	85

DXi Accent Status 127

Chapter 8 **DXi4000 Alerts** **129**

Admin Alerts 129

Service Tickets 131

 Service Ticket Priority 131

 Recommended Actions 132

 Working With Service Tickets 132

Chapter 9 **DXi4000 Configuration** **139**

NAS 139

 NAS Summary 140

 Windows Domain 146

 Share Access 149

 Advanced Setting 155

Replication 157

 Replication Send 157

 Replication Receive 159

OST 162

 Storage Servers 163

 LSU 168

 Manage Users 173

 DXi Accent 177

 OST Client Plug-In 178

Scheduler 178

 Viewing Scheduled Events 179

 Scheduling Replication Throttling 180

 Scheduling Healthchecks 183

 Scheduling Space Reclamation 184

System 184

 Network 184

 Date & Time 192

 Security 194

Notifications 202

 Email 202

 SNMP 212

Contacts	223
Company	223
Primary and Secondary	224

Chapter 10 DXi4000 Utilities 227

Diagnostics	228
System Diag File	228
Storage Array Diag File	229
DSET	230
Healthchecks.	232
Analyzer	236
Network	237
Disk.	239
Space Reclamation	240
General	240
Schedule.	242
License Keys.	244
License Key List	244
Adding a License Key	245
Software Upgrade	248
Reboot & Shutdown	249

Appendix A DXi4000 System Specifications 251

Physical Characteristics	251
Environmental Specifications	254

Appendix B Troubleshooting 257

DXi4000 Status and Problem Reporting	257
General Troubleshooting Actions	258
Viewing Service Tickets	258
Checking Hardware Status	259
Downloading a System Diagnostics File	259
Common Problems and Solutions	259
Start-up Problems.	259

Hardware Problems 260
Ethernet Network Problems 261
Replication Problems 263
Temperature Problems 264

Glossary

267



Figures

Figure 1	DXi4000 System	10
Figure 2	DXi4000 Drive Slot Numbering.	11
Figure 3	DXi4000 Drive Carrier	11
Figure 4	NAS Backup using CIFS and NFS.	13
Figure 5	OpenStorage (OST) Example.	14
Figure 6	DXi4000 RAID Sets	15
Figure 7	DXi4000 System Front View	18
Figure 8	System Rear View	20
Figure 9	Hard Drive Carrier LEDs.	22
Figure 10	Ethernet Port LEDs	23
Figure 11	Power Supply LED.	24
Figure 12	Power Buttons	25
Figure 13	Login Window	29
Figure 14	Home Page	30
Figure 15	System Banner	32
Figure 16	Main Menu	34
Figure 17	Wizards Menu	42
Figure 18	NAS Wizard: About.	43

Figure 19	NAS Wizard: Protocol	44
Figure 20	NAS Wizard: Windows	45
Figure 21	NAS Wizard: Add Share	47
Figure 22	NAS Wizard: Confirm	48
Figure 23	OST Wizard: About	49
Figure 24	OST Wizard: Add Storage Servers	50
Figure 25	OST Wizard: Add LSUs	51
Figure 26	OST Wizard: Add Users	52
Figure 27	OST Wizard: Confirm	53
Figure 28	OST Wizard: Download OST Client Plug-in	54
Figure 29	Replication Wizard: About	55
Figure 30	Replication Wizard: System.	57
Figure 31	Replication Wizard: NAS Shares	59
Figure 32	Replication Wizard: Confirm	60
Figure 33	Email Alerts Wizard: About.	61
Figure 34	Email Alerts Wizard: Server.	62
Figure 35	Email Alerts Wizard: Recipients.	63
Figure 36	Email Alerts Wizard: Confirm	64
Figure 37	Support Wizard: About.	65
Figure 38	Support Wizard: Registration	66
Figure 39	Support Wizard: Guardian	67
Figure 40	Support Wizard: System Log.	68
Figure 41	Support Wizard: Licensed Features.	69
Figure 42	Home Page	72
Figure 43	DXi4000 System Overview	73
Figure 44	Disk Usage Overview	75
Figure 45	Data Reduction Statistics Overview.	76
Figure 46	Replication Overview	78
Figure 47	Current Activity Overview	79

Figure 48	Scheduled Activity Overview	80
Figure 49	Send NAS Page	88
Figure 50	Edit NAS Share Page	92
Figure 51	Directory/File Based Queue	96
Figure 52	Received Snapshots Page	98
Figure 53	Recovered Share Name Page	100
Figure 54	Failback Target Page	101
Figure 55	Recovery Jobs Page	104
Figure 56	Failback Jobs Page	105
Figure 57	Directory/File Based Page	106
Figure 58	Edit Share Settings Page	108
Figure 59	Unpack Queue	109
Figure 60	Actions Page	110
Figure 61	Reports Page	112
Figure 62	Hardware Summary Page	114
Figure 63	System Board Page	116
Figure 64	Network Ports Page	117
Figure 65	Storage Arrays Page	118
Figure 66	Firmware Version Page	119
Figure 67	Inline Page	121
Figure 68	Ethernet Page	122
Figure 69	RAID Page	123
Figure 70	CPU Page	124
Figure 71	Disk Usage Page	125
Figure 72	Accent Status Page	127
Figure 73	Admin Alerts Page	130
Figure 74	Service Tickets Page	132
Figure 75	Ticket Details	134
Figure 76	Recommended Actions	135

Figure 77	Ticket Analysis	136
Figure 78	Email Ticket Information.	137
Figure 79	NAS Summary Page	141
Figure 80	Add NAS Share Page.	143
Figure 81	Edit NAS Share & Replication Settings Page	145
Figure 82	Windows Domain Page	147
Figure 83	Share Access Page (Windows Workgroup)	150
Figure 84	Share Access Page (Active Directory)	150
Figure 85	Add Workgroup User Page	152
Figure 86	Add Share Administrator Page	153
Figure 87	Edit Workgroup User Page	154
Figure 88	Advanced Setting Page.	156
Figure 89	Replication Send Page	158
Figure 90	Replication Receive Page.	160
Figure 91	Storage Servers Page	163
Figure 92	Add Storage Server Page	165
Figure 93	Edit Storage Server Page.	167
Figure 94	LSU Page.	169
Figure 95	Add Logical Storage Unit Page	170
Figure 96	Edit Logical Storage Unit Page	172
Figure 97	Manage Users Page	174
Figure 98	Add Authenticated User Page.	175
Figure 99	Edit Authenticated User Page.	176
Figure 100	Accent Page	177
Figure 101	Scheduler Page	179
Figure 102	Scheduler View Controls.	180
Figure 103	Scheduling a Replication Throttle Event	183
Figure 104	Network Configuration.	186
Figure 105	Date & Time Page	193

Figure 106 Web & CLI Passwords Page 195

Figure 107 SSL Page 198

Figure 108 Install New Certificate Page 200

Figure 109 Login Session Page 201

Figure 110 Security Banner Page 202

Figure 111 Recipients Page. 204

Figure 112 Add Email Recipient Page 205

Figure 113 Edit Email Recipient Page 206

Figure 114 Server Page 208

Figure 115 Email Test Page. 209

Figure 116 Schedule Page 210

Figure 117 On Demand Page 211

Figure 118 Destinations Page 213

Figure 119 Add Trap Destination Page 214

Figure 120 Edit Trap Destination Page 216

Figure 121 Community Page 217

Figure 122 Add SNMP Community Page 218

Figure 123 Edit SNMP Community Page 220

Figure 124 SNMP Test Page 222

Figure 125 Company Page 223

Figure 126 Primary and Secondary Pages 224

Figure 127 System Diag File Page 229

Figure 128 Storage Array Diag File Page 230

Figure 129 DSET Page. 231

Figure 130 General Page 232

Figure 131 Status Page. 234

Figure 132 Edit Healthcheck Page 235

Figure 133 Schedule Page 236

Figure 134 Performance Page. 237

Figures

Figure 135	Settings Page	238
Figure 136	Disk Analyzer Page	239
Figure 137	General Page	241
Figure 138	Schedule Page	243
Figure 139	License Keys Page	244
Figure 140	License Key Management Page.	246
Figure 141	License Details	248
Figure 142	Reboot & Shutdown Page.	249



Tables

Table 1	DXi4000 System - Front Panel LED Indicators, Buttons, and Connectors	19
Table 2	Rear Panel Connectors	21
Table 3	DXi4000 Model Number.	33
Table 4	Menu Items and Management Pages	35
Table 5	Physical Characteristics	252
Table 6	Storage Capacity.	252
Table 7	Cable Drops	253
Table 8	Interfaces	253
Table 9	Power Requirements.	253
Table 10	Environmental Specifications	255
Table 11	Start-up Problems.	260
Table 12	Hardware Problems	260
Table 13	Ethernet Network Problems	262
Table 14	Replication Problems	263



Preface

This manual introduces the Quantum DXi4000 enhanced data protection systems and discusses:

- System operations
- Configuration
- Web interface
- Basic troubleshooting

Audience

This manual is written for DXi4000 operators and administrators.

Note: It is useful for the audience to have a basic understanding of Windows, Linux, and UNIX® as well as backup/recovery systems.

Document Organization

Following is a brief description of chapter contents.

- [Chapter 1, DXi4000 System Description](#) provides an overview of the DXi4000.
- [Chapter 2, Basic Operations](#) provides basic operating instructions for the DXi4000.

- [Chapter 3, DXi4000 Remote Management](#) discusses using the DXi4000 remote management console to control the system remotely.
- [Chapter 4, DXi4000 Configuration Wizards](#) discusses the wizards that provide guidance for setting up the DXi4000.
- [Chapter 5, DXi4000 Home Page](#) discusses the information that appears on the **Home** page of the remote management console.
- [Chapter 6, DXi4000 Replication](#) discusses the remote replication capabilities of the DXi4000.
- [Chapter 7, DXi4000 Status](#) discusses DXi4000 status information.
- [Chapter 8, DXi4000 Alerts](#) discusses DXi4000 alert information and service tickets.
- [Chapter 9, DXi4000 Configuration](#) discusses configuration of the DXi4000.
- [Chapter 10, DXi4000 Utilities](#) discusses DXi4000 utilities such as diagnostic tools and rebooting the system.
- [Appendix A, DXi4000 System Specifications](#) provides system specifications for the DXi4000.
- [Appendix B, Troubleshooting](#) discusses problems you may encounter during the setup and operation of the DXi4000.
- [Glossary](#) provides definitions of terms used in this guide.

Notational Conventions

This manual uses the following conventions:

Note: Note emphasizes important information related to the main topic.

Caution: Caution indicates potential hazards to equipment or data.

WARNING: Warning indicates potential hazards to personal safety.

- Right side of the system - Refers to the right side as you face the component being described.

- Left side of the system - Refers to the left side as you face the component being described.
- Data sizes are reported in base 1000 rather than base 1024. For example:
 - 1 MB = 1,000,000 bytes
 - 1 GB = 1,000,000,000 bytes
 - 1 TB = 1,000,000,000,000 bytes

Product Safety Statements

Quantum will not be held liable for damage arising from unauthorized use of the product. The user assumes all risk in this aspect.

This unit is engineered and manufactured to meet all safety and regulatory requirements. Be aware that improper use may result in bodily injury, damage to the equipment, or interference with other equipment.

WARNING: Before operating this product, read all instructions and warnings in this document and in the system, safety, and regulatory guide.

警告 在使用本产品之前，请先阅读本文档及系统、安全和法规信息指南中所有的说明和警告信息。

警告 操作本产品前，请先閱讀本文件及系統、安全與法規資訊指南中的指示與警告說明。

ADVERSAL Læs alle instruktioner og advarsler i dette dokument og i *Vejledning om system-sikkerheds- og lovgivningsoplysninger*, før produktet betjenes.

AVERTISSEMENT Avant d'utiliser ce produit, lisez la totalité des instructions et avertissements de ce document et du *Guide d'informations sur le système, la sécurité et la réglementation*.

HINWEIS Lesen Sie vor der Verwendung dieses Produkts alle Anweisungen und Warnhinweise in diesem Dokument und im System, Safety, and Regulatory Information Guide (Info-Handbuch: System, Sicherheit und Richtlinien).

אזהרה לפני ההפעלה של מוצר זה, קרא את כל ההוראות והאזהרות הכלולות במסמך זה וכן במדריך מידע בנושאי מערכת, בטיחות ותקינה

警告 この製品を使用する前に、本文書、および『システム、安全、規制に関する情報ガイド』に記載しているすべての警告と指示をお読みください。

경고 이 제품을 작동하기 전에 이 문서 및 시스템, 안전, 및 규제 정보 안내서에 수록된 모든 지침과 경고 표지를 숙지하십시오.

ПРЕДУПРЕЖДЕНИЕ всеми инструкциями и предупреждениями, приведенными в данном документе и в *Справочном руководстве по устройству, технике безопасности и действующим нормативам*.

ADVERTENCIA Antes de utilizar este producto, lea todas las instrucciones y advertencias en este documento y en la Guía informativa sobre sistema, seguridad y normas.

WARNING Läs alla anvisningar och varningar i detta dokument och i *System, säkerhet och krav från myndigheter - Informationshandbok* innan denna produkt tas i bruk.

Related Documents

The following Quantum documents are also available for the DXi4000:

Document No.	Document Title	Document Description
6-00618	<i>System Safety and Regulatory Information - Quantum Products</i>	Lists all safety and regulatory information for all Quantum products.
6-67093	<i>DXi4000 Site Planning Guide</i>	Provides site planning information for the DXi4000.
6-67079	<i>Symantec Veritas NetBackup OST Configuration Guide</i>	Provides information for setting up the DXi4000 for OST operation with NetBackup
6-67080	<i>Symantec Backup Exec OST Configuration Guide</i>	Provides information for setting up the DXi4000 for OST operation with Backup Exec
6-67081	<i>DXi-Series Command Line Interface (CLI) Guide</i>	Provides information on the DXi4000 command line interface.
6-67353	<i>DXi Advanced Reporting User's Guide</i>	Provides information about using DXi Advanced Reporting features.

For the most up to date information on the DXi4000, see:

<http://www.quantum.com/ServiceandSupport/Index.aspx>

Contacts

Quantum company contacts are listed below.

Quantum Corporate Headquarters

To order documentation on the DXi4000 or other products contact:

Quantum Corporation (*Corporate Headquarters*)
1650 Technology Drive, Suite 700
San Jose, CA 95110-1382

Technical Publications

To comment on existing documentation send e-mail to:

doc-comments@quantum.com

Quantum Home Page

Visit the Quantum home page at:

<http://www.quantum.com>

Getting More Information or Help

Quantum. Global Services

StorageCare™, Quantum's comprehensive service approach, leverages advanced data access and diagnostics technologies with cross-environment, multi-vendor expertise to resolve backup issues faster and at lower cost.

Accelerate service issue resolution with these exclusive Quantum StorageCare services:

- **Service and Support Web site** - Register products, license software, browse Quantum Learning courses, check backup software and operating system support, and locate manuals, FAQs, software downloads, product updates and more in one convenient location. Benefit today at:

<http://www.quantum.com/ServiceandSupport/Index.aspx>

- **eSupport** - Submit online service requests, update contact information, add attachments, and receive status updates via e-mail. Online Service accounts are free from Quantum. That account can also be used to access Quantum's Knowledge Base, a comprehensive repository of product support information. Sign up today at:

<http://www.quantum.com/osr>

- **StorageCare Guardian** - Securely links Quantum hardware and the diagnostic data from the surrounding storage ecosystem to Quantum's Global Services Team for faster, more precise root cause diagnosis. StorageCare Guardian is simple to set up through the internet and provides secure, two-way communications with Quantum's Secure Service Center. More StorageCare Guardian information can be found at:

<http://www.quantum.com/ServiceandSupport/Services/GuardianInformation/Index.aspx>

For further assistance, or if training is desired, contact the Quantum Customer Support Center:

United States	800-284-5101 (toll free) 949-725-2100
EMEA	00800-4-782-6886 (toll free) +49 6131 3241 1164
APAC	+800 7826 8887 (toll free) +603 7953 3010

For worldwide support:

<http://www.quantum.com/ServiceandSupport/Index.aspx>

Worldwide End-User Product Warranty

For more information on the Quantum Worldwide End-User Standard Limited Product Warranty:

<http://www.quantum.com/pdf/QuantumWarranty.pdf>



Chapter 1

DXi4000 System Description

This chapter describes the DXi4000 system and its components and includes the following sections:

- [Overview](#)
- [Features and Benefits](#)
- [What's New in DXi 2.1.1 Software](#)
- [Data Reduction](#)
- [Space Reclamation](#)
- [Remote Replication](#)
- [DXi4000 System](#)
- [Hard Drive Storage](#)
- [Supported RAID Configurations](#)
- [DXi Advanced Reporting](#)
- [Network Configuration](#)

Overview

The DXi4000 is Quantum's entry level disk backup solution that integrates data deduplication and replication technology to connect backup and DR (disaster recovery) protection across distributed corporate environments. The DXi4000 disk-based backup appliance uses Quantum's patented data deduplication technology to increase disk capacities by 10 to 50 times, and make WAN replication a practical, cost-effective part of disaster recovery planning. With up to 12 TB capacity (up to 11.61 TB usable for data storage), the DXi4000 is designed for departmental and medium business customers.

Advanced Data Deduplication Increasing Disk Retention for Backup Data

The DXi4000 leverages Quantum's patented data deduplication technology (U.S. Pat. No. 5,990,810) to dramatically increase the role that disk can play in the protection of critical data. With the DXi4000 solution, users can retain 10 to 50 times more backup data on fast recovery disk than with conventional arrays.

Remote Replication of Backup Data Providing Automated Disaster Recovery Protection

With the DXi4000, users can transmit backup data from a remote site to a central, secure location to reduce or eliminate media handling. DXi™-Series replication is asynchronous, automated, and operates as a background process.

Enterprise Features Provide Secure Repository

The DXi4000 features up to 12 TB capacity (up to 11.61 TB usable for data storage). The DXi4000 presents storage as NAS shares (CIFS and NFS) or OST storage servers.

Features and Benefits

The DXi4000 system provides the following features and benefits:

- New, inline data flow provides leading deduplication with an optimal combination of total system performance, manageability, and value.
- NAS or OST (OpenStorage) presentation layer.
- 10 source to one target LAN/WAN replication compatible with DXi2500-D, DXi4000 family, DXi6500 family, DXi6700 family, DXi7500, and DXi8500 models.
- OST Optimized Duplication support with Symantec Backup Exec and Symantec NetBackup.
- Supported by every major backup software vendor.
- Rack space requirements: 2U.
- Installs in a standard rack with a minimum depth of 24.09 in (61 cm).

Note: Quantum recommends installing the DXi4000 system in a controlled or restricted area to prevent access by untrained personnel. In addition, Quantum recommends that system installation be performed only by qualified IT personnel with strong networking experience.

What's New in DXi 2.1.1 Software

DXi 2.1.1 Software for DXi4000 includes the following significant enhancements:

- **Additional OpenStorage (OST) Improvements** - Enhancements include support for optimized synthetic full backups, and support for HP-UX 11i v3 IA-64 platforms (NetBackup only).
- **Replication Throttling and Scheduler** - With replication throttling, you can configure the DXi to limit its outgoing data replication bandwidth to a specified maximum in order to avoid network contention. Use the new **Scheduler** page to set up a recurring schedule for replication throttle, and to manage schedules for space reclamation and healthchecks.
- **AES 256-bit Encryption** - When sending replicated data to a target system, the DXi can take advantage of 256-bit encryption for stronger security.
- **New CLI Functionality** - The command line interface (CLI) supports new and updated functionality for enabling symlinks and hard links on NAS shares, enabling SMB server signing for NAS shares, mapping OST IP addresses, scheduling replication throttling, and performing advanced configuration of network interfaces.
- **Improved Space Reclamation Process** - The space reclamation process now better adjusts its use of system resources, consuming fewer resources during data ingest and performing space reclamation more quickly when more system resources are available.

The following enhancements were previously introduced in DXi 2.0.x software:

- **Inline Data Flow** - The new, inline data flow enabled by the DXi 2.0.x Software deduplicates data as it is ingested into the DXi appliance. Optimized for the new generation of purpose-built DXi hardware platforms, it provides enhanced performance and more efficient dynamic use of system resources (see [Data Reduction](#) on page 6).
- **OpenStorage (OST) Improvements** - Enhancements include increased total performance, including writes, reads, and replication; simplified deployment (see [Manage Users](#) on page 173);

and dynamically sized LSUs with no hard size limit (see [LSU](#) on page 168).

- **Automatic Replication Trigger** - In the Directory/File Based Replication, a file is automatically replicated after it is closed (CIFS shares) or after several minutes of inactivity (NFS shares) (see [Directory/File Based Replication](#) on page 83). There is no need for scripting to execute this function. This action makes files at the target available for access without a local recovery operation.
- **Enhanced Usability** - The user interface of the remote management console has been updated and improved to make it easier to see important information at a glance and perform the most common tasks (see [DXi4000 Remote Management](#) on page 27).

Note: For a list of all menus and pages in the remote management console, see [DXi4000 Management Pages](#) on page 34. Use this list to help find the new location of features in the remote manage console.

- **Custom Network Configuration** - You can now create a custom network configuration using the remote management console as well as through the CLI (command line interface). The custom network option allows you to configure the DXi4000 with individual IP subnet information for each physical interface (see [Network](#) on page 184).
- **Configuration Wizards** - New wizards provide guided assistance to help users configure key features of the DXi4000, such as storage presentation and data replication. Each wizard leads you step-by-step through the configuration process (see [DXi4000 Configuration Wizards](#) on page 41).

Data Reduction

Data reduction is the process of reducing the amount of storage capacity required to store your data. The DXi4000 systems provide two techniques to optimize the storage space required on your system:

- [Data Deduplication](#)
- [Compression](#)

Data Deduplication

The DXi-Series disk backup and replication systems use Quantum's patented data deduplication technology to dramatically increase the role that disk can play in data protection. With DXi-Series solutions, users can retain 10 to 50 times more backup data on fast recovery disk than with conventional arrays. This advantage allows IT departments to cost-effectively retain months of backup data on disk for faster, more reliable restores and more data recovery points. Quantum's innovative implementation of this core technology means that users do not have to compromise on performance to take advantage of extended retention capability. The new, inline data flow in the DXi 2.x Software provides streamlined deduplication that offers a maximum combination of total system performance, manageability, and value.

Quantum's deduplication technology uses a sub-file, variable-length approach to identify redundant blocks in a data stream—blocks that have appeared before in the same dataset or in datasets processed at an earlier time. When a block appears that has already been stored, the DXi system inserts a reference pointer to the earlier instance of the data segment instead of storing another copy. The result is a dramatic reduction in the storage capacity needed to store the data set, and a similar reduction in the bandwidth needed to replicate deduplicated data sets over a network. For more information on enabling data deduplication, see [NAS Summary](#) on page 140.

Compression

The DXi4000 systems use compression technology after duplicate blocks have been identified and replaced as part of the deduplication process. With compression, unique data that has been through the data deduplication process can be compressed at a typical ratio of

approximately 2:1. This enables you to maximize the storage capacity of your system.

Space Reclamation

The space reclamation process performs multiple functions on the DXi4000.

When data is deduplicated it is stored in a block pool—a pool of all unique data blocks that were captured during the data deduplication cycle. When subsequent backup jobs occur, the data deduplication engine searches for new data entering the DXi and uses a variable length compression algorithm to compare new data to existing data in the block pool. Unique blocks are added to the block pool and known blocks are indexed.

The space reclamation function searches the blockpool for data blocks that are not referenced by any pointers (that is, the files associated with the block have been expired and removed). Once such a data block is identified, the block is removed to make the space reusable.

It may be beneficial to schedule space reclamation for a time when other operations are not normally being carried out. By default the process will commence every Sunday at 1:00pm. However, to maximize performance and capacity utilization, it is highly recommended that this process is performed on a daily basis. As best practice it is recommended that this process commences at least two hours after your backup job has completed on a daily basis. It is far more efficient to process a day's worth of new data than a week's worth.

Remote Replication

Today most backup occurs on isolated devices, making it difficult to deploy disk backup when disaster recovery protection is required. DXi-Series solutions use data deduplication and replication to decrease by up to 50 times the bandwidth required to move backup data over networks and between sites. This dramatic gain makes it practical and cost-effective for users to replicate backup data over WANs for secure, network-based disaster recovery protection, and it lets users combine rapid, local restores with sound disaster recovery protection.

With DXi-Series replication, users can transmit data from a single site or multiple sites to a central location using any DXi model. DXi-Series replication is an asynchronous, automated background process that includes encryption of data in transit. This model for protecting the distributed enterprise allows users to combine disk, replication, and tape for an optimal combination of performance, simplicity, and security.

For more information on implementing a replication plan, see [Chapter 6, DXi4000 Replication](#).

DXi4000 System

The DXi4000 product family includes the following models:

- [DXi4510](#)
- [DXi4520](#)
- [DXi4601](#)

DXi4510

This configuration provides a base amount of data storage. It includes the following features:

- 1 system
- 1 RAID controller card

- 4 x 1GbE ports
- 2.2 TB usable for data storage

DXi4520

This system provides increased data storage. It includes the following features:

- 1 system
- 1 RAID controller card
- 4 x 1GbE ports
- 4.4 TB usable for data storage

DXi4601

This system provides increased data storage that can be quickly and easily upgraded at any time by purchasing and adding a license key. It includes the following features:

- 1 system
- 1 RAID controller card
- 4 x 1GbE ports
- Expandable storage capacity up to 12 TB:
 - **Base System Capacity** - 4 TB total (3.87 TB usable for data storage)
 - **With First Capacity Upgrade License** - 8 TB total (7.74 TB usable for data storage)
 - **With Second Capacity Upgrade License** - 12 TB total (11.61 TB usable for data storage)

Note: For DXi4601, storage capacity upgrades are enabled simply by adding a license key and rebooting the system (see [Adding a License Key](#) on page 245). To purchase a storage capacity upgrade license, contact your Quantum sales representative.

Figure 1 DXi4000 System



Hard Drive Storage

The DXi4000 system is based upon high speed disk drives instead of tape drives (see [HDDs](#) on page 10). The usable capacity is 2.2–11.61 TB. The drive storage area is presented as NAS shares or OST LSUs (Logical Storage Units) (see [Network Attached Storage \(NAS\)](#) on page 11 or [OpenStorage \(OST\)](#) on page 13).

By making use of high speed drives, the DXi4000 greatly reduces the time required for backup/restore functions and improves confidence in completing the backup in the time allowed.


HDDs

To optimize performance, the DXi4000 uses hard disk drives (HDDs).

The DXi4000 supports eight hard disks ([Figure 2](#) and [Figure 3](#)):


- **HDDs** - High capacity (500 GB, 1 TB, or 2 TB) hard disk drives are used for data storage, the operating system, and system software.

Figure 2 DXi4000 Drive Slot Numbering



HDD Slot 0	HDD Slot 2	HDD Slot 4	HDD Slot 6
HDD Slot 1	HDD Slot 3	HDD Slot 5	HDD Slot 7

Figure 3 DXi4000 Drive Carrier



Network Attached Storage (NAS)

The DXi4000 system has the ability to serve as a NAS backup system (see [Figure 4](#)) where the following protocols are supported:

- [CIFS Protocol](#)
- [NFS Protocol](#)

Note: In the DXi4000, NAS shares are optimized for backup rather than file sharing.

CIFS Protocol

The CIFS (Common Internet File System) protocol defines a standard for remote file access from many computers at a time in Windows environments. This protocol allows users with different platforms to share files without installing additional software.

Active Directory Support

The DXi4000 supports ADS (Active Directory Services) as well as ACLs (Access Control Lists). This provides the following benefits:

- **Compatibility with CIFS domains** - NAS shares are able to join CIFS domains and use domain authentication.
- **Precise control of file system permissions** - Administrators can specify which users and groups can perform what actions.
- **Robust administrative support** - Administrators have the same implicit permissions as they do in Windows operating systems.

Note: Windows 2003, Windows 2003 R2, Windows 2008, and Windows 2008 R2 are supported for Active Directory domain membership.


Note: When you create a CIFS share, the initial permissions are the same as the default permissions for a Windows 2003 share with the addition of an ACE (Access Control Entry) that permits full access to the share for all authenticated users. Administrators can choose to remove this full access ACE, set up custom permissions, or leave the ACL (Access Control List) as is if the server is set up in a fully trusted environment.

NFS Protocol

The NFS (Network File System) protocol was originally designed by Sun™ Microsystems and allows all network users to access shared files stored on computers of different types. NFS provides access to shared files through an interface called the Virtual File System (VFS) that runs on top of TCP/IP. Users can manipulate shared files as if they were stored locally on the user's own hard disk. With NFS, computers connected to a network operate as clients while accessing remote files, and as servers while providing remote users access to local shared files. This protocol is

used with UNIX and Linux networks. It can also be used with Windows networks.

Figure 4 NAS Backup using CIFS and NFS




OpenStorage (OST)

With the OST presentation, the DXi system presents storage servers to a Symantec NetBackup or Backup Exec media server through a specific Symantec protocol. A storage server consists of logical storage units (LSUs), which are similar to directories in a NAS file system.

The OST presentation requires the Symantec NetBackup (6.5.3 or later) or Backup Exec 2010 or later host application and the OST Plug-in client installation on the media server. Plug-in clients are host-OS dependent and are supplied by Quantum. To use the DXi in OST mode, you must configure an OST storage server and LSUs on the DXi. You must also map the LSUs on the NetBackup server so that NetBackup can perform backups and restore from them. Additionally, policies for optimized duplication (OST replication) and OST direct to tape may need to be set on the NetBackup server.

Figure 5 OpenStorage (OST)
Example



Supported RAID Configurations

RAID is short for Redundant Array of Independent (or Inexpensive) Disks, which is a category of storage that employs two or more drives in combination for fault tolerance and performance. There are a number of RAID levels in use today such as 0, 1, 3, 5, 6 and 10.

The DXi4000 uses the following RAID level:

- [RAID 6 Configuration](#)

RAID 6 Configuration


RAID 6 uses block-level striping with two parity blocks distributed across all member disks. Dual parity provided by a RAID 6 configuration ensures that your data retains full integrity even in the event of two hard drive failures. Since single parity RAID levels are vulnerable to data

loss until the failed drive is rebuilt: the larger the hard drive, the longer the rebuild will take and the longer the system is vulnerable to possible data loss.

The DXi4000 uses RAID 6 volumes for data storage.

- The system contains the following RAID 6 set ([Figure 6](#)):
 - **DATA** - HDD slots 1–8 (data storage)

Figure 6 DXi4000 RAID Sets



HDD Slot 0	HDD Slot 2	HDD Slot 4	HDD Slot 6
HDD Slot 1	HDD Slot 3	HDD Slot 5	HDD Slot 7

DXi Advanced Reporting

Quantum DXi Advanced Reporting works with all DXi-Series disk backup systems. DXi Advanced Reporting combines comprehensive performance data logging with powerful visual reporting and analysis tools to help you identify potential problems and optimize system operation. For more information, refer to the *DXi Advanced Reporting Software and Documentation CD* included with your system.

Network Configuration

During network configuration, each individual interface on the DXi4000 can be configured as a subnet with its own network settings. Each physical Ethernet port can be configured as an interface. In addition, you can also create bonded interfaces (logical ports) consisting of two or more physical ports.

Keep in mind that any traffic can pass through any of the configured Ethernet ports. This means that the routing of different traffic types, as well as firewall capability, must be controlled using the network infrastructure (routers and switches) that the DXi4000 is connected to.

For more information about configuration network settings, see [Network](#) on page 184.

Note: Each configured network interface requires its own set of network settings (IP address, network mask, and gateway).

Caution: For effective bonded network use, a properly configured network switch is required. (A network switch is not supplied with the DXi4000.) The DXi4000 bonding settings must match the switch settings. If the switch settings and the DXi4000 settings do not match, your system may become inaccessible through the switch.



Chapter 2

Basic Operations

Most DXi4000 system operations are performed using the remote management console (see [Chapter 3, DXi4000 Remote Management](#)). This chapter describes the features and basic operation of the DXi4000 hardware, including:

- [DXi4000 System](#)
- [Hard Drive Carrier Indicators](#)
- [Ethernet Port Indicators](#)
- [Power Supply Indicators](#)
- [Turning On and Shutting Down the System](#)

DXi4000 System

The DXi4000 system is a computer server that provides control for the DXi4000 software (host OS and software applications). The system also provides storage (backup data storage) for the DXi4000 system. The system contains 8 drive carriers. In addition, all network connections are made on the node.

System Front Panel Features and Indicators

[Figure 7](#) shows the controls, indicators, and connectors located behind the optional rack bezel on the front panel of the system. [Table 1](#) describes each item.

Figure 7 DXi4000 System
Front View








Table 1 DXi4000 System -
Front Panel LED Indicators,
Buttons, and Connectors

Item	Indicator, Button, or Connector	Icon	Description
1	Power button		<p>Turns the system on or off.</p> <p>Warning: Turning off the power removes the main power but keeps standby power supplied to the system. Because of this, you must unplug the system before servicing.</p> <p>Caution: Turning off the power without properly shutting down the system may result in loss of data (see Turning On and Shutting Down the System on page 24).</p> <p>Caution: To shut down the system in the event of an emergency, press and hold the power button for 4 seconds. This may result in data loss and may cause a delay on next startup due to a block pool verify operation.</p>
2	NMI button		<p>Used to troubleshoot software and device driver errors. This button can be pressed using the end of a paper clip.</p> <p>Use this button only if directed to do so by qualified support personnel.</p>
3	Video connector		Not used.
4	LCD menu buttons		Not used.
5	LCD panel		The LCD lights blue during normal system operation.

Item	Indicator, Button, or Connector	Icon	Description
6	System identification button		The identification buttons on the front and back panels can be used to locate a particular system within a rack. When one of these buttons is pushed, the LCD panel on the front and the blue system status indicator on the back blink until one of the buttons is pushed again.
7	USB connectors (2)		Connects USB 2.0 compliant devices to the system.
8	DVD-ROM		DVD-ROM drive.

System Back Panel Connectors

See the following subsections for information about the back panel connectors available in each possible configuration:

Note: Refer to the port numbering label on the back of the system to help you determine the correct port connections.

[Figure 8](#) shows the connectors located on the rear panel of the system. [Table 2](#) describes each item.

Figure 8 System Rear View




Table 2 Rear Panel Connectors

Item	Description
1	Power supply 1
2	Power supply 2
3	Service port (for Quantum use only)
4	IPMI port (not used)
5	IPMI port (not used)
6	Ethernet ports

Hard Drive Carrier Indicators

Each hard drive carrier has two LED indicators (see [Figure 9](#)):

- **Drive activity indicator (green)**
 - **Flashing** - Indicates hard disk drive activity.
- **Drive failure indicator (green and amber)**
 - **Off** - Drive ready for insertion or removal

Note: The drive status indicator remains off until all hard drives are initialized after system power is applied. Drives are not ready for insertion or removal during this time.


- **Blinks green two times per second** - Identify drive/preparing for removal
- **Blinks green, amber, and off** - Drive predicted failure
- **Blinks amber four times per second** - Drive failed
- **Blinks green slowly** - Drive rebuilding
- **Steady green** - Drive online

- **Blinks green three seconds, off three seconds, amber three seconds, and off three seconds** - Rebuild aborted

Note: If a drive fails, you will be notified by an admin alert in the remote management console (see [Admin Alerts](#) on page 129).

Caution: All drives are hot swappable. When replacing drives, never remove more than one drive at a time from a RAID set. After removing a drive, first wait one minute. Then insert a working drive and wait for the RAID set to finish rebuilding (red indicator light is off) before removing another drive. For information about RAID sets, see [Supported RAID Configurations](#) on page 14.

Figure 9 Hard Drive Carrier LEDs




Ethernet Port Indicators

Each Ethernet port on the back panel has two LED indicators (see [Figure 10](#)):

- **Link Indicator (green)**
 - **Continuously lit** - Indicates the port is connected to the network.
 - **Off** - Indicates the port is not connected to the network.
- **Activity indicator (amber)**
 - **Blinking** - Indicates network data is being sent or received.

Figure 10 Ethernet Port LEDs



Power Supply Indicators


Each power supply has one LED indicator (see [Figure 11](#)):

- **Not lit** - the power supply is not plugged in
- **Green** - Indicates the power supply is turned on and operating correctly.
- **Amber** - Indicates power supply failure.
- **Alternating green and amber** - When hot-adding a power supply, this indicates that the power supply is mismatched with the other

power supply. Replace the power supply that has the flashing indicator with a power supply that matches the capacity of the other installed power supply.

Caution: All power supplies are hot swappable. When replacing power supplies, never remove more than one power supply at a time from the system. Also, before you remove one power supply, make sure the other power supply is operating correctly (indicator LED is green).


Figure 11 Power Supply LED



Turning On and Shutting Down the System

To turn on the system, press the power button located on the front panel of the system (see [Figure 12](#)).

Figure 12 Power Buttons



To shut down the DXi4000, you must use the remote management console (see [Reboot & Shutdown](#) on page 249). Shutting down the system can take up to 15 minutes.

Locating Serial Numbers

You will need the system serial number at various times:

- **System Serial Number** - You need this number to contact Quantum Support or to add a licensed feature.

You can locate the system serial number on the **Home** page of the remote management console.

You can also locate the system serial number by looking at the front and rear of the server node. The top of the EST tab on the front of the unit includes the serial number (labeled as Service Tag), and so does a sticker on the rear of the unit. An example system serial number is 1A2B3C4.



Chapter 3

DXi4000 Remote Management

The Quantum DXi4000 provides a powerful Web-based user interface that allows you to configure and manage the system from a remote workstation on the same network as the DXi4000.

Use the DXi4000 remote management console to perform the following tasks:

- Set up the DXi4000 using guided procedures (see [DXi4000 Configuration Wizards](#) on page 41).
- View important system information at a glance (see [DXi4000 Home Page](#) on page 71).
- Manage data replication activities (see [DXi4000 Replication](#) on page 81).
- Monitor hardware status and system performance (see [DXi4000 Status](#) on page 113).
- View administration alerts and resolve service tickets (see [DXi4000 Alerts](#) on page 129).
- Configure storage presentation, data replication, and system settings (see [DXi4000 Configuration](#) on page 139).
- Run diagnostic tools and maintain the system (see [DXi4000 Utilities](#) on page 227).

Accessing Remote Management

Access the remote management console using a Web browser on a workstation that is on the same network as the DXi4000.

See the following sections for more information about accessing DXi4000 remote management:

- [Supported Browsers](#)
- [Logging On to the DXi4000](#)
- [Logging Off of the DXi4000](#)

Supported Browsers

Web browser software is not included with the DXi4000. You must obtain and install it separately. The DXi4000 remote management console supports the following Web browsers:

- **Windows** - Microsoft Internet Explorer 7.x or 8.x, Mozilla Firefox 7.x or higher
- **Linux** - Mozilla Firefox 7.x or higher

Note: For correct operation of the remote management console, disable any pop-up blockers and enable JavaScript in your Web browser.

Note: Buttons, borders, and other graphic elements may display differently in Internet Explorer 7 and 8. These differences are cosmetic only and do not affect functionality in any way.


Logging On to the DXi4000

To log on to the DXi4000 remote management console:

- 1 Launch a supported Web browser on a workstation that has network access to the DXi4000.
- 2 In the browser address box, type the IP address of the DXi4000, and then press **<Enter>**.

The **Login** window displays (see [Figure 13](#)).

Figure 13 Login Window



If the **Login** window does not display, verify that the IP address is correct and that the network path to the DXi4000 is valid. Also verify that you are using a supported Web browser. Then try again. If you are still unable to access the Login window, contact your DXi4000 administrator.

Note: The default IP address is **10.1.1.1**. The IP address can be changed during installation using the **Getting Started Wizard** or at a later time on the **Network** page (see [Network](#) on page 184).

- 3 Select the login type and enter the corresponding password.
 - **Monitor** - Allowed to view information on the DXi4000 remote management console but cannot make changes. (The default password is **password**.)
 - **Administrator** - Allowed to view and change information on the DXi4000 remote management console. (The default password is **password**.)

Note: Passwords are limited to 15 characters. All alphanumeric characters are allowed, as well as underscores (`_`) and hyphens (`-`). Passwords can be changed on the **Web & CLI Passwords** page (see [Web & CLI Passwords](#) on page 194).


- 4 Click **Login**.

- 5 If a security banner message has been specified for the DXi4000, click **Accept**.

Note: For information about specifying a security banner message, see [Security Banner](#) on page 201.

The **Home** page displays (see [Figure 14](#)).

Figure 14 Home Page



If you are unable to log on, verify that the password is correct, then try again. If you are still unable to log on, contact your DXi4000 administrator.

Caution: More than one Administrator can log on to the DXi at a time. If two Administrators attempt to make configuration changes on the same page at the same time, it is possible that one Administrator's changes will overwrite the other's. Always coordinate configuration changes with other Administrator users.

Logging Off of the DXi4000

When you are done working in the DXi4000 remote management console, click **Logout** on the upper right of the remote management console to end your session.

Note: If the DXi4000 remote management console is idle for more than 30 minutes (default setting), the system logs off the user. The inactivity timeout can be changed on the **Login Session** page (see [Login Session](#) on page 200).

The Remote Management Console


After you log on to the DXi4000, the remote management console displays. The remote management console includes the following features:

- [System Banner](#)
- [Main Menu](#)
- [DXi4000 Management Pages](#)

System Banner

The system banner displays at the top of the remote management console (see [Figure 15](#)). Use the system banner to see overall system status and alert information at a glance, and to quickly access additional information. The system banner also displays the time and date as well as the login type.

Figure 15 System Banner



The following items display on the system banner:

- **Model Number** - The model number of the DXi4000 (see [Model Number](#) on page 33).
- **State** - Displays the operating state of the DXi4000:
 - **Normal** - (Green) The system is operating correctly.
 - **Attention** - (Yellow) There is a problem with the system.
 - **I/O Write Low Threshold** - (Yellow) Ingest rate continues and space reclamation starts.
 - **Verify Failure** - (Red) The blockpool verify process has failed.
 - **Low Space** - (Red) Available disk space has fallen to a low level.
 - **No Space** - (Red) Available disk space has fallen to a critical level.

Click the **Status** button to display detailed status information the system (see [Hardware](#) on page 113).

- **Admin** - The **Admin** button turns yellow when an administration alert occurs. Click the **Admin** button to manage administration alerts (see [Admin Alerts](#) on page 129).

- **Ticket** - The **Ticket** button turns yellow when open service tickets are present. Click the **Ticket** button to manage service tickets (see [Service Tickets](#) on page 131).
- **Low Capacity** - The **Low Capacity** button turns yellow when available disk space falls to a low level. Click the **Low Capacity** button to view the administration alerts related to low disk capacity (see [Admin Alerts](#) on page 129).

Note: When disk capacity is low, target replication to the system is paused (see [Replication Service](#) on page 110). In addition, space reclamation is automatically started to free up disk space (see [Space Reclamation](#) on page 240).

- **Logout** - Click to end your remote management session.
- **Help** - Click to display the online help.

Model Number

The Model Number displays in the DXi4000 **System Overview** section on the **Home** page. The model number indicates the specific hardware configuration of the DXi4000.

[Figure 3](#) describes the DXi4000 hardware configuration that is indicated by each model number.

Table 3 DXi4000 Model Number


DXi4000 Model Number	DXi4000 Configuration
4510	2.2 TB usable for data storage 4 x 1GbE Ethernet ports
4520	4.4 TB usable for data storage 4 x 1GbE Ethernet ports
4601	4.0–12.0 TB total capacity (3.87–11.61 TB usable for data storage) 4 x 1GbE Ethernet ports

Main Menu

The main menu displays on the left side of the DXi4000 remote management console (see [Figure 16](#)). Click a menu item to display the corresponding management page.

To access **DXi Advanced Reporting**, click the link below the main menu. Quantum DXi Advanced Reporting provides performance data logging and visual reporting and graphing features for Quantum DXi-Series systems. For more information, see the *Quantum DXi Advanced Reporting User's Guide* (6-67353).

Figure 16 Main Menu



DXi4000 Management Pages

Use the DXi4000 management pages to view information as well as configure and manage the system. To navigate to a page, first click a menu item, then click a tab to display the corresponding page. Some pages include sub-tabs that display pages with additional information and options.

If you need help as you work, click **Help** in the page's title bar to see online help for that page. In addition, Quick Tips are available on many pages. Click the **Quick Tip** icon [?] next to a section or field to learn more about that item.

Note: Clicking **Wizards** on the main menu replaces the main menu with the wizards menu. Click a menu item to begin a wizard, or click **Exit** to return to the main menu (see [DXi4000 Configuration Wizards](#) on page 41).

Caution: Do not use your Web browser's **Back, Forward, or Refresh** buttons when navigating in the remote management console. Doing so may have unintended effects. Instead, always use the main menu and tabs to navigate in the remote management console.

[Table 4](#) lists the available menu items and management pages.

Table 4 Menu Items and Management Pages

Home Menu		
Home	System Overview	DXi4000
		Disk Usage
		Data Reduction Statistics
		Replication
		Current Activity
		Scheduled Activity
Replication Menu		
Send	NAS	
Receive	NAS	Received Snapshots
		Recovery Jobs
		Failback Jobs
		Directory/File Based

Actions	Replication Service	
	Replication State	
	Replication Performance	
Reports	Replication Report	
Status Menu		
Hardware	Summary	
	Details	System Board
		Network Ports
		Storage Arrays
Firmware Version		
Performance	Ingest	
	Ethernet	
	RAID	
	CPU	
Disk Usage	Available	
	Used	
	Data Reduction	
Accent		
Alerts Menu		
Admin Alerts		
Service Tickets		
Configuration Menu		

NAS	Summary	
	Windows Domain	
	Share Access	
	Advanced Setting	
Replication	Send	Target DXi
	Receive	Source DXis
		Maximum Received Snapshots
OST	Storage Servers	
	LSU	
	Manage Users	
	Accent	
	OST Client Plug-In	
Scheduler		
System	Network	
	Date & Time (NTP Server or Manual)	
	Security	Web & CLI Passwords
		SSL
		Login Session
Security Banner		
Notifications	Email	Recipients
		Server
		Test
		Email Home
	SNMP	Destinations
		Community
		Test

Contacts	Company	
	Primary	
	Secondary	
Utilities Menu		
Diagnostics	System Diag File	
	Storage Array Diag File	
	DSET	
	Healthchecks	General
		Status
		Schedule
Analyzer	Network	Performance
		Settings
	Disk	
Space Reclamation	General	
	Schedule	
License Keys		
Software Upgrade		
Reboot & Shutdown		
Wizards Menu		
Welcome		
NAS	About	
	Protocol	
	Windows	
	Add Share	
	Confirm	

OST	About
	Add Storage Servers
	Add LSUs
	Add Users
	Confirm
	Download OST Client Plug-In
Replication	About
	System
	NAS Shares
	Confirm
Email Alerts	About
	Server
	Recipients
	Confirm
Support	About
	System Log
	Registration
	Guardian
	Licensed Features
Exit	

Chapter 3: DXi4000 Remote Management
The Remote Management Console



Chapter 4

DXi4000 Configuration Wizards

The **Configuration Wizards** provide guided assistance for setting up the DXi4000. Use the wizards to quickly configure the most important features of the system, including storage presentation and data replication. Each wizard leads you step-by-step through the configuration process.

The **Configuration Wizards** page displays the first time you log on to the remote management console after completing the **Getting Started** wizard. After that, to access the **Configuration Wizards**, click **Wizards** on the main menu. This replaces the main menu with the **Wizards** menu (see [Figure 17](#)).


The **Wizards** menu includes the following wizards:

- **NAS** - Helps you configure the DXi4000 as a NAS (Network Attached Storage) appliance for use on a Windows or UNIX/Linux network (see [NAS Wizard](#) on page 42).
- **OST** - Helps you configure the DXi4000 to present its storage as one or more OST (OpenStorage) storage servers for use with a backup application (see [OST Wizard](#) on page 48).
- **Replication** - Helps you configure the DXi4000 to send replicated data to or receive replicated data from another DXi system (see [Replication Wizard](#) on page 54).
- **Email Alerts** - Helps you configure the DXi4000 to automatically send notifications and reports to selected recipients (see [Email Alerts Wizard](#) on page 60).

- **Support** - Helps you enable licensed features on the DXi4000, register your system with Quantum, and perform other tasks that will aid Quantum customer support in assisting you (see [Email Alerts Wizard](#) on page 60).

Click an item on the **Wizards** menu to begin a wizard. After you complete a wizard, a green check mark displays next to its name on the **Wizards** menu. To display the main menu again, click **Exit**.

Figure 17 Wizards Menu



NAS Wizard

The **NAS** wizard provides guided assistance for configuring the DXi4000 as a NAS (Network Attached Storage) appliance. The wizard helps you determine if the NAS shares will be used on a Windows or UNIX/Linux network, and if necessary helps you join the DXi4000 to a Windows domain. Then the wizard guides you through the process of adding one or more NAS shares to receive backup data.

Note: You cannot use the NAS wizard to edit existing shares. For more information about working with NAS shares, see [NAS](#) on page 139.


To begin the **NAS** wizard, on the **Wizards** menu, click **NAS**.

Step 1: About

- 1 Read the information about the wizard (see [Figure 18](#)).
- 2 Click **Next** to continue.

Note: At any time while using the wizard, you can click **Previous** to return to the previous step.

Figure 18 NAS Wizard: About




Step 2: Protocol

- 1 Select the type of host the DXi4000 will present NAS shares to (see [Figure 19](#)):
 - **Windows (CIFS)** - All hosts that will interact with the DXi4000 run Windows.
 - **UNIX/Linux (NFS)** - All hosts that will interact with the DXi4000 run UNIX or Linux.

- **Both Windows & UNIX/Linux** - Both types of hosts (Windows and UNIX/Linux) will interact with the DXi4000.

2 Click **Next** to continue.

Figure 19 NAS Wizard:
Protocol



Step 3: Windows

Note: If you selected the **UNIX/Linux (NFS)** option in the previous step, the wizard automatically skips this step. Continue with [Step 4: Add Share](#) on page 46.

- 1 Select an option for joining the DXi4000 to the Windows network (see [Figure 20](#)):
 - **Active Directory** - Add the DXi4000 to a Windows network using Active Directory
 - **Workgroup** - Add the DXi4000 to a workgroup on a Windows network

Note: To disjoin a domain, see [Windows Domain](#) on page 146.

- 2 In the **Domain/Workgroup Name** box, enter the name of the domain or workgroup the DXi4000 is joining.
- 3 (Active Directory only) Enter information about the primary domain controller:

- **Primary Domain Controller** - Select an option for the Primary Domain Controller (PDC):
 - **Use DNS Discovery** - Discover the PDC automatically.
 - **Specify Address** - Enter the fully qualified name or the IP address of the PDC.
- **Organization Unit** - (Optional) Enter the name of the organizational unit in the domain.

The DXi4000 will become a member of this organization.

- **Administrator Name** - Enter **Administrator** or any user that has the right to join the domain.

By default, any user belonging to the **Administrators** group or the **Domain Admins** group has the right to join the domain. In addition, any user can join the domain if they are specifically delegated this right by a member of the **Administrators** group.

- **Administrator Password** - Enter the password for the user entered above.

Note: To configure users, see [Share Access](#) on page 149.

4 Click **Next** to continue.

Figure 20 NAS Wizard:
Windows

The screenshot shows the 'Windows Domain Settings' wizard step. The interface includes a top navigation bar with 'Quantum', 'DX:4601', and user information. A left sidebar lists various wizard sections like 'Welcome', 'NAS', 'OST', 'Replication', 'Email Alerts', 'Support', and 'Exit'. The main content area is titled 'Windows Domain Settings' and contains the following configuration options:

- Windows Domain**: A sub-header for the current step.
- Domain Type**: Radio buttons for 'Active Directory' (selected) and 'Workgroup'.
- * Domain/Workgroup Name**: A text input field.
- Primary Domain Controller**: Radio buttons for 'Use DNS Discovery' (selected) and 'Specify Address'.
- Organization Unit**: A text input field.
- * Administrator Name**: A text input field.
- * Administrator Password**: A text input field.

At the bottom of the form, there are '< Previous' and 'Next >' buttons. A note at the bottom indicates '* Required Field'.


Step 4: Add Share

- 1 Under **Add Share**, enter information about the NAS share (see [Figure 21](#)):
 - **Name** - Enter the name of the NAS share.
 - **Description** - (Optional) Enter a brief description of the share.
 - **Enable deduplication** - Select the check box to enable data deduplication. Quantum recommends that you enable data deduplication to optimize disk usage.

Note: Data deduplication is enabled by default. You cannot enable or disable data deduplication after the share is added.

 - **Hide from network browsing** - (Windows shares only) Select the check box to hide the share from network browsing. If selected, you cannot see the share when browsing the network.
 - **Export Protocol** - (Available only if you selected the **Both** option in [Step 2: Protocol](#) on page 43) Select the export protocol for the share:
 - **CIFS** - Select the CIFS option to use the share on a Windows network.
 - **NFS** - Select the NFS option to use the share on a UNIX or Linux network.
- 2 Click **Add**.
- 3 (Optional) To add additional shares, repeat Steps 1–2.
- 4 Click **Next** to continue.


Figure 21 NAS Wizard: Add Share



Step 5: Confirm

- 1 Review the settings you selected to make sure they are correct (see [Figure 22](#)). If necessary, click **Previous** to return to a previous step to make changes.
- 2 To make changes to a NAS share you added, first select the share and click **Delete** to delete the share. Then click **Previous** to return to the previous step and add a new share.
- 3 After you have confirmed all settings, click **Finish**. The wizard configures the DXi4000 with the settings you selected.

Figure 22 NAS Wizard:
Confirm



OST Wizard

The **OST** wizard provides guided assistance for configuring the DXi4000 to present its storage as one or more OST (OpenStorage) storage servers for use with a backup application. The wizard guides you through the process of adding one or more OST storage servers, configuring LSUs (logical storage units), and adding OST users. The wizard also provides a link for downloading and installing the OST Plug-in on your backup host.

Note: You cannot use the OST wizard to edit existing storage servers or LSUs. For more information about working with OST, see [OST](#) on page 162.


To begin the **OST** wizard, on the **Wizards** menu, click **OST**.

Step 1: About

- 1 Read the information about the wizard (see [Figure 23](#)).
- 2 Click **Next** to continue.

Note: At any time while using the wizard, you can click **Previous** to return to the previous step.

Figure 23 OST Wizard: About



Step 2: Add Storage Servers

- 1 Under **Add Storage Server**, enter information about the storage server (see [Figure 24](#)):
 - **Name** - Enter the name of the storage server.
 - **Max Connections** - Enter the maximum number of connections allowed to the storage server (3 to 65536).


Note: Quantum recommends setting **Max Connections** to 300.

- 2 Click **Add**.
The storage server displays in the **Storage Servers Added** table.
- 3 (Optional) To add additional storage servers, repeat Steps 1–2.

To remove a storage server, select it in the **Storage Servers Added** table and click **Delete**.

4 Click **Next** to continue.

Figure 24 OST Wizard: Add Storage Servers



Step 3: Add LSUs

1 Enter information about the LSU (see [Figure 25](#)).

- **Storage Server** - Select the storage server that will contain the new LSU.
- **Use Available Capacity** - Select this option to add an LSU that uses the available capacity on the system.

You cannot add an available capacity LSU to a storage server that already contains an LSU. Also, if you add an available capacity LSU to a storage server, you cannot add additional LSUs to that same storage server.

Note: After you add an LSU that uses the **Available Capacity** option, you cannot change the LSU to use the **Specific Capacity** option. Instead, you must delete the LSU, then add a new LSU and choose the **Specific Capacity** option (see [Deleting an LSU](#) on page 173).

- **Specify Capacity** - Select this option to specify the physical capacity of the LSU, and then enter the following information.
 - **LSU Name** - Enter the name of the LSU.
 - **Physical Capacity** - Enter the physical capacity of the LSU (1 to 1048576 GB).

2 Click **Add**.


The LSU displays in the **LSUs Added** table.

3 (Optional) To add additional LSUs, repeat Steps 1–2.

To remove an LSU, select it in the **LSUs Added** table and click **Delete**.

4 Click **Next** to continue.

Figure 25 OST Wizard: Add LSUs



Step 4: Add Users

1 Enter information about the authenticated user (see [Figure 26](#)):

- **Username** - Enter the name of the authenticated user.
- **Password** - Enter the password for the authenticated user.
- **Confirm Password** - Enter the password again to confirm it.
- **Description** - (Optional) Enter a brief description of the authenticated user.

2 Click **Add**.


The user displays in the **Users Added** table.

3 (Optional) To add additional users, repeat Steps 1–2.

To remove a user, select it in the **Users Added** table and click **Delete**.

4 Click **Next** to continue.


Figure 26 OST Wizard: Add Users



Step 5: Confirm

- 1 Review the settings you selected to make sure they are correct (see [Figure 27](#)). The items to be added display in the **Storage Servers Added**, **LSUs Added**, and **Users Added** tables. If necessary, click **Previous** to return to a previous step to make changes.
- 2 To make changes to storage servers, LSUs, or users you added, click **Previous** to return to the appropriate step. Select the incorrect item and click **Delete** to remove it, and then add a new item.
- 3 After you have confirmed all settings, click **Finish**. The wizard configures the DXi4000 with the settings you selected.
- 4 Click **Yes** to continue with downloading the OST Plug-in.

Figure 27 OST Wizard:
Confirm




Step 6: Download OST Client Plug-In

To download the OST Plug-in, click **Client Plug-in Download** (see [Figure 28](#)). On the download page, download the correct OST Plug-in for your backup application and operating system.

Also on the download page, click **Installation Instructions**, to download the *OST Plug-in Installation Instructions*. Follow the instructions to install the OST Plug-in on your media server.

Figure 28 OST Wizard:
Download OST Client Plug-in



Replication Wizard

The **Replication** wizard provides guided assistance for configuring the DXi4000 to send replicated data to another DXi system as part of disaster recovery plan. The wizard can also help you configure the DXi4000 to receive replicated data from another DXi system.

Sources *send* replicated data, and targets *receive* replicated data. A target system can receive data from up to 10 sources. However, a source system can send data to only a single target. Finally, one system can act as both a source and a target.

Note: For more information about working with data replication, see [DXi4000 Replication](#) on page 81.

Note: Use the **Replication** wizard (or the **Configuration > Replication** page) to configure other DXi systems that this DXi4000 is configured to send replicated data to or receive replicated data from. You should configure a target system before configuring source systems.


To begin the **Replication** wizard, on the **Wizards** menu, click **Replication**.

Step 1: About

- 1 Read the information about the wizard (see [Figure 29](#)).
- 2 Click **Next** to continue.

Note: At any time while using the wizard, you can click **Previous** to return to the previous step.

Figure 29 Replication Wizard:
About



Step 2: System

- 1 If data on this DXi4000 will be replicated to another DXi system, enter the following information under **Target DXi** (see [Figure 30](#)):
 - a In the **Target Hostname or IP Address** box, enter the hostname or IP address of the system that will receive the replicated data.

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.

Note: To use hostname format, you must specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184).

- b** In the **Source IP Address** field, enter the IP address that is used to uniquely identify the source DXi to the target. This may be different than the actual network IP address of the source DXi.

If the target system is at DXi 2.1 Software or higher, this field is not required. If the target system is at DXi 2.0.1.x Software or below, then you must enter the IP address by which the target system recognizes the source system. The default value is **0.0.0.0**.

- c** (Optional) Leave the **Encrypt data before replication** check box selected to enable encryption when sending replication data to the target system. Or clear the **Encrypt data before replication** check box to disable encryption when sending replication data to the target system.

If encryption is enabled, select an encryption strength (**128-bit** or **256-bit**). Using 256-bit encryption (default) provides a stronger level of security but may have an impact on system performance in some situations.

Caution: Select 128-bit encryption if you are sending data to a DXi running a system software version prior to DXi 2.1 Software.

Note: Encryption is enabled by default. However, for best performance, if your data network is already secured, you should clear the **Encrypt data before replication** check box.

- 2** If data on other DXi systems will be replicated to this DXi4000, enter the following information under **Source DXis**:

- a** In the **Source Hostnames or IP Addresses** box, enter the hostname or IP address of the system that will send the replicated data to the DXi4000.


To enter multiple sources, press **<Enter>** after each entry. You can specify up to 10 replication sources.

- b In the **Maximum Snapshots Per Share** drop-down box, select the number of snapshots to retain for each replicated share (up to 24).

During scheduled or manual data replication, the DXi4000 receives a snapshot from the source system. A snapshot contains all of the data necessary to fully recover or failback a NAS share to the point in time when the snapshot was saved.

- 3 Click **Next** to continue.

Figure 30 Replication Wizard: System



Step 3: NAS Shares

- 1 Select a NAS share in the **Replication Settings for NAS Shares** section to manage its replication settings (see [Figure 31](#)).

Note: For help adding NAS shares to the system, use the **NAS Configuration Wizard** (see [NAS Wizard](#) on page 42).

- 2 To configure the share to replicate its data to another DXi system, enter the following information under **Send**:
 - a Select the **Enable replication for selected share** check box to enable replication for the share.
 - b (Recommended) Select the **Enable scheduled replication** check box to enable scheduled replication for the share.

Caution: A saved snapshot is necessary to recover your data at a later time. For this reason, it is not enough to simply enable replication for a share. You must also configure a replication schedule (recommended) or perform manual replication on a regular basis to send snapshots of the share to the target system.

- c If you enabled scheduled replication, select a schedule option and specify the replication frequency:
- **Daily at** - Specify the time to replicate the share every day.
 - **Every** - Specify the hourly interval at which to replicate the share and the starting time.

- d (Optional) Select the **Enable Directory/File based replication to target** check box to enable Directory/File Based Replication for the share, and then enter a **Sync ID** in the box.

With Directory/File Based Replication, a file is automatically replicated when it is closed or a period of time after it is modified. After replication, the replicated files are immediately available on the target system.

The Sync ID is used to identify the target share that will receive replicated data from the source share. The Sync ID *must* be identical to the Sync ID of the target share on the target system.

- 3 To configure the share to receive replicated data from another DXi system, enter the following information under **Receive**:

- a (Optional) Select the **Enable Directory/File based replication to this DXi** check box to enable Directory/File Based Replication for the share, and then enter a **Sync ID** in the box.

The Sync ID is used to identify the source share that will send replicated data to the target share. The Sync ID *must* be identical to the Sync ID of the source share on the source system.


- b If you enabled Directory/File Based Replication, select an **Access** option:
- **Locked** - The share is not allowed to receive new Directory/File Based Replication data.

- **Unlocked** - The share is allowed to receive new Directory/ File Based Replication data.

Note: You cannot configure a share to both send and receive Directory/File Based Replication data.

- 4 Click **Apply**.
- 5 (Optional) To configure additional shares for replication, repeat Steps 1–4.
- 6 Click **Next** to continue.

Figure 31 Replication Wizard:
NAS Shares




Step 4: Confirm

- 1 Review the settings you selected to make sure they are correct. If necessary, click **Previous** to return to a previous step to make changes (see [Figure 32](#)).
- 2 After you have confirmed all settings, click **Finish**. The wizard configures the DXi4000 with the settings you selected.

Note: At any time while using the wizard, you can click **Previous** to return to the previous step.

Figure 33 Email Alerts Wizard:
About



Step 2: Server

- 1 In the **Hostname or IP Address** box, enter the hostname or IP address of the outgoing e-mail server (see [Figure 34](#)).

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.


Note: To use hostname format, you must specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184).

- 2 In the **From Email Address** box, enter the return e-mail address displayed in e-mails sent by the DXi4000.

Specify a return address that lets you easily identify the system that generated the e-mail (for example, systemname@any-domain.com). The return address must contain an @ symbol and a valid domain name, including a period.

3 Click **Next** to continue.

Figure 34 Email Alerts Wizard:
Server



Step 3: Recipients

1 Under **Add Email Recipient**, enter information about the recipient (see [Figure 35](#)):

- **Name** - The name of the recipient.
- **Email Address** - The e-mail address of the recipient.
- **Notification Type** - Select the types of notifications to send to the recipient:
 - **High** - Send e-mail notifications for High service tickets.
High service tickets indicate that a critical problem has occurred and needs to be resolved immediately. The operation and performance of the DXi4000 are degraded, and there is a risk of system failure or data loss.
 - **High and Medium** - Send e-mail notifications for High and Medium service tickets.
Medium service tickets indicate that a serious problem occurred and needs to be resolved, but it does not necessarily need to be fixed immediately. The operation and performance of the DXi4000 may be degraded.

- **All** - Send e-mail notifications for High, Middle, and Low service tickets, as well as any administration alerts.
Low service tickets indicate that a minor problem occurred and needs to be resolved, but the operation and performance of the DXi4000 are not significantly affected.

- 2 Select the **Notification Enabled** check box to enable sending of notifications to the recipient.
- 3 Click **Add**.
- 4 (Optional) To add additional recipients, repeat Steps 1–3
- 5 Click **Next** to continue.


Figure 35 Email Alerts Wizard: Recipients

The screenshot shows the Quantum DXi4000 configuration wizard interface. At the top, it displays 'Quantum DXi4000' with a 'Normal' status indicator, the date and time 'Thu Dec 8 2011 - 10:32:23 AM PST', and user information 'Admin'. Below this, there are buttons for 'Ticket' and 'Low Capacity', and links for 'Logout', 'Administrator', and 'Help'. The main navigation bar shows 'Wizards' and four steps: '1 About', '2 Server', '3 Recipients', and '4 Confirm'. On the left, a sidebar contains buttons for 'Welcome', 'NAS', 'OST', 'Replication', 'Email Alerts' (which is highlighted), 'Support', and 'Exit'. The main content area is titled 'Add Email Alert Recipients' and contains a modal window. The modal window has a title 'Add Email Recipient ?' and shows 'Total Recipients: 1'. It includes input fields for '* Name' and '* Email Address', a dropdown menu for 'Notification Type' set to 'High', and a checked checkbox for 'Notification Enabled'. A note indicates '* Required Field'. At the bottom of the modal are 'Add' and 'Reset ?' buttons. Below the modal are '< Previous' and 'Next >' buttons.

Step 4: Confirm

- 1 Review the settings you selected to make sure they are correct. If necessary, click **Previous** to return to a previous step to make changes (see [Figure 36](#)).
- 2 To make changes to an e-mail recipient you added, first select the recipient and click **Delete** to delete the recipient. Then click **Previous** to return to the previous step and add a new recipient.
- 3 After you have confirmed all settings, click **Finish**. The wizard configures the DXi4000 with the settings you selected.

Figure 36 Email Alerts Wizard:
Confirm



Support Wizard

The **Support** wizard provides guided assistance to help you enable licensed features on the DXi4000 and register your system with Quantum. The wizard also guides you through other tasks that will aid Quantum customer support in assisting you, such as downloading StorageCare Guardian and creating a system log.


To begin the **Support** wizard, on the **Wizards** menu, click **Support**.

Step 1: About

- 1 Read the information about the wizard (see [Figure 37](#)).
- 2 Click **Next** to continue.

Note: At any time while using the wizard, you can click **Previous** to return to the previous step.

Figure 37 Support Wizard:
About




Step 2: Registration

You must register your DXi4000 to receive service and support from Quantum.

- 1 Click the link for [Quantum's Product Registration](#) site (see [Figure 38](#)).
- 2 Follow the onscreen instructions to register your system.
- 3 When you are finished, switch back to the **Support** wizard.
- 4 Click **Next** to continue.

Figure 38 Support Wizard:
Registration



Step 3: Guardian

StorageCare Guardian is a remote monitoring and diagnostic solution that enables Quantum to monitor the health of Quantum systems over the Internet and use the intelligent diagnostics data to remotely service the equipment if issues arise.

StorageCare Guardian delivers more reliable backups and faster resolution time for customers at no additional cost for supported products under warranty or service contract.

- 1 Click the link to [learn more](#) about the features and benefits of StorageCare Guardian (see [Figure 39](#)).
- 2 Click the link to [download StorageCare Guardian](#), and then install it on a workstation with outgoing Internet access.

For more information, see the *StorageCare Guardian Installation Guide*. You can download a copy of the *Installation Guide* by clicking the link under **Documentation** on the StorageCare Guardian download page.

- 3 When you are finished, switch back to the **Support** wizard.
- 4 Click **Next** to continue.

Figure 39 Support Wizard:
Guardian



Step 4: System Log

This system diagnostics file contains the diagnostic logs for all of the system components. The diagnostic files are helpful when troubleshooting problems on the DXi4000. You should generate a system diagnostic file after setting up your DXi4000 and save it for future reference.

- 1 Click **Generate New** to generate a new system diagnostics file (see [Figure 40](#)).


The system generates a new diagnostics file. This can take several minutes.

- 2 After the file finishes generating, refresh the Web browser to enable the **Download Current** button.
- 3 To download the generated diagnostics file, click **Download Current**.

A dialog box displays asking if you want to open or save the file.

- 4 Click **Save** or **OK** to download the file.
- 5 Click **Next** to continue.

Figure 40 Support Wizard:
System Log



Step 5: Licensed Features

Add a license key to enable new functionality on the DXi4000. To install a license key, you must first obtain a License Certificate containing an authorization code.

Contact your Quantum sales representative to purchase a license. After you purchase the license, you will receive a License Certificate containing an authorization code.

Note: Some licenses are pre-installed on the DXi4000. For more information about licensed features, see [License Keys](#) on page 244.


- 1 Select the DXi system serial number (displayed under **Enable Licensed Features**) and press **<Ctrl+C>** to copy it (see [Figure 41](#)).
- 2 Click the link for [Quantum's License Key Management](#) site.
The **License Key Management** page displays.
- 3 Click to place the cursor in the **Serial Number** box and press **<Ctrl+V>** to paste the DXi system serial number.
- 4 Click **Submit**.
The **Licensed Feature** page displays.

- 5 Enter the authorization code (printed on the License Certificate) and click **Get License Key**.

The **Licensed Feature** page returns a license key. Select the license key and press **<Ctrl+C>** to copy it. You should also print out or write down the license key, or save it to a text file, for future use.

- 6 Switch back to the **Support** wizard.
- 7 Click to place the cursor in the **New Key** box and press **<Ctrl+V>** to paste the license key.
- 8 Click **Add**.
- 9 (Optional) To add additional license keys, repeat Steps 1–8.
- 10 Click **Finish** to complete the **Support** wizard.

Figure 41 Support Wizard:
Licensed Features





Chapter 5

DXi4000 Home Page

The first page that displays after you log on to the DXi4000 remote management console is the **Home** page (see [Figure 42](#)). Use the **Home** page to see important performance information at a glance, including disk usage, data reduction statistics, and replication activity.

To return to the **Home** page at any time, click **Home** on the main menu.

The **Home** page contains the following overviews:

- [DXi4000 System Overview](#)
- [Disk Usage Overview](#)
- [Data Reduction Statistics Overview](#)
- [Replication Overview](#)
- [Current Activity Overview](#)
- [Scheduled Activity Overview](#)

Note: Disk usage statistics, data reduction statistics, replication statistics, and current and scheduled activity are updated every 30 seconds.

Figure 42 Home Page




DXi4000 System Overview

The **DXi4000 System Overview** on the **Home** page (see [Figure 43](#)) displays the following information about the system:

- **Hostname** - The hostname of the DXi4000. Click to change the hostname (see [Network](#) on page 184).
- **IP Address** - The IP address of the DXi4000. Click to change the IP address (see [Network](#) on page 184).
- **Version** - The software version installed on the DXi4000. (To update the software, see [Software Upgrade](#) on page 248.)
- **Serial Number** - The serial number of the DXi4000. (You need to know the serial number to add a licensed feature. For more information, see [License Keys](#) on page 244.)

Figure 43 DXi4000 System
Overview



Disk Usage Overview

The **Disk Usage** overview on the **Home** page (see [Figure 44](#)) displays the following information about disk usage on the system:

Note: Values are displayed as an amount and as a percentage of the total capacity in the system.

Note: Click an item to view detailed statistics for disk usage (see [Disk Usage](#) on page 125).

- **Disk Capacity** - The total usable disk capacity of the DXi4000.

Note: (DXi4601 only) Click the **Quick Tip** icon [?] to see information about on demand storage capacity upgrades. For more information about upgrading storage capacity of the DXi4601, see [License Keys](#) on page 244.

- **Available Disk Space** - The disk space available for data storage (free space).

On the disk space meter, blue (left side of meter) indicates used disk space and gray (right side of meter) indicates available disk space. The left side of the meter changes color based on the amount of remaining free disk space and the state of the DXi4000:

- **I/O Write Low Threshold state (Yellow)** - Free disk space is equal to or less than $500\text{GB} + [10\text{GB} * (\text{Total system capacity in TB})]$

- **Stop Write state (Red)** - Free disk space is equal to or less than 250GB
- **Stop I/O state (Red)** - Free disk space is equal to or less than 10GB

Note: When disk space is low, click the **Quick Warning** icon [!] next to the space meter to see more information.


Note: When disk capacity is low, target replication to the system is paused (see [Replication Service](#) on page 110). In addition, space reclamation is automatically started to free up disk space (see [Space Reclamation](#) on page 240).

Click **Show More** to display additional information:

- **Used Disk Space** - The disk space that already holds data, including deduplicated data, system metadata, and data not intended for deduplication.
- **Deduplicated Data** - The amount of data that has been deduplicated.
- **Data Not Intended for Deduplication** - The amount of data on shares that do not have deduplication enabled.
- **System Metadata** - The amount of disk space used for internal operations of the DXi, including system configuration files as well as temporary files created during replication, space reclamation, and healthchecks.

Note: Used disk space includes data that is eligible for space reclamation. Because of this, it may appear that your system is using more disk space than you expected. Space is only reclaimed as needed to allow for optimal performance in the event you need to restore your data.

Figure 44 Disk Usage Overview



Data Reduction Statistics Overview

The **Data Reduction Statistics** overview on the **Home** page (see [Figure 45](#)) displays the following information about the results of data reduction:


Note: Click an item to view detailed statistics for disk usage (see [Disk Usage](#) on page 125).

- **Data Size Before Reduction** - The original, native size of all data that has been processed by the data deduplication and compression engines.
- **Data Size After Reduction** - The final, reduced size of all data that has been processed by the data deduplication and compression engines.
- **Total Reduction Ratio** - The total reduction ratio of all data that has been processed by the data deduplication and compression engines (**Data Size Before Reduction** divided by **Data Size After Reduction**).

Click **Show More** to display additional information:

- **Deduplication Ratio** - The deduplication ratio of all data that has been processed by the data deduplication engine.
- **Compression Ratio** - The compression ratio of all data that has been processed by the compression engine.

Figure 45 Data Reduction
Statistics Overview



A screenshot of a 'Data Reduction Statistics' box. The box has a light gray background and a thin border. It contains a table with five rows of statistics. At the bottom left of the box is a blue link labeled 'Show Less'.

Data Reduction Statistics	
Data Size Before Reduction	23.32 TB
Data Size After Reduction	2.56 TB
Total Reduction Ratio	9.10 : 1
Deduplication Ratio	6.04
Compression Ratio	1.51

[Show Less](#)

Replication Overview

The **Replication** overview on the **Home** page (see [Figure 46](#)) displays the following information about target and source replication activity:


- **Status** - The replication status of the DXi4000.
 - **Ready** - (Green) The system is ready to perform replication.
 - **In Progress** - (Blue) A replication job is currently in progress.
 - **Queued** - (Blue) A replication job is queued and will continue when the system is ready.
 - **Waiting** - (Blue) A replication job is waiting for another replication job to complete before beginning.
 - **Partial** - (Yellow) A replication job was partially completed. Generate a replication report to see the files that were not replicated (see [Reports](#) on page 112).
 - **Manually Paused** - (Yellow) Replication was manually paused. To resume replication, click **Resume**.
 - **System Paused** - (Yellow) The system has automatically paused replication due to a problem, for example, low disk space or a problem on the target system.

To see more information about the problem that occurred, click **Admin** at the top of the remote management console to view administration alerts (see [Admin Alerts](#) on page 129). You may also need to view alerts on the target DXi.

- **Failed** - (Red) A replication job was not completed.
- **Internal Error** - (Red) An error occurred during replication.
- **Pause** - Click to pause replication activity.
- **Resume** - Click to resume replication activity.
- **Send Settings & Cumulative Statistics** - Statistics for all data sent from the system since system installation or since **Send** cumulative replication statistics were last cleared by clicking **Clear Send** on the **Replication Actions** page (see [Replication Performance](#) on page 111).
 - **Target DXi** - The hostname or IP address of the target system that the DXi4000 is configured to replicate data to. Click to specify a replication target (see [Replication Send](#) on page 157).
 - **Original Data Size** - The original, native size of data sent during replication or failback. This value does not represent the amount of data actually sent over the network during replication or failback because data is deduplicated and compressed before being sent.
 - **Actual Data Sent** - The amount of data actually sent over the network during replication or failback. This value is usually much less than the **Original Data Size** due to the benefits of data deduplication and compression.
 - **Average Send Rate** - The average send rate (in MB/s) of data sent over the network during replication or failback (**Actual Data Sent** divided by the amount of time required to complete replication or failback).
- **Receive Settings & Cumulative Statistics** - Statistics for all data received by the system from all sources since system installation or since **Receive** cumulative replication statistics were last cleared by clicking **Clear Receive** on the **Replication Actions** page (see [Replication Performance](#) on page 111).
 - **Source DXis** - The number of source systems configured to replicate data to the DXi4000. Click to specify replication sources (see [Replication Receive](#) on page 159).
 - **Actual Data Received** - The amount of data actually received over the network during replication or failback. Click to view detailed statistics for replication (see [Replication Receive](#) on page 159).

- **Average Receive Rate** - The average receive rate (in MB/s) of data received over the network during replication or failback (**Actual Data Received** divided by the amount of time required to complete replication or failback). Click to view detailed statistics for replication (see [Replication Receive](#) on page 159).

Figure 46 Replication Overview



Current Activity Overview

The **Current Activity** overview on the **Home** page (see [Figure 47](#)) displays the following information about system activity that occurred in the previous minute:

- **Inline** - The inline data flow throughput (in MB/s). Inline data flow includes deduplicated and non-deduplicated backup data as well as received replication data. Click to view detailed statistics for inline performance (see [Inline](#) on page 120).
- **Ethernet** - The amount of data received (**In**) and sent (**Out**) by all Ethernet ports (in MB/s). Click to view details statistics for Ethernet performance (see [Ethernet](#) on page 121).
- **Space Reclamation** - The status of space reclamation (**Not running** or **Percent complete**). Click to start or stop space reclamation (see [Space Reclamation](#) on page 240).


- **Accent** - DXi Accent activity for all DXi Accent enabled media servers.

Note: DXi Accent activity displays only if DXi Accent is currently enabled or was previously enabled (see [DXi Accent](#) on page 177).

- **Inline (Accent)** - The inline data flow throughput (in MB/s). Inline data flow represents the original, native size of the data protected by the DXi.
- **Ethernet In (Accent)** - The amount of data received by all Ethernet ports (in MB/s). This amount represents the reduced size of the data protected by the DXi (after deduplication and compression on the media servers).
- **Accent Bandwidth Reduction** - The percentage by which network bandwidth utilization was reduced by enabling Accent.

Note: For more detailed information about all system activity, see [DXi4000 Status](#) on page 113.

Figure 47 Current Activity Overview



Scheduled Activity Overview

The **Scheduled Activity** overview on the **Home** page (see [Figure 48](#)) displays the following information about scheduled system activity:

- **Space Reclamation Schedule** - The schedule for space reclamation activity. Click to configure a space reclamation schedule (see [Schedule](#) on page 242).
- **NAS Replication** - NAS shares scheduled for replication.
 - **Scheduled Shares** - The number of shares scheduled for replication. Click to configure a share for scheduled replication (see [Configuring a Replication Schedule For a Share](#) on page 93).

Click **Show More** to display additional information:

- **Name** - The name of the NAS share scheduled for replication.
- **Schedule** - The schedule for replication of the NAS share.

Figure 48 Scheduled Activity Overview

The screenshot displays the 'Scheduled Activity' overview. It is divided into two main sections: 'Space Reclamation' and 'NAS Replication'. Under 'Space Reclamation', the schedule is listed as 'Daily @ 01:00 PM'. Under 'NAS Replication', it shows 'Scheduled Shares' as '3' and includes a 'Show Less' link. Below this is a table with two columns: 'Name' and 'Schedule'.

Name	Schedule
thor_nfs03	Every 6 Hours starting at 10:00 AM
thor_cifs01	Every 8 Hours starting at 11:00 AM
thor_nfs01	Daily @ 06:00 PM



Chapter 6

DXi4000 Replication

The DXi4000 provides data replication capabilities that you can use as an integral part of a disaster recovery plan. Replication allows you to configure the DXi4000 to create a copy of your data on another DXi system at scheduled intervals (or manually as needed).

In the event of a disaster in which the original data is lost, you can quickly recover the replicated data on the remote system, allowing your business to resume normal operations. Once the original system is available again, you can restore all data back to its original location.

Note: Quantum recommends that you configure and start replication before storing large amounts of data on the DXi4000.

See the following sections for more information about the data replication capabilities of the DXi4000:

- [Understanding Data Replication](#)
- [Performing Data Replication](#)

Understanding Data Replication

During data replication, data is sent from one system (the source) to another system, usually in another location (the target). For example, you might replicate data from a branch office (the source) to a central office (the target).

Sources *send* replicated data, and targets *receive* replicated data. A target system can receive data from up to 10 sources. However, a source system can send data to only a single target. Finally, one system can act as both a source and a target.

Replication works only with deduplicated data, and data is compressed before it is replicated. Because of this, the amount of data transmitted between systems during replication is greatly reduced compared to the original amount of data stored. In addition, a data block is transmitted only if the target does not already have a copy of the block. Finally, data can optionally be encrypted before it is transmitted.

The DXi4000 can perform the following types of replication:

- [Replication](#)
- [Directory/File Based Replication](#)
- [OST Optimized Duplication](#)

Replication

Replication occurs when replication is enabled for a deduplicated NAS share and a replication schedule is configured (or manual replication is performed on a regular basis). For replication to occur, the source system must be configured to point to the target system. Similarly, the target system must be configured to accept data from the source system.

To optimize the replication process, deduplicated data is continuously sent in the background from the source system to the target system. However, a snapshot that preserves the file structure of your data is sent to the target system only when a scheduled or manual replication job occurs. A snapshot contains all of the information that is necessary to recreate a share just as it was at the point in time when the snapshot was created.

Caution: A saved snapshot is necessary to recover your data at a later time. For this reason, it is not enough to simply enable replication for a share. You must also configure a replication schedule (recommended) or perform manual replication on a regular basis to send snapshots of the share to the target system.

If the source system ever becomes unavailable, you can recover the share on the target system using a saved snapshot. After you recover a share, it is recreated on the target system and is available for use. Once the source system becomes available again, you can perform a failback operation to restore the share to its original location.

Directory/File Based Replication

Like replication, Directory/File Based Replication sends data from a NAS share to another system where it can be accessed. However, Directory/File Based Replication differs in a number of important ways:

- Both replication and Directory/File Based Replication must be enabled for the share.
- A unique Sync ID is used to associate the replicated share on the source system with the share that will receive the replicated data on the target system.
- You do not need to schedule or manually perform Directory/File Based Replication through the remote management console. Instead, replication is triggered when a file is closed or a period of time after it is modified (NAS shares).

Note: For CIFS shares, a file is replicated immediately after it is closed. For NFS shares, a file is replicated after it has been idle (not accessed) for several minutes.

- After directories and files are replicated using Directory/File Based Replication, they are automatically recovered on the target system and are immediately available for use. There is no need to first recover the share to access its data.
- Deletions are automatically propagated from the source system to the target system in order to free up space on the target. In addition, you can manually initiate a synchronization from the source system at any time. Synchronizing ensures that the contents

of the source share are exactly the same as the target share.

OST Optimized Duplication

The DXi4000 can duplicate the data on an LSU (logical storage unit) to another location using the OST optimized duplication (OST replication) feature supported by Symantec NetBackup and Backup Exec.

For information about configuring and using OST optimized duplication, see the *Symantec NetBackup OST Configuration Guide* and the *Symantec Backup Exec OST Configuration Guide*.

Performing Data Replication

The **Replication** page allows you to set up replication for NAS shares and to replicate and recover data.

To access the **Replication** page, click the **Replication** menu.

The **Replication** page contains the following tabs:

- [Send NAS](#)
- [Receive NAS](#)
- [Actions](#)
- [Reports](#)

Use the DXi4000 data replication features to perform the following tasks:

- Replicate all data on a share to another system where it can be recovered at a later time (see [Task Overview: Setting Up and Performing Replication](#) on page 85).
- Automatically replicate directories and files to another system where they are immediately available (see [Task Overview: Setting Up and Performing Directory/File Based Replication](#) on page 86).
- Recover data from a lost or damaged share (see [Task Overview: Recovering a Replicated Share](#) on page 87).
- Restore a lost or damaged share back to its original location (see [Task Overview: Performing a Share Failback](#) on page 87).

Note: The **Replication** wizard provides guided assistance for configuring data replication (see [DXi4000 Configuration Wizards](#) on page 41).

Task Overview: Setting Up and Performing Replication

To replicate all data on a NAS share from a source system to a target system:

- 1 On the target system, add the source system to the list of allowed replication sources (see [Replication Receive](#) on page 159).
- 2 On the source system, specify the target system that will receive replicated data (see [Replication Send](#) on page 157).
- 3 On the source system, create a new share with deduplication enabled (see [Adding a NAS Share](#) on page 142).
- 4 Enable replication for the new share (see [Enabling Replication For a Share](#) on page 92).
- 5 Before writing any data to the new share, replicate the new share (see [Replicating a Share](#) on page 95).

Quantum recommends that you always replicate a new share immediately after creating it. This establishes the initial data structure on the target system and greatly increases the speed of the first replication.

- 6 Choose one of the following methods to regularly replicate the new share:
 - (Recommended) Set up a schedule for performing replication automatically after backups complete (see [Configuring a Replication Schedule For a Share](#) on page 93).
 - Manually perform replication at frequent intervals (see [Replicating a Share](#) on page 95).

After replication, a snapshot is sent to the target system. You can use the snapshot to recover the replicated share on the target system (see [Task Overview: Recovering a Replicated Share](#) on page 87) or restore the share to its original location on the source system (see [Task Overview: Performing a Share Failback](#) on page 87).

Caution: If you do not configure a replication schedule or manually replicate the share on a regular basis, your data is *not* protected. While the DXi4000 continually sends data to the target system in the background to optimize the replication process, a snapshot that preserves the complete structure of your data is sent to the target system *only* when a scheduled or manual replication job occurs. If you do not regularly and frequently replicate your data as described in [Step 6](#) above, it cannot be restored at a later time.

Task Overview: Setting Up and Performing Directory/File Based Replication

To automatically replicate directories and files from a source system and immediately recover them for use on a target system:

- 1 Perform the following steps on the target system:
 - a Add the source system to the list of allowed replication sources (see [Replication Receive](#) on page 159).
 - b Create a new share with deduplication enabled (see [Adding a NAS Share](#) on page 142).
 - c Enable Directory/File Based Replication for the new share and specify the Sync ID (see [Configuring a Target Share for Directory/File Based Replication](#) on page 107).
- 2 Perform the following steps on the source system:
 - a Specify the target system that will receive replicated data (see [Replication Send](#) on page 157).
 - b Create a new share with deduplication enabled (see [Adding a NAS Share](#) on page 142).
 - c Enable Directory/File Based Replication for the new share and specify the Sync ID (see [Configuring a Source Share for Directory/File Based Replication](#) on page 93).

A file is automatically replicated when it is closed or a period of time after it is modified. After replication, the replicated directories and files are immediately available on the target system. There is no need to recover the share to make the directories and files available.

Task Overview: Recovering a Replicated Share

If a NAS share is lost or damaged on the source system, you can recover it on the target system using a received snapshot. When you recover a share, it is recreated on the target system just as it was at the point in time when the snapshot was saved.

To recover a replicated share:

- 1 On the target system, select a received snapshot and perform a recover operation (see [Recovering a Share](#) on page 99).

The share is now available on the target system.

- 2 (Optional) Map your backup application to the recovered share on the target system to continue making backups.
- 3 When the source system is operating correctly again, choose one of the following actions:
 - Failback the share to restore it on the original source system (see [Task Overview: Performing a Share Failback](#) on page 87). Then, if necessary, map your backup application to the restored share on the original source system.
 - Continue to make backups to the recovered share on the original target system. In addition, set up replication to replicate the share back to the original source system (see [Task Overview: Setting Up and Performing Replication](#) on page 85). In this scenario, the original source system is now the target, and the original target system is now the source.

Task Overview: Performing a Share Failback

If a NAS share is lost or damaged on the source system, you can failback the share to the source system using a received snapshot on the target system. When you failback a share, it is restored on the source system just as it was at the point in time when the snapshot was saved.

To perform a share failback:

- 1 On the original source system, add the original target system to the list of allowed replication sources (see [Replication Receive](#) on page 159).

Note: For the purposes of failback, the original source system is now acting as a target because it will receive the snapshot from the original target system.

- 2 On the original target system, select a received snapshot and perform a failback operation pointing to the original source system, and then recover the share on the original source system (see [Performing a Failback For a Share](#) on page 100).

The share is now available on the original source system.

- 3 (Optional) If necessary, map your backup application to the restored share on the original source system.


Send NAS

The **Send NAS** page allows you to manage outgoing replication activity for NAS shares. You can replicate shares on the DXi4000 (the source) to another DXi system that supports NAS (the target).

Note: Before you can replicate shares, you must specify the replication target (see [Replication Send](#) on page 157).

To access the **Send NAS** page, click the **Replication** menu, and then click the **Send > NAS** tab (see [Figure 49](#)).

Figure 49 Send NAS Page



Use the **Send NAS** page to perform the following tasks:

- View replication information for shares (see [Shares Eligible for Replication](#) on page 89).
- Enable or disable replication for a share (see [Enabling Replication For a Share](#) on page 92).
- Schedule replication for a share (see [Configuring a Replication Schedule For a Share](#) on page 93).
- Configure Directory/File Based Replication for a share (see [Configuring a Source Share for Directory/File Based Replication](#) on page 93).
- Initiate replication for a share (see [Replicating a Share](#) on page 95).
- Synchronize a share configured for Directory/File Based Replication (see [Synchronizing a Share](#) on page 95).
- View replication statistics for a share configured for Directory/File Based Replication (see [Directory/File Based Queue](#) on page 95).

Shares Eligible for Replication

The **Shares Eligible for Replication** section displays replication statistics for all NAS shares on the DXi4000 that are eligible for replication. To be eligible for replication, a share must have data deduplication enabled at the time it is created.

Note: For information about creating NAS shares, see [Adding a NAS Share](#) on page 142.

Note: If symlink and hard link support is enabled for an NFS share, replication cannot be enabled for the share, and the share will not appear in the **Shares Eligible for Replication** section. For information about enabling symlink and hard link support for a share, see the *DXi-Series Command Line Interface (CLI) Guide* (6-67081).

The **Shares Eligible for Replication** section displays the following information:

- **Replication Service** - The replication status of the DXi4000. Click **Pause** to pause replication activity. Click **Resume** to resume replication activity.

Note: For a detailed description of all possible replication statuses, see [Replication Overview](#) on page 76.

- **Current Replication Target DXi** - The hostname or IP address of the target system that the DXi4000 is configured to replicate data to. (To change the target system, see [Replication Send](#) on page 157.)
- **Cumulative Statistics** - Statistics for all data sent from the system since system installation or since cumulative replication statistics were last cleared. (To clear cumulative replication statistics, see [Replication Performance](#) on page 111.)
 - **Original Data Size** - The original, native size of data sent during replication or failback. This value does not represent the amount of data actually sent over the network during replication or failback because data is deduplicated and compressed before being sent.
 - **Actual Data Sent** - The amount of data actually sent over the network during replication or failback. This value is usually much less than the **Original Data Size** due to the benefits of data deduplication and compression.
 - **Average Send Rate** - The average send rate (in MB/s) of data sent over the network during replication or failback (**Actual Data Sent** divided by the amount of time required to complete replication or failback).
- **View Job Type** - Select an option to filter the list of NAS shares:
 - **All** - Displays all shares.
 - **Replication** - Displays shares with replication jobs.
 - **Synchronization** - Displays shares with synchronization jobs.
- **Share Name** - The name of the share.
- **Replication** - The replication state (**Enabled**, **Disabled**, or **scheduled**).
- **Sync ID** - The Sync ID of the share if Directory/File Based Replication is enabled.
- **Last Job Type** - The type of the most recent replication job (**Replication** or **Synchronization**).
- **Started** - The time the most recent replication job was started.

- **Finished** - The time the most recent replication job finished.
- **Status** - The status of the most recent replication job (see [Replication and Synchronization Status](#) on page 91). Click the status to display detailed information about the most recent replication job.

Note: Click a column heading to sort the rows in the table by that column. Click the column heading again to reverse the sort order.

Note: Click the **Information** button [i] next to a share to display detailed information about the share and recent replication activity.

Replication and Synchronization Status

A replication job can have one of the following statuses:

- **In Progress** - The replication job is in progress.
- **Partial** - The replication job was partially completed. Generate a replication report to see the files that were not replicated (see [Reports](#) on page 112).
- **Queued** - The replication job is queued and will continue when the system is ready.
- **Waiting** - The replication job is waiting for another job to complete before beginning.
- **Success** - The replication job was completed successfully.
- **Failed** - The replication job was not completed.

A synchronization job can have one of the following statuses:

- **Queued** - The synchronization job is queued and will continue when the system is ready.
- **Success** - The synchronization job was completed successfully.
- **Recovering** - The recover operation is in process.
- **Replicating** - The replication operation is in process.
- **Failed** - The synchronization job was not completed.

Enabling Replication For a Share

Enable replication for a NAS share to allow the share's data to be replicated to another DXi system (the target). Disable replication if you do not want to replicate the share's data to another DXi system.


Note: To be eligible for replication, a share must have data deduplication enabled at the time it is created.

To enable or disable replication for a share:

- 1 Select the share and click **Edit**.

The **Edit NAS Share** page displays (see [Figure 50](#)).

Figure 50 Edit NAS Share Page



- 2 Select the **Enable replication** check box to enable replication for the share.

Or clear the **Enable replication** check box to disable replication for the share.

- 3 Click **Apply**.

Note: Quantum recommends scheduling replication to run after backups are complete (see [Configuring a Replication Schedule For a Share](#) on page 93). If you do not enable scheduled replication, replication will only occur if you manually replicate a share (see [Replicating a Share](#) on page 95) or if you configure Directory/File Based Replication (see [Configuring a Source Share for Directory/File Based Replication](#) on page 93).

Configuring a Replication Schedule For a Share

Configure a replication schedule for a NAS share to automatically replicate the share's data to the target system at regular intervals. Disable scheduled replication if you do not want to automatically replicate the share's data to the target.

To configure a replication schedule for a share:

- 1 Select the share and click **Edit**.

The **Edit NAS Share** page displays (see [Figure 50](#)).

- 2 If it is not already selected, select the **Enable replication** check box to enable replication for the share.
- 3 Select the **Enable scheduled replication** check box to enable scheduled replication for the share.

Or clear the **Enable scheduled replication** check box to disable scheduled replication for the share.

- 4 Select a schedule option and specify the replication frequency:
 - **Daily at** - Specify the time to replicate the share every day.
 - **Every** - Specify the hourly interval at which to replicate the share and the starting time.

- 5 Click **Apply**.

Configuring a Source Share for Directory/File Based Replication

Configure a NAS share for Directory/File Based Replication to automatically replicate files to a target system. A file is automatically replicated when it is closed or a period of time after it is modified. After replication, the replicated files are immediately available on the target system. There is no need to recover the share to make the files available.

Disable Directory/File Based Replication if you do not want to automatically replicate files.

When you configure a share for Directory/File Based Replication, you specify a Sync ID for the share. The Sync ID associates the share on the source system with the share on the target system that will receive the replicated data. As long as you specify a matching Sync ID for both the source and target shares, the shares do not have to have the identical names. However, if you do not specify a Sync ID, the source and target shares must have identical names. Quantum recommends that you assign a matching Sync ID to the source and target shares.

Note: For information about specifying the Sync ID on the target share, see [Configuring a Target Share for Directory/File Based Replication](#) on page 107.

To configure a share for Directory/File Based Replication:

- 1 Select the share and click **Edit**.

The **Edit NAS Share** page displays (see [Figure 50](#)).

- 2 If it is not already selected, select the **Enable replication** check box to enable replication for the share.
- 3 Select the **Enable Directory/File Based replication to target Sync ID** check box to enable Directory/File Based Replication for the share.

Or clear the **Enable Directory/File Based replication to target Sync ID** check box to disable Directory/File Based Replication for the share.

- 4 Enter a **Sync ID** in the box.

The Sync ID is used to identify the target share that will receive replicated data from the source share. The Sync ID *must* be identical to the Sync ID of the target share on the target system.

- 5 Click **Apply**.

Note: After you configure a share for Directory/File Based Replication, you should periodically synchronize it to keep it in sync with the target share (see [Synchronizing a Share](#) on page 95).

Replicating a Share

Replicate a NAS share to send a snapshot of the share to the target system. A snapshot is required to recover the data on the share at a later time. If you have not configured a replication schedule for a share, replication only occurs when you manually initiate it (see [Configuring a Replication Schedule For a Share](#) on page 93).

Note: During replication, files that are in use on a share are skipped.

To replicate a share, select the share and click **Replicate Now**. The status of the replication job displays in the **Status** column.

To cancel the replication job, select the share and click **Abort Replication**.

Synchronizing a Share

Synchronize a NAS share to synchronize the contents of the share with the corresponding share on the target system. To synchronize a share, it must be configured for Directory/File Based Replication (see [Configuring a Source Share for Directory/File Based Replication](#) on page 93).

Synchronizing a share ensures that the contents of the source share are the same as the target share. The synchronization verifies that the same files exist in both locations, and that no additional files exist in either location.

Quantum recommends that you periodically perform a synchronization, and also that you also perform a synchronization before scheduled space reclamation.

Note: If replication is paused, always perform a synchronization after replication is resumed again. Any file deletions that occurred while replication was paused will be propagated from the source shares to the targets.

To synchronize a share, select the share and click **Synchronize Now**. The status of the synchronization job displays in the **Status** column.

To cancel the synchronization job, select the share and click **Abort Sync**.

Directory/File Based Queue

The Directory/File Based Queue displays replication statistics for shares that are configured for Directory/File Based Replication (see [Configuring](#)

[a Source Share for Directory/File Based Replication](#) on page 93).

To view the Directory/File Based Queue:

- 1 Select a share that is configured for Directory/File Based Replication.
- 2 Click **Dir/File Based Queue**.

The Directory/File Based Queue displays (see [Figure 51](#)).

Figure 51 Directory/File Based Queue



The Directory/File Based Queue displays the following information for the share:

- **File/Directory** - The file or directory to be replicated.
- **State** - The replication state for the file or directory.
- **Progress** - The percentage complete for replication of the file or directory.
- **Estimated Duration** - The estimated time it will take to complete replication for the file or directory.

Note: The estimated duration may display as **unknown** if replication has been very recently initiated. After the system has enough information to calculate a value, the estimated duration will display.

To update the statistics with the latest information, click **Refresh**.

Note: The contents of the Directory/File Based Queue are dynamic. Because of this, statistics are subject to change if items are added to the queue.

3 To return to the **Send NAS** page, click **OK**.

Receive NAS

The **Receive NAS** page allows you to manage incoming replication activity for NAS shares. You can recover a replicated share on the target system if the source system is unavailable. Once the source system becomes available, you can failback the share to make it available on the source system again.

Note: Before you can receive replicated shares, you must specify one or more replication sources (see [Replication Receive](#) on page 159).

To access the **Receive NAS** page, click the **Replication** menu, and then click the **Receive > NAS** tab.

Use the **Receive NAS** page to perform the following tasks:


- View received snapshots and recover, failback, or delete snapshots (see [Received Snapshots](#) on page 97).
- Manage recovery jobs (see [Recovery Jobs](#) on page 103).
- Manage failback jobs (see [Failback Jobs](#) on page 104).
- Manage shares configured for Directory/File Based Replication (see [Directory/File Based](#) on page 105).

Received Snapshots

The **Received Snapshots** page allows you to view and work with received snapshots. When a replicated NAS share is received from a source system, it is saved as a snapshot. The snapshot contains all of the data necessary to fully recover or failback the share to the point in time when the snapshot was saved.

To access the **Received Snapshots** page, on the **Receive NAS** page, click the **Received Snapshots** tab (see [Figure 52](#)).

Figure 52 Received Snapshots Page



Use the **Received Snapshots** page to perform the following tasks:

- View information about received snapshots (see [Snapshots List](#) on page 98).
- Recover a share on the target system (see [Recovering a Share](#) on page 99).
- Failback a share to the source system (see [Performing a Failback For a Share](#) on page 100).
- Delete a received snapshot (see [Deleting a Snapshot](#) on page 102).

Note: The target system will retain up to 10 replication snapshots (default setting) for each replicated share. Once 10 snapshots have been saved, the oldest snapshot is deleted to make room for each new snapshot that is received. (To change the maximum number of snapshots retained for each share, see [Replication Receive](#) on page 159).

Snapshots List

The **Snapshots List** displays all available snapshots that have been received from configured replication sources. Snapshots are grouped by

NAS share. To see all available snapshots for a share, click the plus icon [+] next to the share name.

The **Snapshots List** displays the following information about each snapshot:

- **Share Name** - The name of the share.
- **Source DXi** - The hostname of the system that the snapshot was sent from.
- **Started** - The time the most recent replication job was started.
- **Finished** - The time the most recent replication job finished.
- **Status** - The status of the most recent replication job (see [Replication and Synchronization Status](#) on page 91). Click the status to display detailed information about the most recent replication job.

Note: Click a column heading to sort the rows in the table by that column. Click the column heading again to reverse the sort order.

Recovering a Share

Recover a NAS share if the source system is unavailable and you need to access the share (for example, to continue performing backups). When you recover a share, you select a received snapshot. The DXi4000 uses the snapshot to recreate the share on the target system just as it was at the point in time when the snapshot was saved.


Note: Before recovering a share, you must enable CIFS on the DXi (see [Windows Domain](#) on page 146). Also, if the DXi is not using Active Directory, you must configure at least one workgroup user to own recovered CIFS shares (see [Share Access](#) on page 149).

To recover a share:

- 1 On the target system, select a snapshot in the **Snapshots List** and click **Recover**.

The **Recovered Share Name** page displays (see [Figure 53](#)).

Figure 53 Recovered Share
Name Page



- 2 (Optional) In the **Recovered Share Name** box, type a new name for the recovered share. (The default name is the original share name.)
- 3 Click **Apply**.
- 4 If the DXi is joined to a Windows workgroup, select the workgroup user that will own the recovered share, and then click **Apply**.

The share is recovered on the target system. All data stored on the share at the time the snapshot was saved is available. The original export protocol of the share (NFS or CIFS) is retained in the recovery process.

Note: After you recover a share, if you want to continue backing up data to the share, you must remap your backup application to point to the target system instead of the source system.

Performing a Failback For a Share

Perform a failback of a NAS share if a source system that was previously unavailable becomes available again. When you failback a share, you select a received snapshot. The DXi4000 copies the snapshot from the target system back to the source system. You can then perform a recover operation to recreate the share on the source system just as it was at the point in time when the snapshot was saved.


Note: Before you can failback a share, on the original source system, you must add the original target system to the list of allowed replication sources (see [Replication Receive](#) on page 159). This is because, during failback, the original target is acting as a source when it sends a snapshot to the original source.

To perform a share failback:

- 1 On the target system, select a snapshot in the **Snapshots List** and click **Failback**.

The **Failback Target** page displays (see [Figure 54](#)).

Figure 54 Failback Target Page



- 2 (Optional) In the **Failback Destination DXi** box, type the hostname or IP address of a new destination system to failback the share to. (The default destination is the original source system.)

Note: To use hostname format, you must specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184).

- 3 (Optional) Leave the **Use Encryption** check box selected to enable encryption when sending the snapshot to the destination. Or clear the **Use Encryption** check box to disable encryption when sending the snapshot to the destination.

If encryption is enabled, select an encryption strength (**128-bit** or **256-bit**). Using 256-bit encryption (default) provides a stronger level of security but may have an impact on system performance in some situations.

Caution: Select 128-bit encryption if you are sending data to a DXi running a system software version prior to DXi 2.1 Software.

Note: Encryption is enabled by default. However, for best performance, if your data network is already secured, you should clear the **Use Encryption** check box.

4 Click **Apply**.

The snapshot is sent to the source system.

5 On the source system, in the **Snapshots List**, select the snapshot that was sent during the failback operation and click **Recover**.

The **Recovered Share Name** page displays (see [Figure 53](#)).

6 (Optional) In the **Recovered Share Name** box, type a new name for the recovered share. (The default name is the original share name.)

7 Click **Apply**.

The share is recovered on the source system. All data stored on the share at the time the snapshot was saved is available. The original export protocol of the share (NFS or CIFS) is retained in the recovery process.

Note: If you previously remapped your backup application to a recovered share on the target system, after you failback the share, you must remap your backup application again to point to the source system.

Deleting a Snapshot

Delete a snapshot if it is no longer needed. After you delete a snapshot, it can no longer be used to recover or failback a NAS share.

Note: You cannot delete a snapshot if a failback operation is in progress for the snapshot. Wait for the failback operation to complete, or abort the operation (see [Failback Jobs](#) on page 104).

To delete a snapshot:

- 1 Do one of the following actions:
 - On the source system, disable replication for the share associated with the snapshot (see [Enabling Replication For a Share](#) on page 92).
 - On the target system, delete the source system associated with the snapshot from the list of allowed replication sources (see [Replication Receive](#) on page 159).
- 2 On the target system, select a snapshot in the **Snapshots List** and click **Delete**.

Note: You cannot delete a snapshot if it is the last received snapshot for a share.


- 3 Click **Yes** to confirm the action.

Recovery Jobs

The **Recovery Jobs** page allows you to view information about snapshot recover operations that were previously completed.

To access the **Recovery Jobs** page, on the **Receive NAS** page, click the **Recovery Jobs** tab (see [Figure 55](#)).

Figure 55 Recovery Jobs Page



The **Snapshot Recovery Jobs** section displays the following information about recovery jobs:

- **Original Share Name** - The name of the share the snapshot was created from.
- **New Share Name** - The name of the share the snapshot was recovered to.
- **Source DXi** - The hostname of the system that the snapshot was received from.
- **Started** - The time the recovery job was started.
- **Finished** - The time the recovery job finished.
- **Status** - The status of the recovery job (**Success**, **In Progress**, or **Failed**).


To delete information for a recovery job, select it in the **Snapshot Recovery Jobs** list and click **Delete Job Info**.

Failback Jobs

The **Failback Jobs** page allows you to view information about snapshot failback operations that were previously completed. You can also abort a failback that is currently in progress.

To access the **Failback Jobs** page, on the **Receive NAS** page, click the **Failback Jobs** tab (see [Figure 56](#)).

Figure 56 Failback Jobs Page



The **Snapshot Failback Jobs** section displays the following information about failback jobs:

- **Share Name** - The name of the share the snapshot was created from.
- **Destination DXi** - The hostname of the system that the snapshot was sent to.
- **Started** - The time the failback job was started.
- **Finished** - The time the failback job finished.
- **Status** - The status of the failback job (**Success**, **In Progress**, or **Failed**).

Use the **Failback Jobs** page to perform the following tasks:

- To delete information for a failback job, select it in the **Snapshot Failback Jobs** section and click **Delete Job Info**.
- To abort a failback job that is in progress, select it in the **Snapshot Failback Jobs** section and click **Abort**.


Directory/File Based

The **Directory/File Based** page allows you to manage Directory/File Based Replication on the target system. You can configure a NAS share to receive Directory/File Based Replication data sent from a source system and view replication statistics for the share.

Note: For information about creating NAS shares, see [Adding a NAS Share](#) on page 142.

To access the **Directory/File Based** page, on the **Receive NAS** page, click the **Directory/File Based** tab (see [Figure 57](#)).

Figure 57 Directory/File Based Page



Use the **Directory/File Based** page to perform the following tasks:

- View shares eligible to receive Directory/File Based data (see [Shares Eligible to Receive Directory/File Based Data](#) on page 106)
- Configure a share to receive Directory/File Based Replication data (see [Configuring a Target Share for Directory/File Based Replication](#) on page 107)
- View statistics for shares configured for Directory/File Based Replication (see [Unpack Queue](#) on page 108)

Shares Eligible to Receive Directory/File Based Data

The **Shares Eligible to Receive Directory/File Based Data** section displays information for all NAS shares on the DXi4000 that are eligible to receive Directory/File Based Replication data from a source share. To be eligible to receive Directory/File Based Replication data, a share must have data deduplication enabled at the time it is created.

The **Shares Eligible for Replication** section displays the following information:

- **Share Name** - The name of the share.
- **State** - The state of Directory/File Based Replication for the share (**Enabled** or **Disabled**).
- **Sync ID** - The Sync ID used to identify the source share that will send replicated data to the share.
- **Access** - The selected access option for the share (**Locked** or **Unlocked**).

Note: Click the Information button [i] next to a share to display detailed information about the share and recent replication activity.

Configuring a Target Share for Directory/File Based Replication

Configuring a NAS share for Directory/File Based Replication enables the automatic replication of files and directories on the source share to the target share. Before you configure a share on the source system for Directory/File Based Replication, you must configure a share on the target system to receive the replicated data from the source share.


Note: For information about configuring Directory/File Based Replication on the source system, see [Configuring a Source Share for Directory/File Based Replication](#) on page 93.

To configure a target share for Directory/File Based Replication:

- 1 Select the share and click **Edit**.

The **Edit Share Settings** page displays (see [Figure 58](#)).

Figure 58 Edit Share Settings
Page



2 Select the **Enable to receive Directory/File Based replication data** check box to enable Directory/File Based Replication for the share.

Or clear the **Enable to receive Directory/File Based replication data** check box to disable Directory/File Based Replication for the share.

3 Enter a **Sync ID** in the box.

The Sync ID is used to identify the source share that will send replicated data to the target share. The Sync ID *must* be identical to the Sync ID of the source share on the source system.

4 Select an **Access** option:

- **Locked** - The share is not allowed to receive new Directory/File Based Replication data.
- **Unlocked** - The share is allowed to receive new Directory/File Based Replication data.


5 Click **Apply**.

Unpack Queue

Use the **Unpack Queue** to view Directory/File Based Replication statistics for data received from the source system.

To view the **Unpack Queue**, select a share and click **View Unpack Queue** (see [Figure 59](#)).

Figure 59 Unpack Queue



The **Unpack Queue** displays the following information:

- **File/Directory** - The file or directory to be replicated.
- **State** - The replication state of the file or directory.


Click **Refresh** to update the statistics in the Unpack Queue. Click **OK** to return to the **Directory/File Based** page.

Actions

The **Actions** page allows you to manage replication activity on the DXi4000. You can pause the replication service, enable the replication state, and clear performance statistics.

To access the **Actions** page, click the **Replication** menu, and then click the **Actions** tab (see [Figure 60](#)).

Figure 60 Actions Page



Use the **Actions** page to perform the following tasks:

- Pause or resume the replication service (see [Replication Service](#) on page 110).
- Enable or disable the replication state (see [Replication State](#) on page 111).
- Clear cumulative replication statistics (see [Replication Performance](#) on page 111).

Replication Service

The replication service controls replication and failback traffic on the DXi4000.

- Click **Pause** to pause all replication and failback traffic.

If a replication job is currently in progress, the system continues to replicate the current block of data. The process of replicating the current block can take up to 15 minutes to complete. After the block has completed replication, the system pauses replication.

Note: If you pause a replication job that is in process, a Failure event is logged in the replication report (see [Reports](#) on page 112).

- Click **Resume** to resume all incoming and outgoing replication and failback traffic.

If a replication job was in progress when replication was paused, the replication job continues.

Replication State

The replication state applies to all NAS shares on the DXi4000 that are eligible for replication (that is, all deduplicated shares).

- Click **Enable** to enable replication for all shares.
- Click **Disable** to disable replication for all shares.

If a replication job is currently in progress, the system continues until the entire replication job is complete. After the replication job has completed, the system disables replication. The system will not be able to replicate data for any shares until you click **Enable**.

Note: To disable replication for a single share, select it on the **Replication > Send** page and click **Edit**. Clear the **Enable replication** and the **Enable scheduled replication** check boxes, and then click **Apply**. For more information, see [Send NAS](#) on page 88.

Replication Performance

The DXi4000 maintains cumulative performance statistics for send and receive replication activity. The statistics appear on the **Home** page and elsewhere. To reset these statistics so the system will calculate them with new data going forward, click **Clear**.


- Click **Clear Send** to reset cumulative performance statistics gathered while replicating shares to target systems, or when sending a snapshot during a failback operation.
- Click **Clear Receive** to reset cumulative performance statistics gathered while receiving replicated shares from source systems, or when receiving a snapshot during a failback operation.

Reports

The **Reports** page allows you to generate and download a replication report. The report includes detailed information about all replication activity, including Directory/File Based Replication.

To access the **Reports** page, click the **Replication** menu, and then click the **Reports** tab (see [Figure 61](#)).

Figure 61 Reports Page



Use the **Reports** page to perform the following tasks:

- To generate a new replication report, click **Generate New**.
- To download the most recently generated replication report, click **Download Current**.

Save the replication report to your local workstation, and then unzip the downloaded file. The report consists of a ZIP file that contains multiple CSV (comma separated value) files. To view the CSV files, open them in a compatible spreadsheet application.



Chapter 7

DXi4000 Status

The **Status** page allows you to view status information for the DXi4000 hardware as well as performance and disk usage information.

Note: Status information is gathered by the system every two minutes.

To access the **Status** pages, click the **Status** menu.

The **Status** pages contains the following tabs:

- [Hardware](#)
- [Performance](#)
- [Disk Usage](#)
- [DXi Accent Status](#)

Hardware

The **Hardware** page allows you to view information about the hardware components of the DXi4000. You can view the overall status of the node as well as detailed status information for components such as the system board, network ports, and storage arrays.

To access the **Hardware** page, click the **Status** menu, and then click the **Hardware** tab.

The **Hardware** page contains the following tabs:

- [Summary](#)
- [Details](#)
- [Firmware Version](#)


Summary

The **Hardware Summary** page allows you to view the overall status of the node and its main components. The system and each component can have one of the following statuses:

- **Normal** - (Green) The hardware is operating correctly.
- **Attention** - (Yellow) There is a problem with the hardware.
- **Failed** - (Red) The hardware has failed.

To access the **Hardware Summary** page, on the **Hardware** page, click the **Summary** tab (see [Figure 62](#)).

Figure 62 Hardware Summary Page



The **Hardware Summary** page displays the following information:

- **Available System Memory (RAM)** - The total amount of memory (RAM) installed in the system.

- **Free System Memory (RAM)** - The amount of system memory (RAM) that is currently free.
- **State** - The status of the node.
- **Status** - The overall status of all components in the node.
- **Component Name** - The name of the main component.

Click the component name to see detailed information (see [Details](#) on page 115).

- **Component Status** - The overall status of the main component.

Details

The **Details** page allows you to view detailed information about the hardware components of the DXi4000.

To access the **Details** page, on the **Hardware** page, click the **Details** tab.

Use the **Details** page to view information for the following components:


- [System Board](#)
- [Network Ports](#)
- [Storage Arrays](#)

System Board

The **System Board** page allows you to view information reported by the main system board in the node, such as temperature, voltage, fan, and power supply information.

To access the **System Board** page, on the **Details** page, click the **System Board** tab (see [Figure 63](#)).

Figure 63 System Board Page



The **System Board** page displays the following information:


- **Component** - The name of the component on the system board.
- **Type** - The component type (Sensor, Fan, or Power Supply).
- **Value** - The value reported by the sensor or component.
- **Status** - The status of the component.
 - **Normal** - (Green) The component is operating correctly.
 - **Attention** - (Yellow) There is a problem with the component.
 - **Failed** - (Red) The component has failed.

Network Ports

The **Network Ports** page allows you to view information about Ethernet ports in the system. The DXi4000 includes four Ethernet ports.

To access the **Network Ports** page, on the **Details** page, click the **Network Ports** tab (see [Figure 64](#)).

Figure 64 Network Ports Page



The **Network Ports** page displays the following information:


- **Component** - The number of Ethernet port.
- **Value** - The speed of the port in Mb/s.
- **Status** - The status of the Ethernet port.
 - **Up** - (Green) The port is connected.
 - **Down** - (Green) The port is not connected.

Storage Arrays

The **Storage Arrays** page allows you to view information about storage arrays and controllers in the DXi4000.

To access the **Storage Arrays** page, on the **Details** page, click the **Storage Arrays** tab (see [Figure 65](#)).

Figure 65 Storage Arrays Page



The **Storage Arrays** section displays the following information about each storage array:

- **Component** - The name of the storage array.
Click the name of the storage array to view detailed information for the array in the **Component** section.
- **Status** - The status of the storage array.
 - **Normal** - (Green) The component is operating correctly.
 - **Attention** - (Yellow) There is a problem with the component.
 - **Failed** - (Red) The component has failed.

The **Components** section displays the following information about the components in the selected storage array:

- **Component** - The name of the component.
Click the name of the component to view detailed information for the component in the subcomponent section.
- **Count** - The number of that component type in the system.
- **Status** - The status of the component.
 - **Normal** - (Green) The component is operating correctly.
 - **Attention** - (Yellow) There is a problem with the component.
 - **Failed** - (Red) The component has failed.

The subcomponent section displays the following information about the subcomponents in the selected component:


- **Component** - The name of the subcomponent.
- **Location** - The location of the subcomponent within the system.
- **Value** - The value reported by the subcomponent.
- **Status** - The status of the subcomponent.
 - **Normal** - (Green) The component is operating correctly.
 - **Attention** - (Yellow) There is a problem with the component.
 - **Failed** - (Red) The component has failed.

Firmware Version

The **Firmware Version** page allows you to view information about hardware components installed in the DXi4000, such as the firmware version, hardware revision, and manufacturer.

To access the **Firmware Version** page, on the **Hardware** page, click the **Firmware Version** tab (see [Figure 66](#)).

Figure 66 Firmware Version Page



The **Firmware Version** page displays the following information:

- **Name** - Displays a hardware component or a property of the component (for example, **Manufacturer**, **Version**, or **Release Date**).

Note: The properties that are listed vary depending on the hardware component.

- **Firmware Version** - The value of the corresponding item in the **Name** column (for example, the specific manufacturer, version number, or release date for the item).

Click **Update** to refresh the table with the latest information.

Note: In some cases, when updating firmware versions, the remote management console may time out and then return to the **Home** page. If this occurs, simply navigate back to the **Status > Hardware > Firmware Version** page to see the updated information.

Performance

The **Performance** page allows you to view information about system performance, including inline throughput, network throughput, read/write throughput, and CPU usage.

To access the **Performance** page, click the **Status** menu, and then click the **Performance** tab.

The **Performance** page contains the following tabs:


- [Inline](#)
- [Ethernet](#)
- [RAID](#)
- [CPU](#)

Inline

The **Inline** page allows you to view throughput performance for inline data flow. Inline data flow includes deduplicated and non-deduplicated backup data as well as received replication data.

To access the **Inline** page, on the **Performance** page, click the **Inline** tab (see [Figure 67](#)).

Figure 67 Inline Page



Use the **Inline** page to display recent inline data flow activity in a dynamic graph:

- Select the amount of time to display in the **Last** list (1–24 hours).
- The horizontal axis displays time (in minutes).
- The vertical axis displays inline throughput (0–2,000 MB/s).

Note: The range represented by the Y-axis changes based on the maximum value, increasing in 200 MB increments as needed.

- Each bar on the graph represents approximately 1 minute of time.
- Hold the cursor over a bar to display the value of the bar.

Ethernet

The **Ethernet** page allows you to view throughput performance for network send and receive activity.

To access the **Ethernet** page, on the **Performance** page, click the **Ethernet** tab (see [Figure 68](#)).

Figure 68 Ethernet Page



Use the **Ethernet** page to display recent network activity in dynamic graphs:


- The top graph reports data received and the bottom graph reports data sent.
- Select the port to monitor in the **Ethernet** drop-down box, or select **Avg** to display an average of all ports.
- The horizontal axis displays time (0–100 seconds).
- The vertical axis displays data throughput (0–125 MB/s).
- Values that exceed the maximum value of the vertical axis are shown in lighter green.
- Each bar on the graph represents approximately 1 second of time.
- Hold the cursor over a bar to display the value of the bar.

RAID

The **RAID** page allows you to view throughput performance for RAID read and write activity.

To access the **RAID** page, on the **Performance** page, click the **RAID** tab (see [Figure 69](#)).

Figure 69 RAID Page



Use the **RAID** page to display recent RAID activity in dynamic graphs:


- The top graph reports data reads and the bottom graph reports data writes.
- The horizontal axis displays time (0–100 seconds).
- The vertical axis displays the amount of data read or written (100 OPS/s).
- Values that exceed the maximum value of the vertical axis are shown in lighter green.
- Each bar on the graph represents approximately 1 second of time.
- Hold the cursor over a bar to display the value of the bar.

CPU

The **CPU** page allows you to view CPU usage.

To access the CPU page, on the **Performance** page, click the **CPU** tab (see [Figure 70](#)).

Figure 70 CPU Page



Use the **CPU** page to display recent CPU usage in a dynamic graph:

- Select the CPU core to monitor in the **CPU** drop-down box, or select **Avg** to display an average of all CPUs.

Note: The **CPU** drop-down box lists all CPU threads. Each hyper-threaded CPU core counts as two threads.


- The horizontal axis displays time (0–100 seconds).
- The vertical axis displays CPU usage (0–100%).
- Each bar on the graph represents approximately 1 second of time.
- Hold the cursor over a bar to display the value of the bar.

Disk Usage

The **Disk Usage** page allows you to view information about free and used disk space on the system. You can also view data reduction statistics.

To access the **Disk Usage** page, click the **Status** menu, and then click the **Disk Usage** tab (see [Figure 71](#)).

Figure 71 Disk Usage Page



Use the **Disk Usage** page to view the following information:

- [Available](#)
- [Used](#)
- [Data Reduction](#)

Available

Available space is the area that is available for data storage. The **Available** value (also called **Free Space**) is displayed as an amount and as a percentage of the total capacity in the system.

Used

Used space is the area that already holds data. The **Used** value is displayed as an amount and as a percentage of the total capacity in the system.

Used space is divided into the following categories:

Note: The value for each category is displayed as an amount and as a percentage of the total capacity in the system.

- **Deduplicated Data** - The amount of data that has been deduplicated.
- **Data Not Intended For Deduplication** - The amount of data that will not be deduplicated (data on shares that do not have deduplication enabled).
- **System Metadata** - The amount of disk space used for internal operations of the DXi, including system configuration files as well as temporary files created during replication, space reclamation, and healthchecks.

Data Reduction

The data reduction area displays the data reduction performance for the system. Data reduction is divided into the following categories:

- **Data Size Before Reduction** - The original, native size of all data that has been processed by the data deduplication and compression engines.
- **Data Size After Reduction** - The final, reduced size of all data that has been processed by the data deduplication and compression engines.
- **Total Reduction Ratio** - The total reduction ratio of all data that has been processed by the data deduplication and compression engines (**Data Size Before Reduction** divided by **Data Size After Reduction**).
- **Deduplication Ratio** - The deduplication ratio of all data that has been processed by the data deduplication engine.
- **Compression Ratio** - The compression ratio of all data that has been processed by the compression engine.


DXi Accent Status

Use the **Accent Status** page to view information about recent DXi Accent activity.

Note: The **Accent Status** page displays only if DXi Accent is currently enabled or was previously enabled (see [DXi Accent](#) on page 177).

To access the **Accent Status** page, click the **Status** menu, and then click the **Accent** tab (see [Figure 72](#)).

Figure 72 Accent Status Page



The **Accent** section displays the following information about DXi Accent activity in the previous minute:

- **Media Server To DXi Previous Minute** - DXi Accent activity for all Accent enabled media servers.
 - **Inline (Accent)** - The inline data flow throughput (in MB/s). Inline data flow represents the original, native size of the data protected by the DXi.
 - **Ethernet In (Accent)** - The amount of data received by all Ethernet ports (in MB/s). This amount represents the reduced

size of the data protected by the DXi (after deduplication and compression on the media servers).

- **Accent Bandwidth Reduction** - The percentage by which network bandwidth utilization was reduced by enabling Accent.
- **Media Server** - The IP address of the media server.
- **Inline (Accent)** - The inline data flow throughput (in MB/s). Inline data flow represents the original, native size of the data protected by the DXi.
- **Ethernet In (Accent)** - The amount of data received by all Ethernet ports (in MB/s). This amount represents the reduced size of the data protected by the DXi (after deduplication and compression on the media server).
- **Accent Bandwidth Reduction** - The percentage by which network bandwidth utilization was reduced by enabling Accent.



Chapter 8

DXi4000 Alerts

The **Alerts** page allows you to view and work with administration alerts and service tickets. The DXi4000 generates administration alerts and service tickets when a hardware or software event occurs.

To access the **Alerts** page, click the **Alerts** menu.

The **Alerts** page contains the following tabs:

- [Admin Alerts](#)
- [Service Tickets](#)


Admin Alerts

The **Admin Alerts** page allows you to view and work with administration alerts. The DXi4000 generates an administration alert when the condition of the system has changed, such as going from the offline state to the online state.

Note: In addition to viewing administration alerts on the **Admin Alerts** page, you can configure the system to send alerts to an e-mail address (see [Recipients](#) on page 203).

To access the **Admin Alerts** page, click the **Alerts** menu, and then click the **Admin Alerts** tab (see [Figure 73](#)).

Figure 73 Admin Alerts Page



The **Admin Alerts** page displays the following information about administration alerts:

- **Alert** - The name of the administration alert.
- **Last Update** - The date when the administration alert was last updated by the system.
- **Summary** - A brief description of the administration alert.

Note: Click a column heading to sort the rows in the table by that column. Click the column heading again to reverse the sort order.

Use the **Admin Alerts** page to perform the following tasks:

- To view details about an administration alert, click the alert name. Detailed information about the alert appears in the **Activity Status History** section.
- To delete an administration alert, select it and click **Delete**.

Service Tickets

The DXi4000 has the capability to automatically detect and resolve problems encountered by the system during operation. If a problem cannot be resolved automatically and requires user intervention or servicing, the system generates a service ticket.

A service ticket contains detailed information about the problem and, if appropriate, steps you can take to resolve it. If the DXi4000 detects that the problem is resolved, the system automatically closes the service ticket. You can also manually close a service ticket after the problem is corrected.

Note: Tickets that are not resolved are generated again after 24 hours.

See the following sections for more information about service tickets:

- [Service Ticket Priority](#)
- [Recommended Actions](#)
- [Working With Service Tickets](#)

Service Ticket Priority

The system assigns each service ticket a priority based on the criticality of the problem that caused the system to generate the ticket. There are three priority levels:

- **Low** - (Green) A minor problem occurred and needs to be resolved, but the operation and performance of the DXi4000 are not significantly affected.
- **Middle** - (Yellow) A serious problem occurred and needs to be resolved, but it does not necessarily need to be fixed immediately. The operation and performance of the DXi4000 may be degraded.
- **High** - (Red) A critical problem has occurred and needs to be resolved immediately. The operation and performance of the DXi4000 are degraded, and there is a risk of system failure or data loss.

Recommended Actions

If appropriate, a service ticket includes recommended actions. The recommended actions provide instructions for resolving the problem that caused the system to generate the ticket.

Perform the recommended actions to try to resolve the problem before contacting Quantum customer support. If you are able to resolve the problem, you can close the service ticket.


Note: The recommended actions should be performed by a user who is familiar with operating the DXi4000.

Working With Service Tickets

The **Service Tickets** page allows you to view and work with service tickets.

To access the **Service Tickets** page, click the **Alerts** menu, and then click the **Service Tickets** tab (see [Figure 74](#)).

Figure 74 Service Tickets Page



Ticket	Request ID	State	Priority	Last Update	Details
4	2134600515	open	middle	Thu Dec 15 2011 - 11:15:02 AM PST	Space Manager daemon : System is nearing full capacity
5	2134600515	open	middle	Fri Dec 16 2011 - 04:02:25 PM PST	Space Manager daemon : I/O Write Low Threshold state
6	2135016579	open	middle	Sun Dec 18 2011 - 09:28:08 PM PST	Space Manager daemon : System is nearing full capacity
7	2135016579	open	middle	Mon Dec 19 2011 - 11:05:48 PM PST	Space Manager daemon : System is nearing full capacity
8	2135016579	open	middle	Wed Dec 21 2011 - 01:15:21 AM PST	Space Manager daemon : System is nearing full capacity

The **Service Tickets** page displays the following information about open service tickets:

- **Ticket** - The service ticket number.
- **Request ID** - The Request ID of the ticket.
- **State** - The current status of the service ticket (**Open** or **Closed**).

- **Priority** - The priority level of the service ticket (**Low**, **Middle**, or **High**).
- **Last Update** - The date when the service ticket was last updated by the system.
- **Details** - A brief description of the service ticket.
- **Close All** - Click to close all open service tickets.
- **Show Tickets** - Select an option to display **Open** tickets, **Closed** tickets, or **All** tickets.
- **Get individual ticket** - To display a specific ticket in the list, enter a ticket number and click **Apply**.

Note: Click a column heading to sort the rows in the table by that column. Click the column heading again to reverse the sort order.

Use the **Service Tickets** page to perform the following tasks:

- View details for a service ticket, including recommended actions (see [Viewing a Service Ticket](#) on page 133).
- Add information to a service ticket (see [Modifying a Service Ticket](#) on page 135).
- Send a service ticket to an e-mail address (see [Sending a Service Ticket](#) on page 136).
- Close a service ticket that has been resolved (see [Closing a Service Ticket](#) on page 137).

Viewing a Service Ticket

View a service ticket to see detailed information about the problem that caused the system to generate the ticket and to view recommended actions.


To view a service ticket:

- 1 In the list of service tickets, click the ticket number.

The **Ticket Details** section at the bottom of the page displays information about the service ticket, including the time the ticket was opened and closed, the ticket status, and detailed information about the problem (see [Figure 75](#)).

Note: The time indicated in the service ticket may not match the DXi4000 system time.

Figure 75 Ticket Details



2 (Optional) Click **View Recommended Actions** to view instructions for resolving the problem.

The recommended actions display in a new Web browser window (see [Figure 76](#)). Follow the instructions to resolve the problem. When you are finished, click the close button [x] on the upper right corner of the window.

Figure 76 Recommended Actions

Recommended Actions	
Quota Limit or Fragmentation Warnings	
IF	THEN
You receive a warning that the quota hard limit is reached for a user:	Either increase the user's quota, or notify the user.
You receive a warning that fragmentation has been detected in an inode:	<ol style="list-style-type: none"> 1. Consult the snfsdefrag man page for instructions on performing fragmentation analysis and defragmenting files. 2. See ExtentCountThreshold in the cvfs_config documentation for information on adjusting this RAS event.
The problem IS resolved:	Close the service ticket. Refer to Closing Service Tickets .
The problem is NOT resolved:	<ol style="list-style-type: none"> 1. Modify the ticket according to the troubleshooting steps taken. Refer to Analyzing Service Tickets. 2. Contact the Quantum Technical Assistance Center. <ul style="list-style-type: none"> In the USA: 1+800-284-5101 UK, France and Germany: 00800 4 QUANTUM EMEA: +49 6131 3241 1164 / Asia Pacific: +603 7953 3010 On the Web: http://www.quantum.com/support
Print Document Close Window	
<small>©2010 Quantum Corporation © All rights reserved.</small>	

Modifying a Service Ticket


Modify a service ticket to add additional information to the ticket, for example, troubleshooting steps you have taken or a record of calls made to Quantum customer support. The additional information is saved with the service ticket and remains associated with the ticket even after it is closed.

To modify a service ticket:

- 1 In the list of service tickets, click the ticket number.
- 2 Click **Analysis** at the bottom of the page.

The **Ticket Analysis** section displays at the bottom of the page (see [Figure 77](#)).

Figure 77 Ticket Analysis



- 3 In the **Analysis Information** box, enter all relevant information about actions taken to resolve the issue.
- 4 Click **Apply**.

Sending a Service Ticket

Send a service ticket to send the ticket details to an e-mail address. You can also add optional comments to the e-mail.


Note: To enable the DXi4000 to send e-mail, you must specify an outgoing e-mail server (see [Server](#) on page 208).

To send a service ticket:

- 1 In the list of service tickets, click the ticket number.
- 2 Click **Email** at the bottom of the page.

The **Email Ticket Information** section displays at the bottom of the page (see [Figure 78](#)).

Figure 78 Email Ticket Information



- 3 In the **Email Recipient** box, enter the e-mail address where you want to send the ticket details.
- 4 (Optional) In the **Comment** box, enter additional information to send with the ticket.
- 5 Click **Send**.

Closing a Service Ticket

Close a service ticket if the problem the caused the system to generate the ticket is resolved. You can also close all service tickets that are currently open.

Note: You can still view and modify a ticket after it has been closed.

To close all service tickets that are currently open, below the list of service tickets, click **Close All**.

To close a single service ticket:

- 1 In the list of service tickets, click the ticket number.
- 2 Click **Analysis** at the bottom of the page.

The **Ticket Analysis** section displays at the bottom of the page (see [Figure 77](#)).

- 3 Select the **Close Ticket** check box.
- 4 Click **Apply**.



Chapter 9

DXi4000 Configuration

The **Configuration** page allows you to configure the features of the DXi4000, including storage presentation, data replication, system settings, and notifications.

To access the **Configuration** page, click the **Configuration** menu.

The **Configuration** page contains the following tabs:

- [NAS](#)
- [Replication](#)
- [OST](#) (including DXi Accent with OST)
- [Scheduler](#)
- [System](#)
- [Notifications](#)
- [Contacts](#)

NAS

The **NAS** page allows you to configure the DXi4000 to present its storage capacity as NAS (network attached storage) shares that are compatible with standard backup applications. You can create NAS

shares for use with Windows or Linux networks. You can also join the DXi4000 to a Windows domain or workgroup and manage users.

Note: The **NAS** wizard provides guided assistance for configuring NAS shares (see [DXi4000 Configuration Wizards](#) on page 41).

Caution: Caution: Filenames on NAS shares are limited to a length of 256 bytes. If a filename uses Japanese characters, the filename can be no longer than 85 characters. This is because each Japanese character is represented by 3 bytes.

To access the **NAS** page, click the **Configuration** menu, and then click the **NAS** tab.

The **NAS** page contains the following tabs:


- [NAS Summary](#)
- [Windows Domain](#)
- [Share Access](#)
- [Advanced Setting](#)

NAS Summary

The **NAS Summary** page allows you to manage NAS shares on the DXi4000. You can view information about existing shares, add or edit shares, and delete shares.

To access the **NAS Summary** page, on the **NAS** page, click the **Summary** tab (see [Figure 79](#)).

Figure 79 NAS Summary Page



Use the **NAS** page to perform the following tasks:

- View information about existing NAS shares (see [NAS Shares List](#) on page 141).
- Add a new NAS share to the system (see [Adding a NAS Share](#) on page 142).
- Edit properties for an existing NAS share (see [Editing a NAS Share](#) on page 144).
- Delete a NAS share from the system (see [Deleting a NAS Share](#) on page 146).

NAS Shares List

The **NAS Shares List** section displays the following information for all NAS shares on the DXi4000:

- **Shares** - The number of shares that have been added to the system.
- **Maximum** - The maximum number of shares that can be added to the system.
- **NFS** - The number of existing shares configured to use the NFS protocol (for Linux networks).
- **CIFS** - The number of existing shares configured to use the CIFS protocol (for Windows networks).
- **Share Name** - The name of the share.

- **Protocol** - The protocol (**CIFS** or **NFS**) the share is configured to use. For NFS shares, the **Protocol** column displays the commit type of the share (**sync** for synchronous or **async** for asynchronous). For information about changing the commit type of NFS shares, see the *DXi-Series Command Line Interface (CLI) Guide* (6-67081).
- **Export Path** - The export path of the share (different for CIFS and NFS shares).
- **Deduplication** - The data deduplication state of the share (**Enabled** or **Disabled**).
- **Permissions** - The permissions in use on the share (**Read & Write** or **Read Only**).
- **Access** - The access type of the share (**all hosts** or specific users).
- **Description** - A brief description of the NAS share (if available).

Note: Click a column heading to sort the rows in the table by that column. Click the column heading again to reverse the sort order.

Note: Click the Information button [i] next to a share to display detailed information about the share and recent replication activity.

Adding a NAS Share

Add a NAS share to present the storage capacity of the DXi4000 as a NAS share that is compatible with standard backup applications. You can add up to 128 shares. When you add a share, you must specify whether it uses the NFS protocol (for Linux networks) or the CIFS protocol (for Windows networks).


Note: If you are adding a CIFS share for use with a Windows network, you must configure the Windows domain before adding the new share (see [Windows Domain](#) on page 146).

To add a NAS share:

- 1 Click **Add**.

The **Add NAS Share** page displays (see [Figure 80](#)).

Figure 80 Add NAS Share Page



2 Under **NAS Share Settings**, enter information about the share:

- **Name** - Enter the name of the NAS share.
- **Description** - (Optional) Enter a brief description of the share.
- **Hide from network browsing** - (CIFS shares only) Select the check box to hide the share from network browsing. If selected, you cannot see the share when browsing the network.
- **Enable data deduplication** - Select the check box to enable data deduplication. Quantum recommends that you enable data deduplication to optimize disk usage.

Note: Data deduplication is enabled by default. You cannot enable or disable data deduplication after the share is added. If data duplication is disabled, then data compression is also disabled.

- **Export Protocol** - Select the export protocol for the share:
 - **CIFS** - Select the CIFS option to use the share on a Windows network.
 - **NFS** - Select the NFS option to use the share on a UNIX or Linux network.

Note: If symlink and hard link support is enabled for an NFS share, replication cannot be enabled for the share. For information about enabling symlink and hard link support for a share, see the *DXi-Series Command Line Interface (CLI) Guide* (6-67081).

3 (Optional) Under **Replication Settings**, specify replication settings.

For more information about configuring replication for a share, or to set up replication for the share at a later time, see [DXi4000 Replication](#) on page 81.

4 Click **Apply**.

Note: When you create a CIFS share, the initial permissions are the same as the default permissions for a Windows 2003 share with the addition of an ACE (Access Control Entry) that permits full access to the share for all authenticated users. Administrators can choose to remove this full access ACE, set up custom permissions, or leave the ACL (Access Control List) as it is if the server is set up in a fully trusted environment.

Editing a NAS Share


Edit a NAS share to modify the settings for the share, for example, to change the description of the share or to select different options.

To edit a NAS share:

1 Select the share and click **Edit**.

The **Edit NAS Share & Replication Settings** page displays (see [Figure 81](#)).

Figure 81 Edit NAS Share & Replication Settings Page



2 Under **NAS Share Settings**, enter information about the share:

Note: If you are editing a share, only the **Description**, **Enforce read-only access**, **Hide from network browsing**, and **Allow all users to access this share** options can be changed.

- **Description** - (Optional) Enter a brief description of the share.
- **Enforce read-only access** - Select the check box to make the share read only. If selected, you cannot write to the share.
- **Hide from network browsing** - (CIFS shares only) Select the check box to hide the share from network browsing. If selected, you cannot see the share when browsing the network.
- **Allow all users/hosts to access this share** - Select this check box to allow all users (CIFS shares) or hosts (NFS shares) to access the share.

Or clear the check box to allow only specified users or hosts to access the share. To add a user or host to the access list, click **Add**. Specify the **Workgroup User** (CIFS shares) or the **Hostname or IP Address** (NFS shares) and the associated permissions (**Read Only** or **Read & Write**), and then click **Apply**.

Note: To modify the users that are available in the **Workgroup User** list, see [Share Access](#) on page 149.

Note: After you add a user or host to the access list, you cannot change their permissions. Instead, select the user or host in the access list and click **Delete** to remove them from the list. Then add the user or host again with the correct permissions.

3 Click **Apply**.

Note: If you modify a NAS share that uses the CIFS protocol, you must restart the CIFS service for the changes to take effect. To restart the CIFS service, first disjoin the Windows workgroup, then join it again (see [Windows Domain](#) on page 146). Restarting the CIFS service will close all active connections to the share. Most Windows workstations will automatically reconnect, but some applications may be affected.

Deleting a NAS Share

Delete a NAS share if it is no longer needed. When you delete a share, all data stored on the share is lost.

To delete a NAS share:

- 1 Select the share and click **Delete**.

Note: You can select multiple shares to delete at once.


- 2 Click **Yes** to confirm the deletion.

Windows Domain

The **Windows Domain** page allows you to join the DXi4000 to a Windows workgroup or a Windows domain using **SMB**. To use a NAS share configured for the CIFS protocol on a Windows network, you must first join the DXi4000 to a workgroup or a domain. After you join the DXi4000 to a workgroup or a domain, CIFS shares are available for use on the Windows network.

To access the **Windows Domain** page, on the **NAS** page, click the **Windows Domain** tab (see [Figure 82](#)).

Figure 82 Windows Domain Page



Use the **Windows Domain** page to perform the following tasks:

- Join the DXi4000 to a Windows workgroup (see [Joining a Windows Workgroup](#) on page 147).
- Join the DXi4000 to a Windows domain (see [Joining a Windows Domain](#) on page 148).
- Remove the DXi4000 from a Windows workgroup or domain (see [Disjoining a Workgroup or Domain](#) on page 149).

Joining a Windows Workgroup

Join a Windows workgroup to add the DXi4000 to a workgroup on a Windows network. After you join a workgroup, CIFS shares are available for use on the Windows network.

To join a Windows workgroup:

- 1 Enter the following information about the Windows domain:
 - **Domain Type** - Select Workgroup.
 - **Domain/Workgroup Name** - Enter the workgroup name.

The workgroup name can be the name of an existing workgroup or a new workgroup (for example, **Workgroup** or **Sales**).

2 Click **Apply**.

Note: When an SMB server is joined to a workgroup, share security is managed directly from the remote management console. For a CIFS share, security is provided through the read only or read/write access to the share. By default, when a CIFS share is created, the default security setting allows access for all users. Any access restrictions on individual users can be managed by editing a share on the NAS Summary page (see [Editing a NAS Share](#) on page 144).

Joining a Windows Domain

Join a Windows domain to add the DXi4000 to a Windows network using Active Directory. After you join a domain, CIFS shares are available for use on the Windows network.

Before joining a Windows domain, make sure the date and time on the DXi4000 is correct and is synchronized with the Active Directory Services (ADS) server (see [Date & Time](#) on page 192). The time difference between the DXi4000 and the ADS server (domain controller) must be less than 300 seconds. Quantum recommends using the same NTP server for the DXi4000 and the ADS server to keep them synchronized.

To join a Windows domain:

- 1 Enter the following information about the Windows domain:
 - **Domain Type** - Select **Active Directory**.
 - **Domain/Workgroup Name** - Enter the domain name.
 - **Primary Domain Controller** - Select an option for the Primary Domain Controller (PDC):
 - **Use DNS Discovery** - Discover the PDC automatically.
 - **Specify Address** - Enter the fully qualified name or the IP address of the PDC.
 - **Organization Unit** - (Optional) Enter the name of the organizational unit in the domain.

The DXi4000 will become a member of this organization.

- **Administrator Name** - Enter **Administrator** or any user that has the right to join the domain.

By default, any user belonging to the **Administrators** group or the **Domain Admins** group has the right to join the domain. In addition, any user can join the domain if they are specifically delegated this right by a member of the **Administrators** group.

- **Administrator Password** - Enter the password for the user entered above.

2 Click **Apply**.

Note: When the system is joined to the Active Directory domain, share security is managed by the MMC (Microsoft Management Console) that is running on the domain controller. By default, when a CIFS share is created, the default security setting allows access for all users. Any access restrictions on individual users must be managed from the MMC.

Disjoining a Workgroup or Domain

Disjoin a workgroup or a domain to remove the DXi4000 from a Windows workgroup or domain. After you disjoin the workgroup or domain, CIFS shares are no longer available for use on the Windows network

To disjoin a workgroup or domain, click **Disjoin**.

Share Access

The **Share Access** page allows you to manage workgroup users when the DXi4000 is joined to a Windows workgroup, or manage share administrators when the DXi4000 is joined to a Windows domain using Active Directory. You can add users or administrators, change user privileges, and delete users or administrators. Available users or administrators can be granted access to NAS shares configured for the CIFS protocol.

Note: You must join a Windows workgroup or domain before you can add workgroup users or share administrators (see [Windows Domain](#) on page 146). The **Share Access** page is different depending on whether the DXi is joined to a workgroup or domain.

To access the **Share Access** page, on the **NAS** page, click the **Share Access** tab (see [Figure 83](#) and [Figure 84](#)).

Figure 83 Share Access Page
(Windows Workgroup)





Figure 84 Share Access Page
(Active Directory)



Use the **Share Access** page to perform the following tasks:

- View information about workgroup users or share administrators (see [Workgroup Users or Share Administrators](#) on page 151).

- Add a workgroup user or a share administrator (see [Adding a Workgroup User or Share Administrator](#) on page 151).
- Edit a workgroup user (see [Editing a Workgroup User](#) on page 153).
- Delete a workgroup user or a share administrator (see [Deleting a Workgroup User or Share Administrator](#) on page 154).

Workgroup Users or Share Administrators

If the DXi4000 is joined to a Windows workgroup, the **Workgroup Users** section displays the following information about workgroup users:

- **Username** - The name of the workgroup user.
- **Administrator Privileges** - The privileges of the workgroup user (Yes if the user has administrator privileges, No if they do not.)
- **Description** - A brief description of the workgroup user (if available).

If the DXi4000 is joined to a Windows domain using Active Directory, the **Share Administrators** section displays the following information about share administrators:

- **User or Group Name** - The fully qualified name of the user or group.

Adding a Workgroup User or Share Administrator

Add a workgroup user or share administrator to be able to grant that user or administrator access to CIFS shares.


Windows Workgroup

To add a workgroup user for a Windows workgroup:

- 1 Click **Add**.

The **Add Workgroup User** page displays (see [Figure 85](#)).

Figure 85 Add Workgroup
User Page



2 Enter information about the workgroup user:

- **User Name** - Enter the name of the workgroup user.
- **Password** - Enter the password for the workgroup user.
- **Confirm Password** - Enter the password again to confirm it.
- **Description** - (Optional) Enter a brief description of the workgroup user.
- **Grant Administrator Privileges** - Select the check box to add the workgroup user to the Windows Administrators group.

This allows the workgroup user to override certain permissions settings and prevents the workgroup user from being locked out of shares or directories.

3 Click **Apply**.

After you create a workgroup user, you can grant the user access to a NAS share (see [Editing a NAS Share](#) on page 144).

Windows Domain

To add a share administrator for a Windows domain:

1 Click **Add**.

The **Add Share Administrator** page displays (see [Figure 86](#)).

Figure 86 Add Share Administrator Page



- 2 Enter the **Fully Qualified User or Group Name** of the share administrator.
- 3 Click **Apply**.

Use the MMC (Microsoft Management Console) to manage users (see [ADS Share Permissions](#) on page 155).

Editing a Workgroup User

Edit a workgroup user to change the user's password or description, or to change the user's administrator privileges.


Note: You cannot edit a share administrator. Instead, delete the share administrator, then add a new share administrator.

To edit a workgroup user:

- 1 Select the user and click **Edit**.

The **Edit Workgroup User** page displays (see [Figure 87](#)).

Figure 87 Edit Workgroup
User Page



2 Enter information about the workgroup user:

Note: If you are editing a workgroup user, you cannot change the **User Name**.

- **User Name** - (Optional) Select a different workgroup user to edit.
- **Password** - Enter the password for the workgroup user.
- **Confirm Password** - Enter the password again to confirm it.
- **Description** - (Optional) Enter a brief description of the workgroup user.
- **Grant Administrator Privileges** - Select the check box to add the workgroup user to the Windows Administrators group.

This allows the workgroup user to override certain permissions settings and prevents the workgroup user from being locked out of shares or directories.

3 Click **Apply**.

Deleting a Workgroup User or Share Administrator

Delete a workgroup user or share administrator if the user or administrator no longer needs to access CIFS shares.

To delete a workgroup user or share administrator, select the user or administrator and click **Delete**.

Note: You can select multiple users or administrators to delete at once.

ADS Share Permissions

To manage user access to CIFS shares when the DXi4000 is joined to a Windows domain, use the MMC (Microsoft Management Console). Log onto the MMC on the domain controller and access a share's properties to set share permissions for users.

Note: In some cases, when you view file permissions on a Windows system, you will not see the user and group information. Instead you will see the SID (security ID) which appears as a series of numbers. This occurs when you move files (for example, using a backup utility or DOS **xcopy**) from one system to another system, and the user and group from the source system do not exist on the target system.


Often users and groups are unique to a particular scope, such as a Windows system or an ADS domain. As a result, some assigned permissions might not be available on the target system because the associated user and group do not exist there. However, common groups (for example, **Administrators**, **Users**, and **Everyone**) are recognized on most Windows systems and domains.

Advanced Setting

The **Advanced Setting** page allows you to enable or disable advanced SMB settings.

To access the **Advanced Setting** page, on the **NAS** page, click the **Advanced Setting** tab (see [Figure 88](#)).

Figure 88 Advanced Setting
Page



To enable or disable advanced SMB settings:

- 1 Select the check box to enable, or clear the check box to disable, the following settings:

- **Enable Opportunistic Locking** - (Enabled by default)
Opportunistic locking lets clients lock files and locally cache information without the risk of another user changing the file. This increases performance for many file operations, but it may decrease performance in other operations because the server that grants the opportunistic lock must manage the breaking of that lock when another user requests access to the file.

Note: System performance may decrease if **Opportunistic Locking** is disabled.

- **Enable SMB Server signing** - (Disabled by default) SMB server signing improves security on Windows networks by requiring clients to provide a security signature to connect to a server. If the DXi4000 is joined to a Windows domain that is configured to require signing, you should enable SMB server signing.

- 2 Click **Apply**.

Replication

The **Replication Configuration** page allows you to configure the DXi4000 to act as a replication source or target. A source *sends* replicated data to a target, and a target *receives* replicated data from up to 10 sources. A DXi4000 can act as both a source and a target.

Note: For more information about data replication, or to perform data replication, see [DXi4000 Replication](#) on page 81.

To access the **Replication Configuration** page, click the **Configuration** menu, and then click the **Replication** tab.

The **Replication Configuration** page contains the following tabs:

- [Replication Send](#)
- [Replication Receive](#)


Replication Send

The **Replication Send** page allows you to specify the target system the DXi4000 will send replicated data to. You must specify the replication target before you enable replication for a NAS share. When replication is enabled for a share, replicated data is sent to the target system during scheduled or manual replication.

Note: For more information about enabling and scheduling replication for a share, see [Send NAS](#) on page 88.

To access the **Replication Send** page, on the **Replication Configuration** page, click the **Send** tab (see [Figure 89](#)).

Figure 89 Replication Send
Page



To specify the replication target:

- 1 If you have previously specified a replication target, you must pause the replication service before changing the target.

Replication Service displays the replication status of the DXi4000. Click **Pause** to pause replication activity. Click **Resume** to resume replication activity.

Note: For a detailed description of all possible replication statuses, see [Replication Overview](#) on page 76.

- 2 In the **Target Hostname or IP Address** box, enter the hostname or IP address of the system that will receive the replicated data.

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.

Note: To use hostname format, you must specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184).

- 3 In the **Source IP Address** field, enter the IP address that is used to uniquely identify the source DXi to the target. This may be different than the actual network IP address of the source DXi.

If the target system is at DXi 2.1 Software or higher, this field is not required. If the target system is at DXi 2.0.1.x Software or below, then you must enter the IP address by which the target system recognizes the source system. The default value is **0.0.0.0**.

- 4 (Optional) Leave the **Use Encryption** check box selected to enable encryption when sending replication data to the target system. Or clear the **Use Encryption** check box to disable encryption when sending replication data to the target system.

If encryption is enabled, select an encryption strength (**128-bit** or **256-bit**). Using 256-bit encryption (default) provides a stronger level of security but may have an impact on system performance in some situations.

Caution: Select 128-bit encryption if you are sending data to a DXi running a system software version prior to DXi 2.1 Software.

Note: Encryption is enabled by default. However, for best performance, if your data network is already secured, you should clear the **Use Encryption** check box.

- 5 Click **Apply**.
- 6 If necessary, click **Resume** to resume the replication service.


Replication Receive

The **Replication Receive** page allows you to specify the source systems the DXi4000 will receive replicated data from. You must add a source system to the list of allowed replication sources before you configure the source to send replicated data to the DXi4000. The DXi4000 can receive replicated data from up to 10 sources. You can also specify the number of received snapshots that are retained for each source.

Note: For more information about working with received snapshots, see [Receive NAS](#) on page 97.

To access the **Replication Receive** page, on the **Replication Configuration** page, click the **Receive** tab (see [Figure 90](#)).

Figure 90 Replication Receive Page



Use the **Replication Receive** page to perform the following tasks:

- View information about allowed replication source systems (see [Source DXIs](#) on page 160).
- Add a system to the list of allowed replication sources (see [Adding a Replication Source](#) on page 161).
- Delete a system from the list of allowed replication sources (see [Deleting a Replication Source](#) on page 161).
- Specify the maximum number of received snapshots to retain for each source (see [Maximum Received Snapshots](#) on page 162).

Source DXIs

The **Replication Receive** page displays the following information for each source DXI:

- **Replication Source DXI** - The IP address of the source system that is allowed to send data to the DXi4000.
- **Actual Data Received** - The amount of data actually received over the network during replication or failback.

- **Average Receive Rate** - The average receive rate (in MB/s) of data received over the network during replication or failback (**Actual Data Received** divided by the amount of time required to complete replication or failback).

Note: The statistics on the **Replication Receive** page are for each source DXi rather than a cumulative total for all sources as is displayed on the **Home** page.

Adding a Replication Source

Add a system to the list of replication sources to allow it to send replicated data to the DXi4000. You can specify up to 10 replication sources.

To add a replication source:

- 1 In the **Source Hostname or IP Address** box, enter the hostname or IP address of the system that will send the replicated data to the DXi4000.

Note: To use hostname format, you must specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184).

- 2 Click **Add**.

Deleting a Replication Source

Delete a system from the list of replication sources if it will no longer send replicated data to the DXi4000. After the source system is deleted, the DXi4000 will no longer accept replicated data from that system.

To delete a replication source:

- 1 Select the system in the **Source DXis** list.
- 2 Click **Delete**.

Note: If a source DXi is deleted from the list, its contribution to the cumulative totals on the **Home** page are not removed until you clear **Receive** statistics (see [Replication Performance](#) on page 111).

Maximum Received Snapshots

During scheduled or manual data replication, the DXi4000 receives a snapshot from the source system. A snapshot contains all of the data necessary to fully recover or failback a NAS share to the point in time when the snapshot was saved.

The DXi4000 can retain up to 24 snapshots for each replicated share. Once the maximum number of snapshots have been saved, the oldest snapshot is deleted to make room for each new snapshot that is received.

To configure the maximum number of received snapshots:

- 1 In the **Maximum Snapshots Per Share** drop-down box, select the number of snapshots to retain for each replicated share.

The default value is 10. The maximum value is 24.

- 2 Click **Apply**.

OST

The **OST** page allows you to configure the DXi4000 to present its storage capacity as storage servers using OpenStorage (OST) technology. You can also add one or more Logical Storage Units (LSUs) to a storage server. Storage servers and LSUs are compatible with backup applications that support OST, such as Symantec NetBackup and Symantec Backup Exec.

The **OST** page also allows you to manage authenticated users. To authenticate OST devices on a media server, you must create OST user credentials. After you create the OST user credentials, enter them in the backup application to authenticate OST devices on the media server.

To access the **OST** page, click the **Configuration** menu, and then click the **OST** tab.

The **OST** page contains the following tabs:

- [Storage Servers](#)
- [LSU](#)
- [Manage Users](#)


- [DXi Accent](#)
- [OST Client Plug-In](#)

Storage Servers

The **Storage Servers** page allows you to manage OST storage servers on the DXi4000. You can view information about existing storage servers, add or edit storage servers, and delete storage servers.

To access the **Storage Servers** page, on the **OST** page, click the **Storage Servers** tab (see [Figure 91](#)).

Figure 91 Storage Servers Page



Use the **Storage Servers** page to perform the following tasks:

- View information about existing storage servers (see [Storage Server List](#) on page 164).
- Add a new storage server to the system (see [Adding a Storage Server](#) on page 164).
- Edit properties for an existing storage server (see [Editing a Storage Server](#) on page 166).
- Delete a storage server from the system (see [Deleting a Storage Server](#) on page 168).

Storage Server List

The **Storage Server List** displays the following information for all storage servers on the DXi4000:

- **Storage Servers** - The number of storage servers that have been added to the system.
- **Maximum Storage Servers** - The maximum number of storage servers that can be added to the system.
- **LSUs** - The number of logical storage units (LSUs) that have been added to the system (see [LSU](#) on page 168).
- **Name** - The name of the storage server.
- **LSUs** - The number of LSUs that have been added to the storage server.
- **Max Connections** - The maximum number of connections allowed to the storage server.
- **Active Connections** - The number of currently active connections to the storage server.
- **Backup Images** - The number of backup images on the storage server.
- **Description** - A brief description of the storage server (if available).

Note: Click a column heading to sort the rows in the table by that column. Click the column heading again to reverse the sort order.

Note: The connections of a storage server that are used equals the data streams plus one for each LSU polling. A backup job may generate more than one data stream if the data can be read in parallel. For example, a policy that is backing up A, B, C, and D, drives of a Windows system can generate four data streams in parallel.

Adding a Storage Server

Add a storage server to present the storage capacity of the DXi4000 as LSUs that are compatible with backup applications that support OST. You can add up to 100 storage servers. When adding a storage server,

you must also add an LSU to the storage server. (For more information about LSUs, see [LSU](#) on page 168.)

Note: Data on storage servers is always deduplicated.

To add a storage server:

- 1 Click **Add**.

The **Add Storage Server** page displays (see [Figure 92](#)).

Figure 92 Add Storage Server Page

The screenshot shows the Quantum DXi4000 web interface. The top navigation bar includes 'Quantum', 'DXi:4601', 'Normal', 'Mon Dec 19 2011 - 8:50:07 AM PST', 'Admin', 'Ticket', 'Low Capacity', 'Logout', and 'Administrator Help'. The main menu includes 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards'. The 'Add Storage Server' page is displayed, featuring a form with the following fields:

- * Name: Text input field
- Description: Text input field
- * Max Connections: Text input field with value '300' and a range '(3 to 65536)'
- Logical Storage Unit: Radio buttons for 'Available Capacity' (selected) and 'Specific Capacity'
- LSU Name: Text input field
- Physical Capacity: Text input field with value '(1 to 1048576 GB)'
- Description: Text input field

 At the bottom of the form are 'Apply', 'Reset', and 'Cancel' buttons. A '* Required Field' note is present below the Physical Capacity field.

- 2 Under **Add Storage Server**, enter information about the storage server:

- **Name** - Enter the name of the storage server.

Caution: Do not use an underscore (`_`) in the name of the storage server.

- **Description** - (Optional) Enter a brief description of the storage server.
- **Max Connections** - Enter the maximum number of connections allowed to the storage server (3 to 65536).

Note: Quantum recommends setting **Max Connections** to 300.

- 3 Under **Logical Storage Unit**, select the type of LSU to add to the new storage server:

Note: For best performance, an LSU should not contain more than 250 backup images. If you will need to store more than 250 backup images on the DXi, you should create additional storage servers and LSUs.

- **Available Capacity** - (Recommended for best performance)
Select this option to add an LSU that uses the available capacity on the system.

You cannot add an available capacity LSU to a storage server that already contains an LSU. Also, if you add an available capacity LSU to a storage server, you cannot add additional LSUs to that same storage server.

Note: After you add an LSU that uses the **Available Capacity** option, you cannot change the LSU to use the **Specific Capacity** option. Instead, you must delete the LSU, then add a new LSU and choose the **Specific Capacity** option (see [Deleting an LSU](#) on page 173).

- **Specific Capacity** - Select this option to specify the physical capacity of the LSU, and then enter the following information.
 - **LSU Name** - Enter the name of the LSU.
 - **Physical Capacity** - Enter the physical capacity of the LSU (1 to 1048576 GB).

Note: Quantum recommends setting LSUs to maximum size (1048576 GB) because spanning them on a backup is not possible.

- 4 (Optional) In the **Description** box, enter a brief description of the LSU.

- 5 Click **Apply**.

Editing a Storage Server


Edit a storage server to change the description of the storage server or the maximum number of allowed connections.

To edit a storage server:

- 1 Select the storage server and click **Edit**.

The **Edit Storage Server** page displays (see [Figure 93](#)).

Figure 93 Edit Storage Server Page



- 2 Enter information about the storage server:

Note: If you are editing a storage server, only the **Description** and **Max Connections** options can be changed.

- **Description** - (Optional) Enter a brief description of the storage server.
- **Max Connections** - Enter the maximum number of connections allowed to the storage server (3 to 65536).

The maximum number of connections cannot be changed if the storage server has more than zero currently active connections. The number of active connections is displayed on the **OST** page (see [Storage Server List](#) on page 164).

Note: Quantum recommends setting **Max Connections** to 300.

- 3 Click **Apply**.

Deleting a Storage Server

Delete a storage server if it is no longer needed. When you delete a storage server, all data stored on the storage server is lost.

Note: If you deleted the storage server from Symantec NetBackup or Symantec Backup Exec, you must wait several minutes before deleting the storage server from the DXi4000.

To delete a storage server:

- 1 Select the storage server in the **Storage Server List**.

You cannot delete a storage server if it has more than zero currently active connections. The number of active connections is displayed on the **OST** page (see [Storage Server List](#) on page 164). Also, you cannot delete a storage server if it contains LSUs. Before deleting the storage server, you must first delete any LSUs it contains (see [Deleting an LSU](#) on page 173).

Note: You can select multiple storage servers to delete at once.


- 2 Click **Delete**.

LSU

The **LSU** page allows you to manage the logical storage units (LSUs) contained on OST storage servers on the DXi4000. You can view information about existing LSUs, add or edit LSUs, and delete LSUs.

To access the **LSU** page, on the **OST** page, click the **LSU** tab (see [Figure 94](#)).

Figure 94 LSU Page



Use the **LSU** page to perform the following tasks:

- View information about existing LSUs (see [Logical Storage Unit List](#) on page 169).
- Add a new LSU to the system (see [Adding an LSU](#) on page 170).
- Edit properties for an existing LSU (see [Editing an LSU](#) on page 171).
- Delete an LSU from the system (see [Deleting an LSU](#) on page 173).

Logical Storage Unit List

The **Logical Storage Unit List** displays the following information for all LSUs on the DXi4000:

- **LSU Name** - The name of the LSU.
- **Storage Server** - The storage server that contains the LSU.
- **Physical Capacity** - The physical storage capacity of the LSU.
- **Active Connections** - The number of currently active connections to the LSU.
- **Backup Images** - The number of backup images on the LSU.
- **Description** - A brief description of the LSU (if available).

Note: Click a column heading to sort the rows in the table by that column. Click the column heading again to reverse the sort order.

Adding an LSU

Add an LSU to a storage server to present the storage capacity of the DXi4000 as an LSU that is compatible with backup applications that support OST. You can add an LSU with a specific capacity, or you can add an LSU that uses the available capacity of the DXi4000.


Note: You must create a storage server before you can add an LSU (see [Adding a Storage Server](#) on page 164).

To add an LSU to a storage server:

- 1 Click **Add**.

The **Add Logical Storage Unit** page displays (see [Figure 95](#)).

Figure 95 Add Logical Storage Unit Page



The screenshot shows the Quantum DXi4000 web interface. The top navigation bar includes 'Quantum', 'DXi:4601', 'Normal', 'Mon Dec 19 2011 - 8:50:07 AM PST', 'Admin', 'Ticket', 'Low Capacity', 'Logout', 'Administrator', and 'Help'. The main menu includes 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards'. The 'Configuration' menu is expanded, showing 'Storage Servers', 'LSU', 'Manage Users', 'Accent', and 'OST Client Plug-in'. The 'Add Logical Storage Unit' dialog box is open, featuring a 'Storage Server' dropdown menu with 'pingost' selected. Below this are two radio buttons: 'Available Capacity' (selected) and 'Specific Capacity'. There are three input fields: '* LSU Name', '* Physical Capacity' (with a value of '(1 to 1048576 GB)'), and 'Description'. A legend indicates that an asterisk (*) denotes a required field. At the bottom of the dialog are 'Apply', 'Reset', and 'Cancel' buttons.

- 2 Enter information about the LSU.

Note: For best performance, an LSU should not contain more than 250 backup images. If you will need to store more than 250 backup images on the DXi, you should create additional storage servers and LSUs.

- **Storage Server** - Select the storage server that will contain the new LSU.
- **Available Capacity** - (Recommended for best performance) Select this option to add an LSU that uses the available capacity on the system.

You cannot add an available capacity LSU to a storage server that already contains an LSU. Also, if you add an available capacity LSU to a storage server, you cannot add additional LSUs to that same storage server.

Note: After you add an LSU that uses the **Available Capacity** option, you cannot change the LSU to use the **Specific Capacity** option. Instead, you must delete the LSU, then add a new LSU and choose the **Specific Capacity** option (see [Deleting an LSU](#) on page 173).

- **Specific Capacity** - Select this option to specify the physical capacity of the LSU, and then enter the following information.
 - **LSU Name** - Enter the name of the LSU.
 - **Physical Capacity** - Enter the physical capacity of the LSU (1 to 1048576 GB).

Note: Quantum recommends setting LSUs to maximum size (1048576 GB) because spanning them on a backup is not possible.

3 (Optional) In the **Description** box, enter a brief description of the LSU.

4 Click **Apply**.

Editing an LSU


Edit an LSU to change the description of the storage server or the maximum number of allowed connections.

To edit an LSU:

- 1 Select the LSU and click **Edit**.

The **Edit Logical Storage Unit** page displays (see [Figure 96](#)).

Figure 96 Edit Logical Storage Unit Page



- 2 Enter information about the LSU:

Note: If you are editing an available capacity LSU, only the **Description** option can be changed. If you are editing a specific capacity LSU, only the **Physical Capacity** and **Description** options can be changed.

- **Physical Capacity** - (Specific capacity LSUs only) Enter the physical capacity of the LSU (1 to 1048576 GB).

The physical capacity cannot be changed if the LSU has more than zero currently active connections. The number of active connections is displayed on the **LSU** page (see [Logical Storage Unit List](#) on page 169).

- **Description** - (Optional) Enter a brief description of the LSU.

- 3 Click **Apply**.

Deleting an LSU

Delete an LSU if it is no longer needed. When you delete an LSU, all data stored on the LSU is lost.

Note: If you deleted the LSU from Symantec NetBackup or Symantec Backup Exec, you must wait several minutes before deleting the LSU from the DXi4000.

To delete an LSU:

1 Select the LSU in the **Logical Storage Unit List**.

You cannot delete an LSU if it has more than zero currently active connections. The number of active connections is displayed on the **LSU** page (see [Logical Storage Unit List](#) on page 169).

Note: You can select multiple LSUs to delete at once.

2 (Optional) Select the **Force Delete LSU** check box to delete LSUs that are not empty.

Normally, you cannot delete an LSU if it contains existing backup images. If for some reason you cannot remove files from the LSU, selecting the **Force Delete LSU** check box allows you to delete the LSU even though it is not empty.


3 Click **Delete**.

Manage Users

The **Manage Users** page allows you to create and manage authenticated users for use with OST. After you create the OST user credentials, enter them in the backup application to authenticate OST devices on the media server.

To access the **Manage Users** page, on the **OST** page, click the **Manage Users** tab (see [Figure 97](#)).

Figure 97 Manage Users Page



Use the **Manage Users** page to perform the following tasks:

- View information about authenticated users (see [Authenticated User List](#) on page 174).
- Add an authenticated user (see [Adding an Authenticated User](#) on page 174).
- Edit an authenticated user (see [Editing an Authenticated User](#) on page 175).
- Delete an authenticated user (see [Deleting an Authenticated User](#) on page 176).

Authenticated User List

The **Authenticated User List** section displays the following information for all authenticated users:

- **Username** - The name of the authenticated user.
- **Description** - A brief description of the authenticated user (if available).

Adding an Authenticated User


Add an authenticated user to create OST user credentials. The OST user credentials are required to authenticate OST devices on a media server.

To add an authenticated user:

- 1 Click **Add**.

The **Add Authenticated User** page displays (see [Figure 98](#)).

Figure 98 Add Authenticated User Page



- 2 Enter information about the authenticated user:

- **Username** - Enter the name of the authenticated user.
- **Password** - Enter the password for the authenticated user.
- **Confirm Password** - Enter the password again to confirm it.
- **Description** - (Optional) Enter a brief description of the authenticated user.

- 3 Click **Apply**.

Editing an Authenticated User


Edit an authenticated user to change the user's password or description.

To edit an authenticated user:

- 1 Select the user and click **Edit**.

The **Edit Authenticated User** page displays (see [Figure 99](#)).

Figure 99 Edit Authenticated
User Page



2 Enter information about the authenticated user:

Note: If you are editing an authenticated user, you cannot change the **Username**.

- **Username** - (Optional) Select a different authenticated user to edit.
- **New Password** - Enter the password for the authenticated user.
- **Confirm New Password** - Enter the password again to confirm it.
- **Description** - (Optional) Enter a brief description of the authenticated user.

3 Click **Apply**.

Deleting an Authenticated User

Delete an authenticated user if the OST user credentials are no longer needed to authenticate OST devices on a media server.

To delete an authenticated user, select the user and click **Delete**.

Note: You can select multiple users to delete at once.


DXi Accent

Use the **Accent** page to enable or disable DXi Accent. Quantum's DXi Accent software accelerates backups and reduces network bandwidth requirements by distributing deduplication between the backup server and the DXi.

Note: DXi Accent is supported only on DXi4601.

To access the **Accent** page, on the **OST** page, click the **Accent** tab (see [Figure 97](#)).

Figure 100 Accent Page



To configure DXi Accent:

- 1 To enable DXi Accent, select the **Enable Inline Dedupe with Accent** check box.

Or to disable DXi Accent, clear the **Enable Inline Dedupe with Accent** check box.

- 2 (Optional) Select the **Use Encryption** check box selected to enable encryption when sending OST data from the media server to the DXi.

Or clear the **Use Encryption** check box to disable encryption when sending OST data from the media server to the DXi.

If encryption is enabled, select an encryption strength (**128-bit** or **256-bit**). Using 256-bit encryption (default) provides a stronger

level of security but may have an impact on system performance in some situations.

3 Click Apply.

Note: To use DXi Accent, you must install the Quantum OST Client Plug-in on the media server. For information about installing the OST Plug-in and using DXi Accent, see the *Symantec NetBackup OST Configuration Guide*.

OST Client Plug-In

Use the **OST Client Plug-In** page to download the Quantum OST Plug-in.

OST (OpenStorage) technology allows Symantec NetBackup and Backup Exec to seamlessly integrate with the DXi4000. Using OST, NetBackup and Backup Exec can manage backups through the DXi4000 and can take advantage of the system's capabilities, such as data deduplication and replication. To use OST, you must first download the OST Plug-in and install it on the NetBackup or Backup Exec media server.

To download the OST Plug-in, click **Client Plug-in Download**. On the download page, download the correct OST Plug-in for your backup application and operating system. Also on the download page, click **Installation Instructions**, to download the *OST Plug-in Installation Instructions*. Follow the included instructions to install the OST Plug-in on your media server.

Note: For information about configuring and using OST with the DXi4000, see the *Symantec NetBackup OST Configuration Guide* and the *Symantec Backup Exec OST Configuration Guide*.


Scheduler

The **Scheduler** page allows you to manage scheduled events on the DXi4000, including replication throttling, healthchecks, and space reclamation. With schedules, you specify when certain events should occur, and the system automatically performs those events at the

specified time. Events can be one-time only, or they can reoccur at defined intervals.

To access the **Scheduler** page, click the **Configuration** menu, and then click the **Scheduler** tab (see [Figure 101](#)).

Figure 101 Scheduler Page



Use the **Scheduler** page to perform the following tasks:

- View currently scheduled replication throttle, healthchecks, and space reclamation events (see [Viewing Scheduled Events](#) on page 179).
- Add and edit replication throttle events (see [Scheduling Replication Throttling](#) on page 180).
- View healthchecks events (see [Scheduling Healthchecks](#) on page 183).
- View space reclamation events (see [Scheduling Space Reclamation](#) on page 184).


Viewing Scheduled Events

The **Scheduler** page displays all replication throttle, healthchecks, and space reclamation events scheduled to occur in a selected time period.

Use the following controls to adjust the schedule view (see [Figure 101](#)):

- To change the number of days displayed at a time, select **Daily View**, **Weekly View**, or **Monthly View** in the drop-down list at the top of the schedule view.
- To move the view backward or forward in time, click the arrows at the upper left and upper right of the schedule view.
- To view the schedule for a specific day, select it in the **Date** pop-up calendar.
- To update the schedule view with the latest data, click the **Refresh** icon.

Figure 102 Scheduler View Controls



Scheduling Replication Throttling

During replication throttling, the DXi4000 limits the amount of source replication data it sends to not exceed a specified maximum bandwidth. Schedule replication throttling to control the amount of network bandwidth used by source replication at certain times. For example, you might configure replication throttling to occur during planned backup times to avoid network contention.

Note: For more information about replication, see [DXi4000 Replication](#) on page 81.

About Replication Throttling Statistics

Keep in mind the following information when observing actual network bandwidth usage during a replication throttle event:

- During a replication throttle event, only outgoing replication data traffic is throttled, not other outgoing traffic. Because of this, you may observe network usage to be higher than the specified

maximum bandwidth. Differences in the sampling time period may also cause discrepancies between the specified maximum bandwidth and observed traffic.

- If the DXi is configured to use a bonded network interface for replication traffic, load balancing is determined independently by the bonding mode selected for the interface (see [Network](#) on page 184). Because of this, you may need to sum the values for all slave devices in the bonded interface to calculate the overall outgoing traffic rate.
- The replication throttle bandwidth maximum is specified in KB/s or MB/s, so depending on the statistic or report you are observing, you may need to convert the bandwidth maximum to Kb/s or Mb/s in order to correctly compare it to the observed values.

Adding or Editing a Replication Throttle Schedule

To add or edit a replication throttling schedule:

- 1 On the **Scheduler** page, adjust the schedule view to display the time period when the event will occur (see [Viewing Scheduled Events](#) on page 179). Then do one of the following actions:

- To add a new replication throttle event, click and drag on the schedule in the **Replication Throttle** row (see [Figure 103](#)). A new event is added where you dragged the cursor.

Note: The new event must begin after the current time, which is indicated by the red vertical line.

- To edit an existing replication throttle event, double-click the event in the **Replication Throttle** row. If the event is recurring, select **Open this occurrence** to edit only the one instance of the event, or select **Open the series** to edit the entire recurring series, and then click **OK**.

- 2 Define the start and end of the event.

- Specify the **Start Date** and **Start Time** using the pop-up calendar and drop-down list.
- If the event will have a defined end, specify the **End Date** and **End Time**. The end date and time must occur after the start date and time.

Note: For a new event, you can click and drag in the **Replication Throttle** row to adjust the start and end time. For an existing event, you can drag the event to change when it occurs. You can also drag the left or right edge of the event to adjust the start or end time.

- 3 Enter a brief description of the event in the **Description** box. The description displays on the schedule view.
- 4 Specify the maximum allowed bandwidth by entering a value in the **Bandwidth** box and selecting the units in the drop-down list (**KB/s**, or **MB/s**). The lowest value you can set is 32 KB/s. The highest value you can set is 125 MB/s.

During the replication throttle event, the DXi will limit the amount of data it sends during source replication so that it does not exceed the specified bandwidth. After the replication throttle event ends, the DXi will no longer throttle the sending of source replication data (until the next replication throttle event occurs).

Caution: Do not set the maximum allowed bandwidth to a value that is lower than necessary. If the maximum allowed bandwidth is set to the lowest value, large replication jobs may fail.

- 5 In the **Repeats** drop-down list, select **Does not repeat** to disable recurrence. Or to enable recurrence, select how often the event reoccurs:
 - **Daily** - Specify the recurrence interval in days.
 - **Weekly** - Specify the recurrence interval in weeks, and select the days the event occurs on.
 - **Monthly** - Specify the recurrence interval in months, and specify the day the event occurs on (for example, the 1st day of each month or the third Friday of each month).
 - **Yearly** - Specify the recurrence interval in years, and specify the date and month the event occurs on (for example, the 15th day of March or the first Monday in May).


For recurring events, specify how long the recurrence continues (**forever**, **for** a certain number of occurrences, or **until** a specific date).

6 Click Save.

Caution: When adding multiple events, make sure the events do not overlap. If two events overlap, the later event takes precedence over the earlier event.

Figure 103 Scheduling a Replication Throttle Event

Click and drag to add a new replication throttle event



Scheduling Healthchecks

During healthchecks, the DXi4000 performs tests to verify the health and integrity of the data deduplication blockpool. Schedule healthchecks regularly to make sure the system is healthy and operating correctly.

Use the **Healthchecks** page to configure a healthchecks schedule (see [Healthchecks](#) on page 232). After a healthchecks schedule is configured, it appears on the **Scheduler** page. Double-click a healthchecks event on the **Scheduler** page to view or edit the healthchecks schedule on the **Utilities > Healthchecks > Schedule** page.

Note: To quickly access the **Healthchecks** page, click the **Healthchecks** link in the schedule view.

Scheduling Space Reclamation

During space reclamation, the DXi4000 deletes unneeded tags from the blockpool to free up disk space. Schedule space reclamation regularly to make sure there is enough disk space to store data.

Use the **Space Reclamation** page to configure a space reclamation schedule (see [Space Reclamation](#) on page 240). After a space reclamation schedule is configured, it appears on the **Scheduler** page. Double-click a space reclamation event on the **Scheduler** page to view or edit the space reclamation schedule on the **Utilities > Space Reclamation > Schedule** page.

Note: To quickly access the **Space Reclamation** page, click the **Space Reclamation** link in the schedule view.

System

The **System** page allows you to configure system settings for the DXi4000, including network settings, system date and time, and security settings.

To access the **System** page, click the **Configuration** menu, and then click the **System** tab.

The **System** page contains the following tabs:

- [Network](#)
- [Date & Time](#)
- [Security](#)

Network

The **Network** page allows you to view and change network configuration information for the DXi4000. The DXi4000 uses this information to connect to the network.

Network configuration information is entered during initial setup DXi4000. You should consult your network administrator before making any changes to the network settings.

Caution: Changing the network configuration requires a system reboot to allow all system services to function correctly. Changing the network configuration requires a system reboot immediately after the changes are applied.

Note: Rebooting the system can take several minutes. After the new network configuration is saved, close your Web browser and wait 15 minutes before logging in again. If you change the IP address that you use to log in to the system, you will temporarily lose your connection to the remote management console. Because of this, you might not see a confirmation page informing you that the new settings have been saved.

To access the **Network** page, on the **System** page, click the **Network** tab (see [Figure 104](#)).

Figure 104 Network Configuration

Quantum DXi4601 | Normal | Tue Dec 20 2011 - 10:50:45 AM PST | Admin | Ticket | Low Capacity | Logout Administrator Help

Home | Network | Date & Time | Security

Replication | Network Configuration

Status

Alerts

Configuration

Utilities

Wizards

DXi Advanced Reporting

General

* Hostname: ping | Primary DNS IP Address: 10.10.10.10
 Default Gateway: 10.10.10.10 | Secondary DNS IP Address:
 DNS Suffix Search List: quantum-sqa.com | Tertiary DNS IP Address:

Note: Domain Suffix Search List and DNS IP addresses cannot be changed while the DXi is joined to a Windows domain. To disjoin from the domain, go to the Windows Domain page.

IP Address Configuration

Hide Bonding Details

Note: To maintain system network connectivity the switch connected to your system must be configured to use the same bonding mode.

Not Bonded	eth2(1GbE)	eth3(1GbE)	eth4(1GbE)	eth5(1GbE)	* Bonding Mode
bond0	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	N/A
bond1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Round Robin (Mode 0)

Update | Undo

Hide Interface Details

Jumbo Frame	Physical Ports	Bonding Mode	Link Speed	Link Status	Carrier Status
bond0	<input type="checkbox"/>	eth2,eth3,eth4,eth5	Round Robin (Mode 0)	1GbE	Up

Update | Undo

IP Address Table

Note: A maximum of 10 IP addresses per interface are allowed.

Interface	* IP Address	* Netmask	* Gateway	Mgmt	Repl	Data	Any
bond0.2	10.10.10.10	255.255.255.0	10.10.10.10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Add IP | Update | Delete | Undo

Hide Routing Details for bond0.2

Destination	Dest Netmask	Dest Gateway
bond0.2	10.10.10.0	255.255.255.0

Add Route | Update | Delete | Undo

Physical Ports Layout

Location of Ethernet ports on rear of system.

<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
ETH2	ETH3	ETH4	ETH5

Connected | Configured - No Carrier

bond0: ETH2 + ETH3 + ETH4 + ETH5 (Bonded together) | Internal ports

Note: Click refresh to update Ethernet port connectivity status.

* Required Field

Apply | Reset

Configuring the Network

Using the **Network** page, each individual interface on the DXi can be configured as a subnet with its own network settings. Each physical Ethernet port can be configured as an interface. You can enable jumbo frames and add multiple IP addresses and routes for each interface. In addition, you can also create bonded interfaces (logical ports) consisting of two or more physical ports.

Keep in mind that any traffic can pass through any of the configured Ethernet ports. This means that the routing of different traffic types, as well as firewall capability, must be controlled using the network infrastructure (routers and switches) that the DXi is connected to.

To perform network configuration:

- 1 Under **General**, enter the following network information as provided by your network administrator:

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.

- **Hostname** - The hostname of the DXi4000.
- **Default Gateway** - The default gateway IP address.

Specifying a default gateway is optional if all access is local to a particular subnet. For example, if the DXi4000 and all of its clients are on the same subnet, you do not need to specify a default gateway.

Caution: Specifying a default gateway is required to enable connectivity with all subnets other than those that the DXi4000 is directly connected to. For example, if the DXi4000 and its clients are on different subnets, you must specify a default gateway.

- **Domain Suffix Search List** - (Optional) The local domain to search first when resolving domain names.

The domain suffix is a single domain name. The domain name may contain only letters (A–Z), numbers (0–9), dots (.), and hyphens (-).

- **Primary, Secondary, and Tertiary DNS IP Address - (Optional)**
The IP addresses of up to three DNS servers used to resolve domain names and translate them into IP addresses.

Note: You must specify a DNS IP address if you plan to use hostname format when configuring an NTP time server, outgoing e-mail server, replication sources and targets, and other information.

Note: The **Domain Suffix Search List** and **DNS IP Addresses** cannot be modified if the DXi4000 is currently joined to a Windows domain. To disjoin a Windows domain, see [Windows Domain](#) on page 146.

- 2 Under **IP Address Configuration > Bonding Details**, configure bonded interfaces:
 - a If necessary, click the **Show** link to show the bonding details table.
 - b For each available interface (**bond0**, **bond1**, and so on), select one or more Ethernet ports with the same link speed to assign to the bond. Or select **Not Bonded** to leave a port unassigned to any bond.

If no ports are assigned to a bond, the bond cannot be configured. That is, settings cannot be entered for the bond in the **Interface Details** or **IP Address** tables because no Ethernet ports are assigned to the port.

All ports assigned to the same interface are bonded together into a single logical port. For example, if you select **bond0** for port **eth0** and port **eth1**, both ports are bonded together in the **bond0** interface. A bonded interface can contain two or more ports.
 - c For each bonded interface, specify the bonding mode:

Note: To maintain network connectivity, the switch connected to the DXi4000 must be configured to use the same bonding mode. The best time to change the bonding mode on the switch is during the next reboot of your system, after saving the new network settings. Changing the bonding mode on the switch before saving these settings and rebooting may result in the loss of network connectivity to the system.

- **Round Robin (Mode 0)** - This option sends Ethernet frames using the bonded Ethernet ports with a valid MII link. Frames are sent in a round-robin fashion, starting with the first slave device and then the rest of the devices. This only applies to the traffic sent from the DXi4000. The Ethernet switch needs to aggregate the ports, so the connected ports are treated as a logical port. The frame reception is completely dependent on the transmission algorithm of the Ethernet switch. The bonding mechanism does not balance the frame reception.
 - **LACP (Mode 4)** - This option (Link Aggregation Control Protocol) is based on the 802.3ad IEEE standard for aggregating Ethernet ports. If the bonding algorithm is set to LACP, the Ethernet switch ports must be configured in a 802.3ad based Link Aggregation group (LAG) in LACP mode. The frame reception and transmission is controlled by the LACP between the bonded ports and the Ethernet switch ports.
- d Click **Update** to save the changes you made to the **Bonding Details** table. (Clicking **Update** does not yet apply the new network settings to the DXi4000.)
- Click **Undo** to revert to all current Bonding Details changes to the last update.
- 3 Under **IP Address Configuration > Interface Details**, configure jumbo Ethernet frame settings for each interface:
- a If necessary, click the **Show** link to show the interface details table.
 - b For each interface, select the **Jumbo Frame** check box to enable jumbo frames for the interface.

Or clear the **Jumbo Frame** check box to disable jumbo frames for the interface.

If jumbo frames are enabled, the MTU (Maximum Transmission Unit) frame size is set to 9,000 bytes. Otherwise, the standard MTU (STD) frame size of 1,500 bytes is used.

Note: If the MTU size is greater than 1,500 and less than 9,000, the **Network** page displays the MTU size as read only. In this case, MTU size can only be set using the `syscli`. For information, see the *DXi-Series Command Line Interface (CLI) Guide (6-67081)*.

- c Click **Update** to save the changes you made to the **Interface Details** table. (Clicking **Update** does not yet apply the new network settings to the DXi4000.)

Click **Undo** to revert to all current Interface Details changes to the last update.

- 4 Under **IP Address Configuration > IP Address Table**, enter network information for each interface (physical Ethernet port or bonded interface):

- a Click the **Add IP** link to add IP address information for an interface.

Or select an interface to edit the IP address, netmask, gateway and traffic type. (To select an interface, click the radio button next to the interface index name, for example, **bond0:2**.)

Note: A maximum of 10 IP addresses are allowed per interface. All IP addresses in the IP Address Table (added or modified) must be valid and unique, and must have a valid gateway and netmask.

- b Enter the following network information as provided by your network administrator (all fields are required):
- **IP Address** - The IP address of the interface.
 - **Netmask** - The network mask of the interface.
 - **Gateway** - The gateway IP address. (The gateway for a directly connected interface is the IP address.)

- c Select the check box for each type of network traffic allowed on the interface:

Note: At least one interface must allow management traffic.

- **Mgmt** - Select to allow management traffic.
 - **Repl** - Select to allow replication traffic.
 - **Data** - Select to allow data traffic.
 - **Any** - Select to allow all types of traffic (management, replication, and data).
- d Click **Update** to save the changes you made to the **IP Address** table. (Clicking **Update** does not yet apply the new network settings to the DXi4000.)

Click **Delete** to remove IP address information for the selected interface. Or click **Undo** to revert all current IP Address Table changes to the last update.

- 5 Under **IP Address Configuration > Routing Details**, enter routing information for one or more interfaces:
- a In the **IP Address Table** (above routing details), select an interface to add or modify routing data. (To select an interface, click the radio button next to the interface index name, for example, **bond0:2**.)

After selecting an interface in the **IP Address Table**, the **Routing Details** table below expands to display available routes (if any).

Note: A maximum of 8 routes per interface are allowed.

- b If necessary, click the **Show** link to show the routing details table.
- c Click **Add Route** to add a route to the selected interface.
Or select a route to edit its settings.
- d Enter the following network information as provided by your network administrator:
- **Destination** - The destination network for the route.
 - **Dest Netmask** - The network mask for the route.

- **Dest Gateway** - (Optional) The gateway IP address for the route.
- e Click **Update** to save the changes you made to the **Routing Details** table. (Clicking **Update** does not yet apply the new network settings to the DXi4000.)
- Click **Delete** to remove IP routing information for the selected interface. Or click **Undo** to revert all current Routing Details changes to the last update.

6 Click **Apply**.

Note: To revert all network settings to the initial state and undo all changes, click the **Reset** button. For network changes to take effect, you must apply the changes, finalize the confirmation, and reboot the system.

Physical Ports Layout

The **Physical Ports Layout** section at the bottom of the **Network** page displays a graphical representation of the Ethernet ports as they appear on the rear of the system.

The grid indicates the current bonding configuration and connectivity status for all Ethernet ports.

- Ports that are bonded together in an interface are shaded the same color.
- A green border indicates a port is connected to a network.
- A red border indicates a port is configured but is not connected to a network.
- Click the **refresh** link to update the information in the grid.


Date & Time

The **Date & Time** page allows you to set the system date and time of the DXi4000. You can specify a Network Time Protocol (NTP) server to synchronize the system time with, or you can manually enter the date and time.

Note: If you intend to join the DXi4000 to a Windows network using Active Directory for NAS storage, Quantum recommends using an NTP Server to set the system date and time (see [Windows Domain](#) on page 146).

To access the **Date & Time** page, on the **System** page, click the **Date & Time** tab (see [Figure 105](#)).

Figure 105 Date & Time Page



To set the system date and time:

1 Select one of the following options:

- **Network Time Protocol (NTP) Server - (Recommended)** Select this option to synchronize the DXi4000 with an NTP timeserver or pool. Then select or specify a timeserver or pool.
- **Select a Timeserver Pool - (Recommended)** Select one of the well-known, geographically-based NTP timeserver pools in the drop-down box.

Note: To select a timeserver pool, you must first specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184). Otherwise, you must specify the IP address of the timeserver pool.

- **Specify a Timeserver or Pool** - Type the name or IP address of the NTP server or pool. (See <http://support.ntp.org> for information about publicly available NTP servers)

To verify that the DXi4000 can communicate with the NTP server or pool, click **Test NTP**.

- **Manual Date & Time Settings** - Select this option to manually set the system date and time.

Specify the **New System Date** by clicking the calendar icon. Specify the **New System Time** using the drop-down boxes.

- 2 In the **Timezone** drop-down box, select the time zone where the DXi4000 is located.
- 3 Next to **Time Format**, select the format to use when displaying times (**24 hours** or **12 hours**).
- 4 Click **Apply**.

Security

The **Security** page allows you to configure security settings for the DXi4000, including access passwords, SSL settings, and the inactivity timeout.

To access the **Security** page, click the **Configuration** menu, and then click the **Security** tab.

The **Security** page contains the following tabs:

- [Web & CLI Passwords](#)
- [SSL](#)
- [Login Session](#)
- [Security Banner](#)

Web & CLI Passwords


The **Web & CLI Passwords** page allows you to change the account passwords for the remote management console (**Web**) and the command line interface (**CLI**). You can also enable or disable the CLI account.

The DXi4000 has two access levels for logging onto the remote management console or the CLI:

- **Monitor** - Allowed to view information on the DXi4000 remote management console or the CLI but cannot make changes.
- **Administrator** - Allowed to view and change information on the DXi4000 remote management console or the CLI.

To access the **Web & CLI Passwords** page, on the **Security** page, click the **Web & CLI Passwords** tab (see [Figure 106](#)).

Figure 106 Web & CLI Passwords Page



Use the **Web & CLI Passwords** page to perform the following tasks:

- Change the administrator or monitor password for Web access (see [Changing Web Passwords](#) on page 196).
- Enable or disable CLI access for the administrator or monitor account (see [Enabling CLI Accounts](#) on page 196).
- Change the administrator or monitor password for CLI access (see [Changing CLI Passwords](#) on page 197).
- Reset the CLI administrator or monitor password to the factory default (see [Resetting CLI Passwords](#) on page 197).

Changing Web Passwords

Use the Web passwords when logging onto the remote management console as an administrator or monitor (see [Accessing Remote](#)

[Management](#) on page 28).

To change the Web passwords:

1 Under **Web Administrator Password** or under **Web Monitor Password**, enter the following information:

- **Old Password** - Enter the old password.
- **New Password** - Enter the new password.
- **Confirm New Password** - Enter the new password again to confirm it.

Note: The default password is **password**.

Note: Passwords are limited to 15 characters. All alphanumeric characters are allowed, as well as underscores (`_`) and hyphens (`-`).

2 Click **Apply**.

Enabling CLI Accounts

The CLI accounts provide access to the DXi4000 command line interface as an administrator or monitor.

Note: For more information about using the CLI, see the *DXi4000 Command Line Interface (CLI) Guide*.

To enable or disable the CLI accounts:

1 Under **CLI Administrator Login Settings** or under **CLI Monitor Login Settings**, do one of the following steps:

- Select the **Enable CLI Login** check box to enable the CLI account.
- Clear the **Enable CLI Login** check box to disable the CLI account.

2 Click **Apply**.

Changing CLI Passwords

Use the CLI passwords when logging onto the command line interface as an administrator or monitor.

To change the CLI passwords:

- 1 Under **CLI Administrator Login Settings** or under **CLI Monitor Login Settings**, select the **Change password** option.
- 2 Enter the following information:
 - **Old Password** - Enter the old password.
 - **New Password** - Enter the new password.
 - **Confirm New Password** - Enter the new password again to confirm it.

Note: The default password for the CLI Administrator account is **cliadmin**. The default password for the CLI Monitor account is **cliviewer**.

Note: Passwords are limited to 15 characters. All alphanumeric characters are allowed, as well as underscores (**_**) and hyphens (**-**).

- 3 Click **Apply**.

Resetting CLI Passwords

The default password for the CLI Administrator account is **cliadmin**. The default password for the CLI Monitor account is **cliviewer**.

To reset the CLI account passwords to their default values:


- 1 Under **CLI Administrator Login Settings** or under **CLI Monitor Login Settings**, select the **Reset password to factory default** option.
- 2 Click **Apply**.

SSL

The **SSL** page allows you to enable or disable SSL on the DXi4000. You can also install a new SSL certificate to replace the Quantum default SSL certificate.

To access the **SSL** page, on the **Security** page, click the **SSL** tab (see [Figure 107](#)).

Figure 107 SSL Page



Use the **SSL** page to perform the following tasks:

- Enable or disable SSL on the DXi4000 (see [Enabling SSL](#) on page 198).

Note: If you enable SSL, see [Server Authentication Warnings](#) on page 199 for important information about Web browser settings.

- Install a new SSL certificate (see [Installing an SSL Certificate](#) on page 199).

Enabling SSL

SSL (Secure Sockets Layer) is a protocol that provides security and privacy over the Internet by negotiating encryption keys before transmitting data between a client and a server.

To establish a secure connection, the DXi4000 must have an encryption key assigned to it by a Certification Authority in the form of a certificate file, private key file, and pass phrase. After you install these components, you can establish a secure connection using the SSL protocol. The DXi4000 comes with a Quantum default SSL certificate.

To enable or disable SSL:

- 1 Under **SSL Properties**, select the **Enable SSL** option to enable SSL.
Or select the **Disable SSL** option to disable SSL.

Note: The default setting is disabled.

2 Click **Apply**.

Server Authentication Warnings

Enabling SSL with the default Quantum certificate allows you to securely communicate with the DXi4000 Web-based interface using SSL encryption. However, you may receive a warning from your Web browser stating that the server you are attempting to connect to does not match the server embedded within the certificate.

This is expected behavior because the default certificate can only be used for encryption and not server authentication. You can install your own custom certificate in order to take advantage of server authentication in addition to encrypted communication.

To suppress server authentication warnings for the default certificate:

- **Internet Explorer** - If a dialog box displays warning you of a possible certificate error, add the IP address for the DXi4000 to the **Trusted Sites** list (**Tools > Internet Options > Security > Trusted Sites**). If subsequent warning pages display along with an option to close your Web browser or continue to the Web site, click **Continue**. This suppresses the warnings until you restart your Web browser.
- **Firefox** - If the **Secure Connection Failed** dialog box displays, click the link at the bottom of the dialog box and follow the instructions to add an exception for your DXi4000.

Installing an SSL Certificate

You can purchase and install your own custom SSL certificate in order to take advantage of server authentication in addition to encrypted communication on the DXi4000.

To install an SSL certificate:

1 Under **Certificate**, click **New**.

The **Install New Certificate** page displays (see [Figure 108](#)).

Figure 108 Install New Certificate Page



2 In the **Certificate File** box, type the location and filename of the new SSL certificate file.

Or click **Browse** to browse the system and locate the SSL certificate file. The SSL certificate file must be named **server.crt**.

3 Click **Upload**.

4 Type your SSL private key and press **<Enter>**.

5 Type your SSL pass phrase and press **<Enter>**.

A **Successful Upload** page displays stating that the SSL certificate file has been installed on the system.

6 Click **OK**.

The certificate displays in the **Certificate** section.


Login Session

The **Login Session** page allows you to specify the inactivity timeout for the DXi4000 remote management console. The default timeout is 30 minutes.

When the remote management console is inactive for the specified period of time, the user is automatically logged off and must log back on to continue (see [Accessing Remote Management](#) on page 28).

To access the **Login Session** page, on the **Security** page, click **Login Session** (see [Figure 109](#)).

Figure 109 Login Session Page



To specify the inactivity timeout:

- 1 In the **Inactivity Timeout** box, enter the number of minutes of inactivity before a user is automatically logged off (1–60 minutes).
- 2 Click **Apply**.


Security Banner

The **Security Banner** page allows you to specify a message that will appear to all users when logging on to the remote management console or the CLI (command line interface).

If a security banner message has been specified, the user must accept the message in order to begin using the system. If no banner content has been specified, the user can use the system immediately after logging on.

To access the **Security Banner** page, on the **Security** page, click **Security Banner** (see [Figure 110](#)).

Figure 110 Security Banner
Page



To add or update a security banner message, enter the security message in the box and click **Apply**.

Notifications

The **Notifications** page allows you to manage the methods the DXi4000 uses to send notifications. The DXi4000 can send notifications by e-mail or using SNMP (Simple Network Management Protocol).

To access the **Notifications** page, click the **Configuration** menu, and then click the **Notifications** tab.

The **Notifications** page contains the following tabs:

- [Email](#)
- [SNMP](#)

Email

The **Email** page allows you to specify the recipients to notify by e-mail when administration alerts or service tickets occur. You can specify e-mail recipients, notification levels, and information about your e-mail

configuration. You can also configure the DXi4000 to generate and send configuration and status reports.

Note: For more information about administration alerts and service tickets, see [DXi4000 Alerts](#) on page 129.

To access the **Email** page, on the **Notifications** page, click the **Email** tab.

The **Email** page contains the following tabs:

- [Recipients](#)
- [Server](#)
- [Test](#)
- [Email Home](#)


Recipients

The **Recipients** page allows you to manage the e-mail recipients the DXi4000 sends notifications to. You can add, edit, and delete e-mail recipients, and you can specify the types of notifications to send.

Note: To enable the DXi4000 to send e-mail, you must specify an outgoing e-mail server (see [Server](#) on page 208).

To access the **Recipients** page, on the **Email** page, click the **Recipients** tab (see [Figure 111](#)).

Figure 111 Recipients Page



Use the **Recipients** page to perform the following tasks:

- View information about e-mail recipients (see [Email Recipient List](#) on page 204).
- Add an e-mail recipient (see [Adding an E-mail Recipient](#) on page 205).
- Edit an e-mail recipient (see [Editing an E-mail Recipient](#) on page 206).
- Delete an e-mail recipient (see [Deleting an E-mail Recipient](#) on page 207).

Email Recipient List

The **Email Recipient List** displays the following information about e-mail recipients:

- **Name** - The name of the recipient.
- **Email Address** - The e-mail address of the recipient.
- **Notification Type** - The types of notifications sent to the recipient (**High**, **High and Medium**, or **All**).
- **Notification Status** - The status of e-mail notifications for the recipient (**Enabled** or **Disabled**).

Adding an E-mail Recipient


Add an e-mail recipient to send notifications about administration alerts or service tickets to the recipient by e-mail.

To add an e-mail recipient:

- 1 Click **Add**.

The **Add Email Recipient** page displays (see [Figure 112](#)).

Figure 112 Add Email Recipient Page



- 2 Enter information about the recipient:

- **Name** - The name of the recipient.
- **Email Address** - The e-mail address of the recipient.
- **Notification Type** - Select the types of notifications to send to the recipient:

- **High** - Send e-mail notifications for High service tickets.

High service tickets indicate that a critical problem has occurred and needs to be resolved immediately. The operation and performance of the DXi4000 are degraded, and there is a risk of system failure or data loss.

- **High and Medium** - Send e-mail notifications for High and Medium service tickets.

Medium service tickets indicate that a serious problem occurred and needs to be resolved, but it does not

necessarily need to be fixed immediately. The operation and performance of the DXi4000 may be degraded.

- **All** - Send e-mail notifications for High, Middle, and Low service tickets, as well as any administration alerts.

Low service tickets indicate that a minor problem occurred and needs to be resolved, but the operation and performance of the DXi4000 are not significantly affected.

- 3 Select the **Enable notification** check box to enable sending of notifications to the recipient.

Or clear the **Enable notification** check box to disable sending of notifications to the recipient.

- 4 Click **Apply**.

Editing an E-mail Recipient

Edit an e-mail recipient to change the recipient's e-mail address or the types of notifications sent to the recipient. You can also enable or disable sending of notifications to the recipient.

To edit an e-mail recipient:

- 1 Click **Edit**.

The **Edit Email Recipient** page displays (see [Figure 113](#)).

Figure 113 Edit Email
Recipient Page

The screenshot shows the Quantum DXi4601 web interface. The top navigation bar includes 'Quantum', 'DXi4601', and various status indicators like 'Normal', 'Admin', 'Ticket', and 'Low Capacity'. The left sidebar contains a menu with 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards'. The main content area is titled 'Edit Email Recipient' and contains a form with the following fields: 'Name' (DXi4601), '* Email Address' (ian.tran@quantum.com), and 'Notification Type' (High and Medium). There is a checked checkbox for 'Enable notification' and a note '* Required Field'. At the bottom of the form are 'Apply', 'Reset', and 'Cancel' buttons.

- 2 Enter information about the recipient:

Note: If you are editing an e-mail recipient, you cannot change the **Name**.

- **Name** - (Optional) Select a different e-mail recipient to edit.
- **Email Address** - The e-mail address of the recipient.
- **Notification Type** - Select the types of notifications to send to the recipient:
 - **High** - Send e-mail notifications for High service tickets.
High service tickets indicate that a critical problem has occurred and needs to be resolved immediately. The operation and performance of the DXi4000 are degraded, and there is a risk of system failure or data loss.
 - **High and Medium** - Send e-mail notifications for High and Medium service tickets.
Medium service tickets indicate that a serious problem occurred and needs to be resolved, but it does not necessarily need to be fixed immediately. The operation and performance of the DXi4000 may be degraded.
 - **All** - Send e-mail notifications for High, Middle, and Low service tickets, as well as any administration alerts.
Low service tickets indicate that a minor problem occurred and needs to be resolved, but the operation and performance of the DXi4000 are not significantly affected.

3 Select the **Enable notification** check box to enable sending of notifications to the recipient.

Or clear the **Enable notification** check box to disable sending of notifications to the recipient.

4 Click **Apply**.

Deleting an E-mail Recipient

Delete an e-mail recipient if you no longer want the DXi4000 to send e-mail notifications to the recipient.

To delete an e-mail recipient, select the recipient and click **Delete**.


Note: You can select multiple recipients to delete at once.

Server

The **Server** page allows you to specify the server for outgoing e-mail. The DXi4000 cannot send e-mail notifications until you specify the outgoing e-mail server.

To access the **Server** page, on the **Email** page, click the **Server** tab (see [Figure 114](#)).

Figure 114 Server Page



To specify the outgoing e-mail server:

- 1 In the **Hostname or IP Address** box, enter the hostname or IP address of the outgoing e-mail server.

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.

Note: To use hostname format, you must specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184).

- 2 In the **From Email Address** box, enter the return e-mail address displayed in e-mails sent by the DXi4000.

Specify a return address that lets you easily identify the system that generated the e-mail (for example, systemname@any-domain.com). The return address must contain an @ symbol and a valid domain name, including a period.


3 Click **Apply**.

Test

The **Email Test** page allows you to send a test e-mail to verify that e-mail notifications are correctly configured on the DXi4000.

To access the **Email Test** page, on the **Email** page, click the **Test** tab (see [Figure 115](#)).

Figure 115 Email Test Page



To send a test e-mail, select a recipient in the list and click **Send**. If the recipient does not receive the e-mail, make sure that the recipient's e-mail address is correct (see [Editing an E-mail Recipient](#) on page 206). Also make sure that the outgoing e-mail server is correct (see [Server](#) on page 208).

Email Home

The **Email Home** page allows you to configure the DXi4000 to send reports to e-mail recipients. The system can generate a report with system status data or with configuration data. Each report also includes

the system serial number, date and time, and a message that informs the recipient that the e-mail is automated and they should not respond to it.

Note: To enable the DXi4000 to send e-mail, you must specify an outgoing e-mail server (see [Server](#) on page 208).

To access the **Email Home** page, on the **Email** page, click the **Email Home** tab.

The **Email Home** page contains the following tabs:


- [Schedule](#)
- [On Demand](#)

Schedule

The **Schedule** page allows you to configure the DXi4000 to automatically send status data and configuration data reports to e-mail recipients. The reports are sent once a week to the specified recipients.

To access the **Schedule** page, on the **Email Home** page, click the **Schedule** tab (see [Figure 116](#)).

Figure 116 Schedule Page



To configure the DXi4000 to automatically send status data and configuration data reports:

- 1 Select the **Enable scheduled Email Home** check box to enable the Email Home schedule.

Or clear the **Enable scheduled Email Home** check box to disable the Email Home schedule.

Note: The default setting is enabled.

- 2 Use the drop-down boxes to specify the day and hour when reports are sent each week.
- 3 Enter the e-mail addresses of up to three recipients.

Note: You cannot edit the first recipient.


- 4 Click **Apply**.

On Demand

The **On Demand** page allows you to manually generate a status data or configuration data report. The report is immediately sent to the specified e-mail recipient. You can also view configuration data.

To access the **On Demand** page, on the **Email Home** page, click the **On Demand** tab (see [Figure 117](#)).

Figure 117 On Demand Page



Use the **On Demand** page to perform the following tasks:

- Manually send a status data or configuration data report (see [Sending a Report](#) on page 212).
- View a configuration data report (see [Viewing Configuration Data](#) on page 212).

Sending a Report

To manually send a status data or configuration data report:

- 1 Under **Email Type**, select the type of report to send (**Status data** or **Configuration data**).
- 2 In the **Send To** box, enter the e-mail address of the recipient.
- 3 Click **Send**.

Viewing Configuration Data

To view a configuration data report:

- 1 Under **Email Type**, select **Configuration data**.
- 2 Click **View**.

The **System Configuration Report** window displays.

- 3 (Optional) Click **Save** to save a local copy of the report in TXT format.

SNMP

The **SNMP** page allows you to configure the DXi4000 to send status messages using SNMP (Simple Network Management Protocol). The DXi4000 supports SNMP v1 and v2c.

SNMP works by sending messages, called protocol data units (PDUs), to different parts of a network, or communities. SNMP compliant devices, called agents, store data about themselves in Management Information Bases (MIBs) and return this data to the SNMP requesters.

You can configure the DXi4000 to act as an agent and send traps to a specified destination. You can also add SNMP community information.

To access the **SNMP** page, on the **Notifications** page, click the **SNMP** tab.

The **SNMP** page contains the following tabs:

- [Destinations](#)


- [Community](#)
- [Test](#)

Destinations

The **Destinations** page allows you to manage the destinations the DXi4000 sends SNMP traps to. You can add, edit, and delete SNMP destinations, and you can specify the types of traps to send.

To access the **Destinations** page, on the **SNMP** page, click the **Destinations** tab (see [Figure 118](#) on page 213).

Figure 118 Destinations Page



Use the **Destinations** page to perform the following tasks:

- View information about SNMP destinations (see [Trap Destination List](#) on page 213).
- Add an SNMP destination (see [Adding a Destination](#) on page 214).
- Edit an SNMP destination (see [Editing a Destination](#) on page 215).
- Delete an SNMP destination (see [Deleting a Destination](#) on page 216).

Trap Destination List

The **Trap Destination List** displays the following information about SNMP destinations:

- **IP Address** - The IP address of the destination.
- **Name** - The name of the destination.
- **Selected Traps** - The traps the DXi4000 sends to the destination (**Failure, Warning, Informational, Available, or Unavailable**).

Adding a Destination

Add an SNMP destination to send traps from the DXi4000 to the destination.


Note: You can add up to 5 destinations.

To add a destination:

- 1 Click **Add**.

The **Add Trap Destination** page displays (see [Figure 119](#)).

Figure 119 Add Trap Destination Page



The screenshot shows the Quantum DXi4000 web interface. The top navigation bar includes 'Quantum', 'DXi:4601', 'Normal', 'Mon Dec 19 2011 - 8:50:07 AM PST', 'Admin', 'Ticket', 'Low Capacity', 'Logout', 'Administrator', and 'Help'. The main menu includes 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards'. The 'Configuration' menu is expanded, showing 'Email', 'SNMP', 'Destinations', 'Community', and 'Test'. The 'Add Trap Destination' dialog box is open, displaying the following fields and options:

- * IP Address: [Text Input Field]
- * Name: [Text Input Field with value 'public']
- Selected Traps:
 - Failure
 - Warning
 - Informational
 - Available
 - Unavailable
- * Required Field
- Buttons: Apply, Reset, Cancel

- 2 Enter information about the destination:

- **IP Address** - Enter the IP address of the system that will receive the traps generated by the DXi4000.

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.

Note: To use hostname format, you must specify at least one DNS IP address on the **Network** page (see [Network](#) on page 184).

- **Name** - Enter the name of the destination.

3 Select one or more traps to send to the destination:

- **Failure** - Sends failure traps.
- **Warning** - Sends warning traps.
- **Informational** - Sends informational traps.
- **Available** - Sends a trap when the system transitions from an unavailable to an available state.
- **Unavailable** - Sends a trap when the system transitions from an available to an unavailable state.

4 Click **Apply**.

Editing a Destination


Edit an SNMP destination to change the name of the destination or the types of traps the DXi4000 sends to the destination.

To edit a destination:

1 Click **Edit**.

The **Edit Trap Destination** page displays (see [Figure 120](#)).

Figure 120 Edit Trap
Destination Page



2 Enter information about the destination:

Note: If you are editing a destination, you cannot change the **IP Address**.

- **IP Address** - (Optional) Select a different destination to edit.
- **Name** - Enter the name of the destination.

3 Select one or more traps to send to the destination:

- **Failure** - Sends failure traps.
- **Warning** - Sends warning traps.
- **Informational** - Sends informational traps.
- **Available** - Sends a trap when the system transitions from an unavailable to an available state.
- **Unavailable** - Sends a trap when the system transitions from an available to an unavailable state.

4 Click **Apply**.

Deleting a Destination

Delete an SNMP destination if you no longer want the DXi4000 to send traps to the destination.

To delete a destination, select the destination and click **Delete**.


Note: You can select multiple destinations to delete at once.

Community

The **Community** page allows you to manage SNMP community information for the DXi4000. You can add, edit, and delete communities, and you can specify the community access type.

To access the **Community** page, on the **SNMP** page, click the **Community** tab (see [Figure 121](#)).

Figure 121 Community Page



Use the **Community** page to perform the following tasks:

- View information about SNMP communities (see [SNMP Community List](#) on page 217).
- Add an SNMP community (see [Adding a Community](#) on page 218).
- Edit an SNMP community (see [Editing a Community](#) on page 220).
- Delete an SNMP community (see [Deleting a Community](#) on page 222).

SNMP Community List

The **SNMP Community List** displays the following information about SNMP communities:

- **Name** - The name of the community.
- **IP Address** - The IP address of the community.
- **Network Mask** - The network mask of the community.
- **Access Type** - The access type of the community (**Get** or **Get/Set**).
- **Community Status** - The status of the community (**Enabled** or **Disabled**).

Adding a Community

Add an SNMP community to include the DXi4000 in a group of devices that are monitored by a common management station.


Note: If no communities are defined, the SNMP agent is not accessible.

To add a community:

- 1 Click **Add**.

The **Add SNMP Community** page displays (see [Figure 122](#)).

Figure 122 Add SNMP Community Page



The screenshot shows the Quantum DXi4000 web interface. At the top, there is a navigation bar with 'Quantum. DX:4601' and a status bar showing 'Normal' and 'Mon Dec 19 2011 - 8:50:07 AM PST'. Below the navigation bar, there are tabs for 'Email', 'SNMP', 'Destinations', 'Community', and 'Test'. The 'Community' tab is active. A dialog box titled 'Add SNMP Community' is open, featuring a 'Help' button in the top right corner. The dialog box contains the following fields and controls: a text input for '* Name', a text input for '* IP Address' with a help icon, a text input for 'Network Mask', a dropdown menu for 'Access Type' currently set to 'Get', and a checked checkbox for 'Community status'. A note below the checkbox states '* Required Field'. At the bottom of the dialog box are three buttons: 'Apply', 'Reset', and 'Cancel'. The background of the web interface shows a sidebar with navigation options like 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards', and a main content area with a 'DXi Advanced Reporting' logo.

- 2 In the **Name** box, enter a unique **Name** for the community (up to 20 characters).

Valid characters are letters, numbers, hyphens, and underscores.

3 Enter a valid IP Address and Network Mask pair.

A pair is valid if performing a logical bitwise **AND** operation on the IP address and the network mask results in the IP address. See the table below for examples:

IP Address / Network Mask	Result
10.40.166.87 255.255.255.255	Allows access only from 10.40.166.87
10.40.166.87 10.40.166.87	Allows access only from 10.40.166.87
10.40.166.87 10.40.166.0	Invalid because the logical bitwise operation (address AND mask) is not equal to the address
10.40.166.87 255.255.0.0	Invalid because the logical bitwise operation (address AND mask) is not equal to the address
10.40.0.0 255.255.0.0	Allows access from any client with address 10.40.xx.xx

Note: If you define a single community and set both the IP address and network mask to 0.0.0.0 (or leave both blank), then IP address-based access control is disabled. In this case, the SNMP agent is accessible from any IP address.

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.

4 In the Access Type drop-down box, select the access type for the community:

- **Get** - Allows SNMP get operations.
- **Get/Set** - Allows both SNMP **get** and **put** operations.

- 5 Select the **Community status** check box to enable the community.
Or clear the **Community status** check box to disable the community.
- 6 Click **Apply**.

Editing a Community

Edit an SNMP community to change the IP address or access type for the community. You can also enable or disable the community.

To edit a community:

- 1 Click **Edit**.

The **Edit SNMP Community** page displays (see [Figure 122](#)).

Figure 123 Edit SNMP
Community Page

The screenshot shows the Quantum DXi4601 web interface. The top navigation bar includes 'Home', 'Replication', 'OST', 'Scheduler', 'System', 'Notifications', and 'Contacts'. The 'Edit SNMP Community' dialog box is open, displaying the following fields:

Name	Community1
* IP Address	10.40.0.0
Network Mask	255.255.0.0
Access Type	Get
<input checked="" type="checkbox"/> Community status	

* Required Field

Buttons: Apply, Reset, Cancel

- 2 (Optional) In the **Name** box, select a different community to edit.
- 3 Enter a valid **IP Address and Network Mask** pair.

A pair is valid if performing a logical bitwise **AND** operation on the IP address and the network mask results in the IP address. See the table below for examples:

IP Address / Network Mask	Result
10.40.166.87 255.255.255.255	Allows access only from 10.40.166.87
10.40.166.87 10.40.166.87	Allows access only from 10.40.166.87
10.40.166.87 10.40.166.0	Invalid because the logical bitwise operation (address AND mask) is not equal to the address
10.40.166.87 255.255.0.0	Invalid because the logical bitwise operation (address AND mask) is not equal to the address
10.40.0.0 255.255.0.0	Allows access from any client with address 10.40.xx.xx

Note: If you define a single community and set both the IP address and network mask to 0.0.0.0 (or leave both blank), then IP address-based access control is disabled. In this case, the SNMP agent is accessible from any IP address.

Note: When entering IP addresses, never use an address that is in a reserved IP address range. To see a list of reserved IP address ranges, click the quick tip icon [?] located near the IP address field.

- 4 In the **Access Type** drop-down box, select the access type for the community:
 - **Get** - Allows SNMP get operations.
 - **Get/Set** - Allows both SNMP **get** and **put** operations.
- 5 Select the **Community status** check box to enable the community.
Or clear the **Community status** check box to disable the community.

6 Click **Apply**.

Deleting a Community

Delete an SNMP community if you no longer want the DXi4000 to belong to a group of devices that are monitored by a common management station.

To delete a community, select the community and click **Delete**.


Note: You can select multiple communities to delete at once.

Test

The **SNMP Test** page allows you to send a test SNMP trap to verify that SNMP is correctly configured on the DXi4000.

To access the **SNMP Test** page, on the **SNMP** page, click the **Test** tab (see [Figure 124](#)).

Figure 124 SNMP Test Page



To send a test SNMP trap, select a destination in the list and click **Send**. If the destination does not receive the SNMP trap, make sure that the destination IP address is correct (see [Editing a Destination](#) on page 215). Also make sure that the community information is correct (see [Community](#) on page 217).

Contacts

The **Contacts** page allows you to enter company information. You can also enter individual contact information for primary and secondary contacts.

To access the **Contacts** page, click the **Configuration** menu, and then click the **Contacts** tab.

The **Contacts** page contains the following tabs:


- [Company](#)
- [Primary and Secondary](#)

Company

The **Company** page allows you to enter information about the company and location of the DXi4000.

To access the **Company** page, on the **Contacts** page, click the **Company** tab (see [Figure 125](#)).

Figure 125 Company Page



The screenshot shows the Quantum DXi4000 web interface. The top navigation bar includes 'Quantum', 'DXi:4601', 'Normal', 'Mon Dec 19 2011 - 8:50:07 AM PST', 'Admin', 'Ticket', 'Low Capacity', 'Logout', 'Administrator', and 'Help'. The main navigation menu on the left includes 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards'. The 'Configuration' menu is expanded to show 'Company', 'Primary', and 'Secondary'. The 'Company' tab is selected, displaying a 'Company information' form with the following fields: Company Name, Street, City, State, Postal Code, Country, DXi4801 Location, and Support Contract. An 'Apply' button is located at the bottom of the form.

To enter company information:

- 1 Enter the following information:

- **Company Name** - Enter the company name.
- **Street** - Enter the company street address.
- **City** - Enter the company city.
- **State** - Enter the company state.
- **Postal Code** - Enter the company postal code.
- **Country** - Enter the company country.
- **DXi4000 Location** - Enter the physical location of the DXi4000 (for example, data center).
- **Support Contract** - Enter the support contract number for the DXi4000.


2 Click **Apply**.

Primary and Secondary

The **Primary** and **Secondary** pages allow you to enter information about the primary and secondary contacts for the DXi4000.

To access the **Primary** or **Secondary** page, on the **Contacts** page, click the **Primary** or **Secondary** tab (see [Figure 126](#)).

Figure 126 Primary and Secondary Pages



The screenshot displays the Quantum DXi4000 web interface. The top navigation bar includes the Quantum logo, the device ID 'DXi:4601', a status indicator 'Normal', the date and time 'Mon Dec 19 2011 - 8:50:07 AM PST', and user options 'Admin', 'Ticket', 'Low Capacity', 'Logout', 'Administrator', and 'Help'. Below the navigation bar, there are tabs for 'Company', 'Primary', and 'Secondary'. The 'Primary' tab is selected, and the 'Primary Contact Information' form is displayed. The form contains the following fields: Name, Email Address, Phone, Fax, Pager, Street, City, State, Postal Code, and Country. An 'Apply' button is located at the bottom of the form. On the left side of the interface, there is a vertical menu with buttons for 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards'. At the bottom left, there is a logo for 'DXi Advanced Reporting'.

To enter primary or secondary contact information:

- 1 Enter the following information:

- **Name** - Enter the contact name.
- **Email Address** - (Required) Enter the contact e-mail address.
- **Phone** - Enter the contact phone number.
- **Fax** - Enter the contact fax number.
- **Pager** - Enter the contact pager number.
- **Street** - Enter the contact street address.
- **City** - Enter the contact city.
- **State** - Enter the contact state.
- **Postal Code** - Enter the contact postal code.
- **Country** - Enter the contact country.

2 Click **Apply**.



Chapter 10

DXi4000 Utilities

The **Utilities** pages to perform maintenance tasks on the DXi4000, such as generating and downloading diagnostic files, analyzing disk and network performance, and managing space reclamation. You can also install license keys, upgrade the system software, and reboot or shut down the DXi4000.

To access the **Utilities** pages, click the **Utilities** menu.

The **Utilities** pages contain the following tabs:

- [Diagnostics](#)
- [Analyzer](#)
- [Space Reclamation](#)
- [License Keys](#)
- [Software Upgrade](#)
- [Reboot & Shutdown](#)

Diagnostics

The **Diagnostics** page allows you to generate and download diagnostic files. You can also perform healthchecks to verify the health and integrity of the data deduplication blockpool.

The diagnostic files are helpful when troubleshooting problems on the DXi4000. Generate and download the diagnostic files before contacting Quantum customer support.

To access the **Diagnostics** page, click the **Utilities** menu, and then click the **Diagnostics** tab.

The **Diagnostics** page contains the following tabs:

- [System Diag File](#)
- [Storage Array Diag File](#)
- [DSET](#)
- [Healthchecks](#)

System Diag File

The **System Diag File** page allows you to generate and download a system diagnostics file. This file contains the diagnostic logs for all of the system components.

To access the **System Diag File** page, on the **Diagnostics** page, click the **System Diag File** tab (see [Figure 127](#)).

Figure 127 System Diag File Page



To generate and download a system diagnostics file:

- 1 Click **Generate New** to generate a new system diagnostics file.
The system generates a new diagnostics file. This can take several minutes.
- 2 After the file finishes generating, refresh the Web browser to enable the **Download Current** button.
- 3 To download the generated diagnostics file, click **Download Current**.
A dialog box displays asking if you want to open or save the file.
- 4 Click **Save** or **OK** to download the file.

Storage Array Diag File

The **Storage Array Diag File** page allows you to generate and download a storage array diagnostics file. This file contains the diagnostic logs for the storage arrays.

To access the **Storage Array Diag File** page, on the **Diagnostics** page, click the **Storage Array Diag File** tab (see [Figure 128](#)).

Figure 128 Storage Array Diag
File Page



To generate and download a system diagnostics file:

- 1 Click **Generate New** to generate a new storage array diagnostics file.
The system generates a new diagnostics file. This can take several minutes.
- 2 After the file finishes generating, refresh the Web browser to enable the **Download Current** button.
- 3 To download the generated diagnostics file, click **Download Current**.
A dialog box displays asking if you want to open or save the file.
- 4 Click **Save** or **OK** to download the file.

DSET

The **DSET** page allows you to generate a DSET report. DSET is a hardware diagnostic utility included with the DXi4000. A DSET report contains an array of status information about the DXi4000 hardware. A Quantum customer support representative can use this information to help identify and diagnose problems.

Note: Generate a DSET report only if directed to do so by a Quantum customer support representative.

To access the **DSET** page, on the **Diagnostics** page, click the **DSET** tab (see [Figure 129](#)).

Figure 129 DSET Page



To generate a DSET report:

1 Click Generate Report.

Click **OK** to continue. The system generates a new DSET report. This can take several minutes.

Note: You may see error or warning messages in the status text as the DSET report is generated. This is expected and does not indicate a problem with the report.

2 To download the newly generated DSET report, click Download Report.

A dialog box displays asking if you want to open or save the file.

3 Click Save or OK to download the file.

The DSET report is saved as a compressed zip file to the specified location.

4 Locate the DSET report you downloaded and send it to the e-mail or FTP address provided by Quantum Customer Support.

Healthchecks

The **Healthchecks** page allows you to perform tests that verify the health and integrity of the data deduplication blockpool. You can also configure the DXi4000 to automatically run the healthchecks at specified intervals.

To access the **Healthchecks** page, on the **Diagnostics** page, click the **Healthchecks** tab.

The **Healthchecks** page contains the following tabs:


- [General](#)
- [Status](#)
- [Schedule](#)

General

The **General** page allows you to start running the healthchecks or stop them if they are already running. When you start the healthchecks, only the healthchecks that are currently enabled are run (see [Status](#) on page 233).

To access the **General** page, on the **Healthchecks** page, click the **General** tab (see [Figure 130](#)).

Figure 130 General Page



The **General** page displays the following information about the most recently run healthchecks:

- **Status** - The status of the healthchecks (**In Progress**, **Success**, **Failed**, or **Interrupted**).
- **Progress** - The percentage complete of the healthchecks.
- **Start Time** - The time the healthchecks started.
- **End Time** - The time the healthchecks ended.

Use the **General** page to perform the following tasks:

- To start all enabled healthchecks, click **Start**.
- To stop all healthchecks in progress, click **Stop**.

Status


The **Status** page allows you to view information about the most recent test results for each healthcheck. You can also enable or disable a healthcheck.

The following healthchecks are available:

- **De-Duplication** - Checks the overall health of the blockpool. This healthcheck verifies that the metadata in the namespace file and the data tags in the blockpool are correctly in sync.
- **Integrity** - Checks the integrity of data in the blockpool. This healthcheck examines a sample of data tags in the blockpool and verifies that the data has been properly stored without errors or corruption.

To access the **Status** page, on the **Healthchecks** page, click the **Status** tab (see [Figure 131](#)).

Figure 131 Status Page



The **Status** page displays the following information about the most recently run test for each healthcheck:


- **Healthcheck Name** - The name of the healthcheck.
- **State** - The state of the healthcheck (**enabled** or **disabled**).
- **Started** - The time the healthcheck started.
- **Finished** - The time the healthcheck ended.
- **Status** - The status of the healthcheck (**Success** or **Failed**).

To enable or disable a healthcheck:

- 1 Select the healthcheck and click **Edit**.

The **Edit Healthcheck** page displays (see [Figure 132](#)).

Figure 132 Edit Healthcheck
Page



- 2 Select the check box to enable the healthcheck.
Or clear the check box to disable the healthcheck.
- 3 Click **Apply**.

Note: When healthchecks are run (manually or scheduled), only enabled healthchecks are run.


Caution: If a healthcheck fails when it is run, there may be a problem in the blockpool that could cause replication or restore operations to fail. Contact Quantum customer support if a healthcheck fails.

Schedule

The **Schedule** page allows you to configure the DXi4000 to automatically run healthchecks. You can schedule healthchecks to run daily, weekly, or not at all. When you schedule healthchecks, only the healthchecks that are currently enabled are run (see [Status](#) on page 233).

To access the **Schedule** page, on the **Healthchecks** page, click the **Schedule** tab (see [Figure 133](#)).

Figure 133 Schedule Page



To configure a healthchecks schedule:

- 1 Select a schedule option:

Note: By default, healthchecks are run daily at 5:00a.m.

- **Never** - The DXi4000 does not automatically run healthchecks.
- **Daily start at** - The DXi4000 runs healthchecks once each day. In the drop-down boxes, specify the time to run the healthchecks each day.
- **Weekly start at** - The DXi4000 runs healthchecks once each week. In the drop-down boxes, specify the day and time to run the healthchecks each week.

- 2 Click **Apply**.

Analyzer

The **Analyzer** page allows you to analyze the network and disk performance of the DXi4000.

To access the **Analyzer** page, click the **Utilities** menu, and then click the **Analyzer** tab.

The **Analyzer** page contains the following tabs:

- [Network](#)
- [Disk](#)

Network

The **Network Analyzer** page allows you to analyze network performance by measuring network throughput between the DXi4000 and another system (such as another DXi system).

To access the **Network Analyzer** page, on the **Analyzer** page, click the **Network** tab.

The **Network Analyzer** page contains the following tabs:


- [Performance](#)
- [Settings](#)

Performance

The **Performance** page allows you to perform network analysis with another system (the target). You can also view results from the most recently run test

To access the **Performance** page, on the **Network Analyzer** page, click the **Performance** tab (see [Figure 134](#)).

Figure 134 Performance Page



To perform network analysis:

- 1 In the **Target IP Address** box, enter the IP address of the system to perform network analysis with.

The target system must have NetServer enabled (see [Settings](#) on page 238).

- 2 Click **Start**.

The throughput result is displayed under **Result From Last Run** in MB/s.


Note: It takes approximately 5 seconds to refresh the results.

Settings

The **Settings** page allows you to enable or disable NetServer on the DXi4000. NetServer must be enabled on the target DXi system to perform network analysis with the system (see [Performance](#) on page 237).

To access the **Settings** page, on the **Network Analyzer** page, click the **Settings** tab (see [Figure 135](#)).

Figure 135 Settings Page



To enable or disable NetServer on the target DXi4000:

- 1 Select **Enable NetServer** to enable NetServer.

Or select **Disable NetServer** to disable NetServer.

2 Click **Apply**.


Note: You should disable NetServer on the target system when you are done analyzing network performance.

Disk

The **Disk Analyzer** page allows you to analyze disk performance by measuring disk read and write throughput.

To access the **Disk Analyzer** page, on the **Analyzer** page, click the **Disk** tab (see [Figure 136](#)).

Figure 136 Disk Analyzer Page



To perform disk analysis, click **Start**. The throughput result is displayed under **Result From Last Run** in KB/s.

Note: It takes approximately 5 seconds to refresh the results.

Space Reclamation

The **Space Reclamation** page allows you to manage space reclamation activity on the DXi4000. You can start space reclamation and monitor its progress. You can also schedule space reclamation to occur on a regular basis.

During space reclamation, the DXi4000 searches the blockpool for tags that are no longer referenced and then deletes the unneeded tags to free up space.

Note: When disk capacity is low, target replication to the system is paused (see [Replication Service](#) on page 110). In addition, space reclamation is automatically started to free up disk space.

To access the **Space Reclamation** page, click the **Utilities** menu, and then click the **Space Reclamation** tab.

The **Space Reclamation** page contains the following tabs:

- [General](#)
- [Schedule](#)


General

The **General** page allows you to start or stop space reclamation. You can also monitor the progress of space reclamation activity.

Caution: Space reclamation may affect system performance. Avoid running space reclamation during known backup periods.

To access the **General** page, on the **Space Reclamation** page, click the **General** tab (see [Figure 137](#)).

Figure 137 General Page



The **General** page displays the following information about the current or most recent space reclamation activity:

- **Status** - The status of space reclamation (see [Space Reclamation Status](#) on page 241).
- **Total Progress** - The percentage complete of all space reclamation activity.
- **Start Time** - The time space reclamation started.
- **End Time** - The time space reclamation ended.
- **Space Reclaimed** - The amount of disk space reclaimed.

Use the **General** page to perform the following tasks:

- To start space reclamation, click **Start**.
- To stop space reclamation, click **Stop**.

Space Reclamation Status

Space reclamation can have one of the following statuses:

- **Reclamation Completed** - Space reclamation completed without errors.
- **Reclamation Started by User** - Space reclamation was started manually by a user.

- **Reclamation Interrupted** - Space reclamation was interrupted and must be restarted.
- **Reclamation Interrupted by User** - Space reclamation was interrupted by a user and must be restarted.
- **Reclamation Interrupted - Error Encountered** - Space reclamation was interrupted because an error was encountered and must be restarted.
- **Reclamation Interrupt by User - Cannot be interrupted at this time** - Because the system is in a Low Space state, space reclamation cannot be stopped. Wait for space reclamation to finish freeing up disk space.
- **Reclamation Completed - No Candidates To Delete** - Space reclamation completed, but there were no candidates for reclamation.
- **Reclaim Existing Blockpool Freed Space** - The existing blockpool space has been reclaimed for use.
- **Stage 1 of 4** - Reclaim Disk Space (Initial).
- **Stage 2 of 4** - Calculating Deletion Candidates.
- **Stage 3 of 4** - Deleting New Candidates.
- **Stage 4 of 4** - Reclaim Disk Space.


Schedule

The **Schedule** page allows you to configure the DXi4000 to automatically perform space reclamation on a regular basis.

Caution: Space reclamation may affect system performance. Avoid running space reclamation during known backup periods.

To access the **Schedule** page, on the **Space Reclamation** page, click the **Schedule** tab (see [Figure 138](#)).

Figure 138 Schedule Page



To schedule space reclamation:

- 1 Select a schedule option:

Note: By default, space reclamation is run daily at 1:00p.m.

- **Tuesday, Thursday** - Space reclamation occurs on Tuesdays and Thursdays.
 - **Monday, Wednesday, Friday** - Space reclamation occurs on Mondays, Wednesdays, and Fridays.
 - **Weekly on** - Space reclamation occurs on the day specified in the drop-down box.
 - **Daily** - Space reclamation occurs every day.
 - **No Schedule** - Scheduled space reclamation does not occur.
- 2 Use the drop-down boxes to specify the time when space reclamation starts on the specified days.
 - 3 Click **Apply**.


License Keys

The **License Keys** page allows you to add a license key to the DXi4000 to enable new functionality. You can also view a list of available licenses and see the licenses are installed on the system.

For DXi4601 systems, you can add license keys to increase the available storage capacity of the system up to a total of 12 TB (11.61 TB usable for data storage). For more information, see [Adding a License Key](#) on page 245.

To access the **License Keys** page, click the **Utilities** menu, and then click the **License Keys** tab (see [Figure 139](#)).

Figure 139 License Keys Page



The screenshot shows the Quantum DXi4601 web interface. The top navigation bar includes 'Quantum', 'DXi:4601', 'Normal', 'Thu Dec 8 2011 - 10:32:23 AM PST', 'Admin', 'Ticket', 'Show Capacity', 'Logout', 'Administrator', and 'Help'. The main menu on the left includes 'Home', 'Replication', 'Status', 'Alerts', 'Configuration', 'Utilities', and 'Wizards'. The 'Utilities' menu is expanded, showing 'License Keys' as the selected option. The 'License Keys' page displays a 'License Key List' table with the following data:

Name	Installed	Date Installed	Description
NAS	Yes	2011-12-12 13:18:08	Enables NAS (NFS, CIFS) connectivity
Data Deduplication	Yes	2011-12-12 13:18:08	Enables data deduplication and compression
Replication	Yes	2011-12-12 13:18:09	Enables replication to other DXi
Storage Capacity	Yes	2011-12-16 21:41:49	Enables storage capacity
OST	Yes	2011-12-12 13:18:09	Enables Open Storage backup with Symantec OST

Below the table, there is a 'Serial Number' field with a redacted value, a '* New Key' input field, and an 'Add' button. A note below the input field states '* Required Field'. At the bottom of the page, a message reads 'No License Name selected for display.'

Use the **License Keys** page to perform the following tasks:

- View information about available and installed licenses (see [License Key List](#) on page 244).
- Add a license key (see [Adding a License Key](#) on page 245).

License Key List

The **License Key List** displays the following information about licenses that are available for the DXi4000:

- **Name** - The name of the license.

To display details for a license, click the license name. For a description of the licenses that are available on the DXi4000, see [Available Licenses](#) on page 245.

- **Installed** - The state of the license (**Yes** if the license is installed, **No** if the license is not installed).
- **Date Installed** - If installed, the date the license was installed.
- **Description** - A brief description of the license.

Available Licenses

The following licenses are available from Quantum.

- **NAS** - Enables NAS (NFS, CIFS) connectivity. (License key is pre-installed on all DXi4000 models.)
- **Data Deduplication** - Enables data deduplication and compression. (License key is pre-installed on all DXi4000 models.)
- **Replication** - Enables replication to other DXi systems. (License key is pre-installed on all DXi4000 models.)
- **Storage Capacity** - (DXi4601 only) Enables the purchased storage capacity for the system. (License key is pre-installed on all DXi4601 models.)

A storage capacity license key is pre-installed for all initially purchased capacity. You can increase the available storage capacity of the system up to a total of 12 TB (11.61 TB usable for data storage) by adding additional license keys.

Note: If you purchase a storage capacity upgrade, you will receive a License Certificate you can use to enable the additional capacity (see [Adding a License Key](#) on page 245).

- **OST** - Enables OpenStorage backup with Symantec OST. (License key is pre-installed on all DXi4000 models.)

Adding a License Key

Add a license key to enable additional storage capacity on a DXi4601 system. To install a license key, you must first obtain a License Certificate containing an authorization code.


Contact your Quantum sales representative to purchase a storage capacity upgrade license. After you purchase the license, you will receive a License Certificate containing an authorization code.

To upgrade the storage capacity of a DXi4601, locate the License Certificate, and then perform the following steps:

- 1 Open a Web browser on a computer with Internet access.
- 2 Enter <http://www.quantum.com/licensekeys> in the browser address box.

The License Key Management page displays (see [Figure 140](#)).

Figure 140 License Key Management Page



- 3 Enter the DXi system serial number in the **Serial Number** box and click **Submit**.

The **Licensed Feature** page displays.

Note: The serial number displays on the **Home** page in the remote management console (see [DXi4000 System Overview](#) on page 72).

- 4 Enter the authorization code (printed on the License Certificate) and click **Get License Key**.

The **Licensed Feature** page returns a license key. Print out or write down the license key, or save it to a text file.

- 5 Access the DXi remote management console (see [Accessing Remote Management](#) on page 28).

- 6 Click the **Utilities** menu, and then click the **License Keys** tab.

The **License Keys** page displays (see [Figure 139](#)).

- 7 Enter the license key in the **New Key** box.

- 8 Click **Add**.

The license key is added to the system.


- 9 Reboot the DXi to complete the storage capacity upgrade (see [Reboot & Shutdown](#) on page 249).

Caution: Stop all backup, restore, and replication jobs before rebooting. The new storage capacity will not be available until you reboot the DXi.

- 10 After the DXi finishes rebooting, verify the licensed capacity.

Click the **Storage Capacity** license link on the **License Keys** page. The maximum allowed storage capacity appears under **License Details** (see [Figure 141](#)). Verify that the licensed capacity equals the total purchased capacity, including the new capacity upgrade.

Figure 141 License Details



Software Upgrade

The **Software Upgrade** page allows you to upload a new software image to update the system software on the DXi4000. To see if a software upgrade is available for your DXi, contact Quantum Customer Support (see [Getting More Information or Help](#) on page xxiv).


For information about performing a software upgrade, refer to the *DXi-Series Software Upgrade Guide (6-67321)*.

Reboot & Shutdown

The **Reboot & Shutdown** page allows you to reboot or shut down the DXi4000.

To access the **Reboot & Shutdown** page, click the **Utilities** menu, and then click the **Reboot & Shutdown** tab (see [Figure 142](#)).

Figure 142 Reboot & Shutdown Page



To reboot or shutdown the DXi4000:

- 1 Under **System Action**, select an option:
 - **Reboot** - Reboots the DXi4000.
Rebooting the system closes the Web browser connection. You must log on again after the system has rebooted.
 - **Shutdown** - Shuts down the DXi4000.
 - **Reset from diagnostic state** - (Only available when the node is in degraded mode) Restarts the services on the node without rebooting the system.
- 2 Click **Apply**.

Note: Shutting down the system can take up to 15 minutes. Only the node will completely shut down. When rebooting, the system can take approximately 30 minutes to start up, depending on the amount of installed storage capacity.



Appendix A

DXi4000 System Specifications

This appendix lists characteristics and specifications of the DXi4000. These characteristics and specifications are categorized as follows:

- [Physical Characteristics](#)
- [Environmental Specifications](#)

Note: For hard drive specifications see the appropriate hard drive product manual.

Physical Characteristics

The following tables provide dimensions and other physical characteristics of the DXi4000 system components:

- [Table 5 - Physical Characteristics](#)
- [Table 6 - Storage Capacity](#)
- [Table 7 - Cable Drops](#)
- [Table 8 - Interfaces](#)
- [Table 9 - Power Requirements](#)

Table 5 Physical Characteristics

	System
Height	3.40 in (8.6 cm)
Width (side to side)	17.19 in (43.6 cm)
Depth (front to back)	24.09 in (61 cm)
Weight (stand alone)	49.5 lbs (22.5 Kg)
Rack Space Required	2U
Air clearance	Open 4 in (10.2 cm) behind unit for proper air flow

Table 6 Storage Capacity

DXi4000 Storage Capacity	
Usable capacity	<ul style="list-style-type: none"> • DXi4510 - 2.2 TB usable for data storage • DXi4520 - 4.4 TB usable for data storage • DXi4601 - Expandable storage capacity up to 12 TB: <ul style="list-style-type: none"> • Base System Capacity - 4 TB total (3.87 TB usable for data storage) • With First Capacity Upgrade License - 8 TB total (7.74 TB usable for data storage) • With Second Capacity Upgrade License - 12 TB total (11.61 TB usable for data storage) <p>Note: For DXi4601, storage capacity upgrades are enabled simply by adding a license key and rebooting the system (see Adding a License Key on page 245). To purchase a storage capacity upgrade license, contact your Quantum sales representative.</p>

Table 7 Cable Drops

DXi4000 Cable Drops	
Ethernet Cable Drops	Model 4510/4520/4601 (4 x 1GbE ports) - 1 to 4 1GbE Ethernet connections for NAS or OST connectivity, replication, and remote management
Power Outlets	System - 2 USA type 3-prong power outlets (Nema 5-15) or 2 C13 type 3-prong power outlets (IEC320 C13).

Table 8 Interfaces

DXi4000 Interfaces	
Interfaces	NAS backup target: 128 shares maximum (NFS or CIFS) OST backup target: 100 storage servers maximum Note: NFS version: NFSv2 and NFSv3 Note: Samba version: 3.6.0
Hardware	Model 4510/4520/4601 4 ports 100/1000BASE-T Ethernet (RJ45 connector)

Table 9 Power Requirements

DXi4000 Power Requirements	
Power Supplies and Cords	Two (2) hot swappable redundant power supplies Two (2) USA type 3-prong power cords with IEC320 C13 to Nema 5-15 connectors Two (2) C13 to C14 type 3-prong power cords with IEC320 C13 to IEC320 C14 connectors
Voltage	100–240 VAC
Frequency	50–60Hz

DXi4510	Inrush	2.2A @ 100V 0.92A @ 240V 220W
	Typical	2.0A @100V 0.83A @240V 200W 683 BTU/Hr
	Maximum	7.5A @100V 4.0A @ 240V 750W
DXi4520 and DXi4601	Inrush	3.0A @ 100V 1.3A @ 240V 300W
	Typical	2.0A @100V 0.83A @240V 200W 683 BTU/Hr
	Maximum	7.5A @100V 4.0A @ 240V 750W

Caution: To safeguard backups in the event of a power outage, Quantum recommends that you connect the DXi4000 to a UPS (uninterruptable power supply).

Environmental Specifications


[Table 10](#) provides various DXi4000 environmental specifications.

Table 10 Environmental Specifications

Climatic Environment		
Temperature and Altitude	Operating	10 to 35 °C (50 to 95 °F) 35 °C Max, Altitude = 900 m or 2952.75 ft (28 °C Max, Altitude = 3048 m or 10,000 ft)
	Shipping and storage	-40 to 65 °C (-40 to 149 °F) up 12,000m (39,370 ft)
Relative humidity	Operating	20% to 80% (non-condensing)
	Shipping and storage	5% to 95% (non-condensing)
Vibration and Shock		
Operational Shock	Peak Acceleration	31G
	Duration	2.6 milliseconds
	Wave Shape	½ Sine
Operational Vibration	Mode	Random Vibration
	Frequency Range	5Hz–350Hz
	Amplitude	0.26Grms
	Application	Operational Orientations
Shipping and Storage	Mode	Random Vibration
	Frequency Range	10Hz–250Hz
	Amplitude	1.54 Grms
	Rate/Duration	(PSD can be provided) 15 minutes all operational orientations
Acoustic		
Acoustic output	Operating	< 67 dBA at 1 meter, room temperature (20C)
Agency Approvals		
Safety	IEC 60950-1, CSA 60950-1-03/UL 60950-1	

Emissions	EN55022 Class A, FCC Part 15 Class A, ICES-003 Class A, VCCI Class A, CISPR 22 Class A, CNS13438 Class A, KN22 Class A
Immunity	<p>EN55024/KN24:</p> <p>EN 61000-3-2 - Harmonic current emissions test</p> <p>EN 61000-3-3 - Voltage fluctuations and flicker in low-voltage supply systems test</p> <p>EN 55024:1998 - Information technology equipment - Immunity characteristics - Limits and methods of measurements</p> <p>EN 61000-4-2 - Electrostatic discharge immunity test</p> <p>EN 61000-4-3 - Radiated, radio-frequency, electromagnetic field immunity test</p> <p>EN 61000-4-4 - Electrical fast transient/burst immunity test</p> <p>EN 61000-4-5 - Surge immunity test</p> <p>EN 61000-4-6 - Immunity to conducted disturbances, induced by radio-frequency fields</p> <p>EN 61000-4-8 - Power frequency magnetic field immunity test</p> <p>EN 61000-4-11 - Voltage dips, short interruptions and voltage variations immunity test</p>

Caution: The DXi4000 system is designed to be installed in a rack enclosure. Ensure that the operating temperature inside the rack enclosure does not exceed the maximum rated ambient temperature. Do not restrict air flow to the DXi4000 components.



Appendix B

Troubleshooting

This appendix describes the status and problem reporting features of the DXi4000 as well as problems you might encounter during setup and operation of the system. Corrective information is provided to help you resolve these problems.

For information about troubleshooting the DXi4000, see the following sections:

- [DXi4000 Status and Problem Reporting](#)
- [General Troubleshooting Actions](#)
- [Common Problems and Solutions](#)

DXi4000 Status and Problem Reporting

To maintain system health and help you identify and correct problems that occur, the DXi4000 constantly performs the following actions:

- Monitors the system software and hardware components.
- Detects system problems.
- Attempts to isolate each problem to a specific field replaceable component.

- Attempts to recover from the problem.
- Logs the problem.
- If the problem requires service, the system reports the problem in a service ticket associated with the field replaceable component.

General Troubleshooting Actions

For information about general troubleshoot actions you can take, see the following sections:

- [Viewing Service Tickets](#)
- [Checking Hardware Status](#)
- [Downloading a System Diagnostics File](#)

Viewing Service Tickets

Service tickets include time and date information, status (open or closed), information about each error, and links to recommended troubleshooting procedures. The DXi4000 generates service tickets according to the following scenarios:

- If the component associated with the problem does not have an open service ticket, the DXi4000 opens a service ticket for the component and reports the problem in a service ticket.
- If the problem reoccurs, the DXi4000 logs the number of times that it detects the problem in the existing report.
- If a different problem occurs with the same component, the DXi4000 adds a new report to the same service ticket.
- If a problem occurs with a different component, the DXi4000 uses the above scenario to open a new service ticket for the component or report the problem in an existing service ticket associated with the component.

To access the **Service Tickets** page, click the **Alerts** menu, and then click the **Service Tickets** tab.

For more information about working with service tickets, see [Service Tickets](#) on page 131.

Checking Hardware Status

The **Hardware** page allows you to view information about the hardware components of the DXi4000. You can view the overall status of the node as well as detailed status information for components such as the system board, Fibre Channel adapters, network ports and storage arrays.

To access the **Hardware** page, click the **Status** menu, and then click the **Hardware** tab.

For information about using the **Status** page, see [Hardware](#) on page 113.

Downloading a System Diagnostics File

The **System Diag File** page allows you to generate and download a system diagnostics file. This file contains the diagnostic logs for all of the system components.

To access the **System Diag File** page, on the **Diagnostics** page, click the **System Diag File** tab.

For information about downloading the system diagnostics file, see [System Diag File](#) on page 228.

Common Problems and Solutions

The troubleshooting information in this section covers the following topics:

- [Start-up Problems](#)
- [Hardware Problems](#)
- [Ethernet Network Problems](#)
- [Replication Problems](#)
- [Temperature Problems](#)

Start-up Problems

[Table 11](#) describes problems that can occur during system start-up.

Table 11 Start-up Problems

Problem	Corrective Action
FATAL ERROR Unable to start SNFS! Message displays.	Contact your Quantum Customer Support representative (see Getting More Information or Help on page xxiv).
FATAL ERROR Unable to start blockpool! Message displays.	Contact your Quantum Customer Support representative (see Getting More Information or Help on page xxiv).

Hardware Problems

[Table 12](#) describes corrective actions for problems occurring with the system hardware.

Table 12 Hardware Problems

Problem	Corrective Action
The system does not power on.	Make sure the power cords are connected to a grounded electrical outlet and the power switches located on the back of the power supplies are on. If the problem persists, contact your Quantum Customer Support representative to arrange for service (see Getting More Information or Help on page xxiv).
One power supply is not functioning.	Determine which power supply has failed by observing the red fault LED on the power supply. Contact your Quantum Customer Support representative to arrange for service (see Getting More Information or Help on page xxiv).
Both power supplies are not functioning.	Determine which power supply has failed by observing the red fault LED on the power supply. Contact your Quantum Customer Support representative to arrange for service (see Getting More Information or Help on page xxiv).

Problem	Corrective Action
One fan is not operating.	Determine which fan has failed by reading the service ticket generated by the system. Contact your Quantum Customer Support representative to arrange for service (see Getting More Information or Help on page xxiv).
Multiple fans are not operating.	Caution: Turn the system off immediately! The system will overheat with multiple fans not operating. Contact your Quantum Customer Support representative to arrange for service (see Getting More Information or Help on page xxiv).
A hard drive is not responding	Determine which drive has failed by observing the red fault LED on the drive carrier. Contact your Quantum Customer Support representative for a drive carrier replacement (see Getting More Information or Help on page xxiv).
A SAS cable is removed during normal operation.	The system will shut down as soon as it recognizes the problem. There is a potential for data loss. Power off the system, re-insert the SAS cable and restart the system. Depending on the state of the system when the SAS cable was removed, a long-running, mandatory data verification may occur.

Ethernet Network Problems

[Table 13](#) describes corrective actions for problems occurring with the Ethernet network.

Table 13 Ethernet Network Problems

Problem	Corrective Action
<p>The Ethernet link light on the DXi4000 is not lit when a cable is connected to a hub or switch.</p>	<p>Check to make sure the Ethernet cable is not a cross-over cable. Use only "straight" CAT-6 Ethernet cables.</p> <p>Port on the hub or switch is not active or damaged.</p> <p>Port on the DXi4000 is damaged. Contact the Quantum Customer Support department (see Getting More Information or Help on page xxiv).</p>
<p>The Ethernet link light on the switch or hub is not lit when a cable is connected to DXi4000 system.</p>	<p>Check to make sure the Ethernet cable is not a cross-over cable. Use only "straight" CAT-6 Ethernet cables.</p> <p>Port on the hub or switch is not active or damaged.</p> <p>Port on the DXi4000 is damaged. Contact the Quantum Customer Support department (see Getting More Information or Help on page xxiv).</p>
<p>DXi4000 system is not visible on the Ethernet network.</p>	<p>Try to ping the DXi4000 system IP address from a host on the same network. If the ping reports round trip times, the DXi4000 system is active. If not, check the cables, switches, or hubs for damaged components. If everything checks out, contact the Quantum Customer Support department (see Getting More Information or Help on page xxiv).</p>

Problem	Corrective Action
DXi4000 remote management pages are not visible.	<p>IF you cannot connect to the DXi4000 remote management pages, verify that the following network settings for the DXi4000 are correct:</p> <ul style="list-style-type: none"> • Hostname • IP addresses • Default gateway • Subnet mask • Domain name (optional)
An Ethernet cable is removed during normal operation.	<p>The system will discontinue use of the associated Ethernet port. A Service ticket will be issued. The possibility of errors exist; data corruption will not occur.</p> <p>Reconnect the cable as soon as possible. It is not necessary to power the system off. Depending on the state of the system when the Ethernet cable was removed, replication, system management, or ingest may need to be restarted.</p>

Replication Problems

[Table 14](#) describes corrective actions for problems occurring with the replication.

Table 14 Replication Problems

Problem	Explanation/Corrective Action
The replication was paused, but the replication is still in process.	<p>When you click Pause, the system will continue to replicate the current tag or block of information in process. The process of completing the current tag replication can take up to 15 minutes to complete. Once that tag has completed replication the system will pause and wait to resume.</p>

Problem	Explanation/Corrective Action
The replication was paused and a Failure event was generated in the Replication Events page.	This is normal. When a replication is paused, a failure event is generated on the Replication Events page. The system will continue the replication when you click Resume .
Replication was disabled while a replication was in process and the replication completed.	If you click Disable during a replication in process, the system will complete the entire replication and then disable replication on the system. The system will be unable to replicate until you click Enable .
Enabled replication on a NAS share and received the following Event: No destination host is specified for replication.	You must configure the target system prior to configuring the source. If the target system is not configured first, you will not be able to designate the replication target.
Able to enable and schedule replication for NAS even though no target IP configured.	It is possible to enable and schedule a replication when a target system has not been configured. The replication will not start until a target system is configured.

Temperature Problems

Temperature problems are generally caused by incorrect room temperature, poor air circulation inside the DXi4000 rack or components, or a malfunctioning cooling fan.

Use the following procedure if a temperature problem is reported:

- 1 Check the ambient temperature of the room containing the DXi4000 system to verify that the temperature falls within the specified range.
- 2 Inspect for adequate air circulation inside the rack. Some racks may provide additional fans to improve air circulations. Check the fan for proper operation. Clean or replace any air filter as necessary.

- 3 If a component reports a temperature problem, verify that the associated fan is operating correctly. If necessary, contact Quantum customer support to replace the fan (see [Getting More Information or Help](#) on page xxiv).



Glossary

B

Blockpool A pool of all unique data blocks that were captured during the data deduplication cycle. When backup jobs occur, the data deduplication engine searches for new data entering the DXi4000 and uses a variable length compression type algorithm to compare this to existing data in the blockpool. Unique blocks are added to the blockpool and all known blocks are indexed.

Byte The basic unit of computer memory which is large enough to hold one character.

C

Compress A process of removing fine-grained redundancy from data prior to storing or transmitting it. The granularity may vary, but generally compression deals with redundancy in grains of a few bytes.

D

Data Deduplication A process of removing coarse-grained redundancy from data prior to storing or transmitting it. The granularity may vary, but generally data deduplication deals with redundancy in grains of several kilobytes. When you select **Enable Data Deduplication** for a NAS share, data deduplication is running all of the time. Backup data is sent to the DXi4000 and data deduplication is performed on data as it

is ingested.

Disk A fixed set of sectors with sequential numbers starting from zero, directly and independently accessible and mutable by those numbers without affecting any other sector.

F

Filesystem An abstraction layered over storage devices (typically disks) obscuring the physical details of the storage devices it supports in favor of a presentation oriented at storing and organizing files.

H

Host The device or devices to which the system is connected.

I

Ingest The throughput performance of data writes to the system.

L

LSU Logical Storage Unit. A logical storage entity defined under the Symantec OpenStorage API.

N

NAS Network Attached Storage is file-level computer data storage connected to a computer network providing data access to network clients.

NDMP Network Data Management Protocol is a protocol meant to transport data between NAS devices, also known as filers, and backup devices. This removes the need for transporting the data through the backup server itself, thus enhancing speed and removing load from the backup server.

O

OST OpenStorage API. An interface specific to Symantec NetBackup and Backup Exec for writing data to disk backup appliances, replicating it, and, in the case of NetBackup, writing data directly to disk, under control of the backup application.

R

RAID Redundant Array of Independent Disks is a technology through which several physical storage disks are grouped into an array that appears to an operating system as one or more physical devices.

S

SNFS StorNext® File System

SNMP Short for *Simple Network Management Protocol*, a set of protocols for managing complex networks.

Sync ID When you configure a share for Directory/File Based Replication, you specify a Sync ID for the share. The Sync ID associates the share on the source system with the share on the target system that will receive the replicated data. The Sync ID of the source share and the target share *must* be identical.

T

Terabyte A unit of measure for digital data equal to 1,000 gigabytes.

