



StorNext M440 Metadata Appliance

4.3.1 Release Notes

Purpose of this Release

The StorNext M440 combines industry-proven Quantum hardware and StorNext software into one convenient, out-of-the-box solution. Your M440 system has been pre-installed and is ready to operate with a minimum of additional configuration.

This document contains additional information related to your M440 system.

For the complete list of documentation for the M440 Metadata Appliance, click the **Documentation** tab on the following web page:

<http://www.quantum.com/ServiceandSupport/SoftwareandDocumentationDownloads/M330/Index.aspx>

StorNext 4.3.1 is an important new release of StorNext software and includes important bug fixes. Additionally, it adds support for:

- The StorNext M440 Metadata Appliance

The complete list of documentation for StorNext 4.3.1 can be found here (click the “Select a StorNext Version” menu to view the documents for that version of StorNext):

<http://www.quantum.com/ServiceandSupport/SoftwareandDocumentationDownloads/SNMS/Index.aspx?whattab=Fourth>

About This Release

This section contains important things you should know about your M440 Metadata Appliance.



M440 Metadata Appliance

The StorNext M440 metadata controller (MDC) nodes are designed to run the MDC file system and, optionally, with the StorNext Storage Manager and the Distributed Data Mover features installed. The Gateway server feature is not supported for installation directly on the M440, but is fully supported when running on a separate client.

M440 Hardware Expansion

Although your M440 comes with unfilled expansion slots and drive bays, other hardware upgrades are not supported.

Data Replication and Deduplication

The M440 supports the use of an optional StorNext replication license. Replication throughput is limited to a single GbE port.

The M440 is not designed for deduplication, and the standard StorNext deduplication license is not supported with the M440.

Configuring Clients for the M440

In order to prevent a split-brain condition between the HA pair of MDCs on the M440, at least one additional StorNext client must mount the HA file system. This will allow the additional client to "vote" in the event of a split-brain condition.

Because the shared file system on the M440 is on the internal RAID and not visible, you must mount the client using the "diskless=yes" option.

On Linux systems, put into the `/etc/fstab` an entry similar to this:

```
shared-02637 /stornext/shared cvfs diskless=yes 0 0
```

(The name "shared-02637" used in the example will vary. The format is "shared-NNNNN")

On Windows clients, use the Mount Options field to add "diskless=yes".

For more information about this procedure, refer to the HA chapter in the *StorNext User's Guide*.

Note: You need to do this on only one client machine.

Linux Device Mapper Multipath Support

M440 clients support the Linux Device Mapper (DM) Multipath driver. This driver provides redundancy and improved I/O performance by taking advantage of multiple paths to storage. If you plan to use the Linux DM Multipath support with StorNext, be aware of the following:

- The M440 comes with a pre-configured `/etc/multipath.conf` file which handles the internal LSI array LUNs. The settings and sections concerning LSI arrays should not be modified or else the HA shared filesystem may not be accessible and failover will not work properly.
- Ensure that the `/etc/multipath.conf` file is identical on both the primary and secondary nodes of the MDC HA pair. (See CR [40015](#) in [Table 1](#) on page 6.)

- Not all RAID configurations work with the DM Multipath Driver. Check with your storage vendor for compatibility.
- For detailed instructions on installing and configuring the DM Multipath Driver, refer to the SuSE documentation provided with your version of Linux.
- For StorNext to use Linux Device Mapper Multipath devices, you must make three changes to the `/etc/multipath.conf` file.
 - 1 Set `user_friendly_names` to `yes`.
 - 2 Quantum recommends that the `cvfsctl` devices not be included as multipath devices. This can be achieved by including the following in the blacklist entry:

```
devnode "cvfsctl*"
```
 - 3 Current versions of the DM Multipath driver assign a default value of 1000 for `rr_min_io`, which is too high for most configurations having multiple active paths. Using a smaller value such as 32 will typically result in significantly improved performance. Experimentation may be required to determine the optimal value.

In addition, using the `alias` attribute in a multipath subsection of the `/etc/multipath.conf` file is not currently supported for devices used by StorNext. Its use can lead to mount failures.

- When migrating from other multipath drivers to DM Multipath, tuning may be required to achieve previous levels of performance. The specifics of this will depend on system configuration details.
- Using the `cvpaths` file and `udev` rules configuration files is typically unnecessary with Linux Device-Mapper with StorNext.
- On SuSE Linux Systems: In order to use Linux Device Mapper Multipath with StorNext, `/etc/multipath.conf` must be used because SuSE Linux does not install a `multipath.conf`, and Novell recommends against using it.

Although SuSE Linux does not install a `multipath.conf` file by default, an example file located at:

```
/usr/share/doc/packages/multipath/tools/  
multipath.conf.synthetic
```

can be copied to:

```
/etc/multipath.conf
```

- On RedHat Linux Systems: Red Hat does install a `multipath.conf` file. By default, Red Hat `multipath.conf` file blacklists all multipath-capable targets. This means `blacklist { devnode "*" }` must be commented out.

Target Reset and Fiber Channel Tape Support on Qlogic HBAs

The Enable SCSI Bus Target Reset parameter is enabled by default on all Fiber channel HBAs. The parameter exists for disk arrays, but poses a problem for tape drives.

PROBLEM

When the SCSI bus target (the tape drive) is reset when a backup job is running, the backup job may abort. If the tape drive does not receive the rewind and unload commands from the backup job, it leaves the tape in the drive. This may cause the drive to be seen as not ready, and then be marked offline in the backup application when the next job tries to use the drive.

SOLUTION

To disable Target Resets on the tape SAN port on the M440, the following commands can be run on each node.

- 1 Connect to each node via ssh and login using the "stornext" user ID.
- 2 Change to root user permissions by running "sudo rootsh"
- 3 Disable Target Resets on the tape SAN port by issuing "/usr/local/bin/scli -n 1 TR 0"
- 4 Confirm that the setting is correct by issuing "/usr/local/bin/scli -c" and comparing the output for Port 2. It should look like:

```
[root@Acadia1-1 scripts]# scli -c
-----
HBA Instance 0: QLE2562 Port 1 WWPN 21-00-00-1B-32-9D-4A-8D PortID 00-00-00
-----
Connection Options           : 2 - Loop Preferred, Otherwise Point-to-
Point
Data Rate                    : Auto
Frame Size                   : 2048
Hard Loop ID                 : 0
Loop Reset Delay (seconds)   : 5
Enable Host HBA BIOS        : Disabled
Enable Hard Loop ID         : Disabled
Enable FC Tape Support      : Enabled
Operation Mode               : 0 - Interrupt for every I/O completion
Interrupt Delay Timer (100ms): 0
Execution Throttle          : 65535
Login Retry Count           : 8
Port Down Retry Count       : 30
Enable LIP Full Login       : Enabled
Link Down Timeout (seconds) : 30
Enable Target Reset         : Enabled
LUNs Per Target             : 128
Enable Out Of Order Frame Assembly: Disabled
-----
HBA Instance 1: QLE2562 Port 2 WWPN 21-01-00-1B-32-BD-4A-8D PortID 00-00-00
-----
Connection Options           : 2 - Loop Preferred, Otherwise Point-to-
Point
Data Rate                    : Auto
Frame Size                   : 2048
Hard Loop ID                 : 0
Loop Reset Delay (seconds)   : 5
Enable Host HBA BIOS        : Disabled
Enable Hard Loop ID         : Disabled
```

Enable FC Tape Support : Enabled
Operation Mode : 0 - Interrupt for every I/O completion
Interrupt Delay Timer (100ms) : 0
Execution Throttle : 65535
Login Retry Count : 8
Port Down Retry Count : 30
Enable LIP Full Login : Enabled
Link Down Timeout (seconds) : 30
Enable Target Reset : Disabled
LUNs Per Target : 128
Enable Out Of Order Frame Assembly: Disabled

Known Issues

[Table 1](#) lists the known issues for StorNext Metadata Appliances:

Table 1 Known Issues

Operating System	CR Number	SR Number	Description	Workaround (if applicable)
All	40015		The M440 <code>/etc/multipath.conf</code> file needs to be identical on both the primary and secondary nodes of the HA pair for failover to work properly.	Copy the <code>/etc/multipath.conf</code> file into the same directory on both MDC nodes of the M440 system any time changes are made to the file.
	31975		Machine check and CPU-related messages may be posted when one AC power cord is removed from the redundant power supply of the M440 system. Messages such as the following may be posted for each CPU core: Processor x below trip temperature. Throttling disabled. CPUx: Core power limit normal.	There is no work around. The messages are benign and can be ignored. No additional action is needed.
	38419	n/a	In the GUI, the reset button on the Configuration > System -> Network tab doesn't always restore current network configuration values.	When this happens, navigate away from the page by selecting any other menu item and navigate back again to reload the current network settings.

Operating System	CR Number	SR Number	Description	Workaround (if applicable)
All (cont'd)	38291	n/a	In an HA failover, an Admin Alert is issued if the new primary MDC attempts to initiate an fs_fmover process on the new standby MDC while the standby MDC is still being rebooted.	Once the impacted standby MDC finishes rebooting and becomes functional again, use fsddmconfig (or the GUI) from the master MDC to re-enable DDM for the standby MDC, as follows: # fsddmconfig -u -s e standby_mdc_hostname
	29483/ 38267	n/a	Logical and physical Fibre Channel port numbers may not match.	There is no current workaround for this issue. This will be fixed in a future StorNext release.
Linux	37538	1398524	GUI is unable to down a stripe group when LUNs are unavailable	Mark stripe groups down in the GUI before taking the stripe group's disks offline. If that is not possible, set the stripe group down directly through the FSM configuration file and restart the FSM. See the snfs_config(5) man page or the MAN Pages Reference Guide for details.
	38128	1395540	Using the GUI while a large Media import is kicked off via the command line can cause the GUI to timeout or crash.	Wait until a bulk load from tape is finished prior to opening the StorNext GUI.
	29098/ 37916	n/a	Admin alerts are generated for network or FC ports that are disconnected but are configured in the system.	The only way to prevent these alerts from displaying is to remove the network or FC ports that are disconnected from your configuration, unless the ports will only be down temporarily.

Contacting Quantum

More information about this product is available on the Quantum Service and Support website at www.quantum.com/ServiceandSupport. The Quantum Service and Support website contains a collection of information, including answers to frequently asked questions (FAQs). You can also access software, firmware, and drivers through this site.

For further assistance, or if training is desired, contact Quantum Technical Assistance Center:

North America	1 800-284-5101 (toll free) 1-720-249-5700
EMEA	+00800 7826 8888 (toll free) +49 6131 3241 1164
APAC	1-800-7826-8887 (toll free) +603-7953-3010
Service and Support Web Site	www.quantum.com/ServiceandSupport
Online Service Request System	www.quantum.com/OSR

(Local numbers for specific countries are listed on the Quantum Service and Support Website.)

Made in the USA. Quantum Corporation provides this publication "as is" without warranty of any kind, either express or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Quantum Corporation may revise this publication from time to time without notice.

COPYRIGHT STATEMENT

© 2012 Quantum Corporation. All rights reserved. Your right to copy this manual is limited by copyright law. Making copies or adaptations without prior written authorization of Quantum Corporation is prohibited by law and constitutes a punishable violation of the law.

TRADEMARK STATEMENT

Quantum, the Quantum logo, DLT, DLTtape, the DLTtape logo, Scalar, StorNext, the DLT logo, DXi, GoVault, SDLT, StorageCare, Super DLTtape, and SuperLoader are registered trademarks of Quantum Corporation in the U.S. and other countries. Protected by Pending and Issued U.S. and Foreign Patents, including U.S. Patent No. 5,990,810. LTO and Ultrium are trademarks of HP, IBM, and Quantum in the U.S. and other countries. All other trademarks are the property of their respective companies. Specifications are subject to change without notice.